

# Service Manual

## Screw Compressor

**M170 SIGMA CONTROL MOBIL**

No.: 9\_9425 01 E

Manufacturer:

**KAESER KOMPRESSOREN GmbH**

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

<http://www.kaeser.com>



<b>1</b>	<b>Regarding this document</b>	
1.1	Using the Document .....	1
1.2	Further documents .....	1
1.3	Copyright .....	1
1.4	Symbols and markings .....	1
1.4.1	Warning notices .....	1
1.4.2	Other notices and symbols .....	2
<b>2</b>	<b>Technical Specification</b>	
2.1	Nameplate .....	3
2.2	List of Options .....	3
2.2.1	Air Treatment .....	4
2.2.2	Compressed air distributor .....	4
2.2.3	Check valve function .....	5
2.2.4	Low temperature equipment .....	5
2.2.5	Automatic engine start/stop .....	5
2.2.6	External fuel pump .....	5
2.2.7	Chassis .....	5
2.2.8	Lighting .....	6
2.2.9	Pedestrian protection .....	6
2.3	Machine (without options) .....	6
2.3.1	Sound emission .....	6
2.3.2	Torques .....	7
2.3.3	Ambient conditions .....	7
2.3.4	Additional specifications .....	7
2.4	Chassis .....	8
2.4.1	Weights .....	8
2.4.2	Tyres .....	8
2.4.3	Wheel nut/bolt tightening torque .....	8
2.4.4	Towbar tightening torque .....	8
2.5	Compressor .....	9
2.5.1	Working pressure and FAD .....	9
2.5.2	Compressed air outlet .....	9
2.5.3	Pressure relief valve .....	9
2.5.4	Temperature .....	9
2.5.5	Cooling oil recommendation .....	10
2.5.6	Cooling oil charge .....	10
2.6	Engine .....	10
2.6.1	Engine data .....	10
2.6.2	Oil recommendation .....	11
2.6.3	Engine coolant recommendation .....	11
2.6.4	Fluid volumes .....	12
2.6.5	Batteries .....	12
2.7	Options .....	12
2.7.1	Fresh air filter .....	12
2.7.2	Low temperature equipment .....	12
2.7.3	Trickle Charging Starter Batteries .....	13
<b>3</b>	<b>Safety and Responsibility</b>	
3.1	Basic Information .....	14
3.2	Specified use .....	14
3.3	Improper Use .....	14
3.4	User's Responsibilities .....	14
3.4.1	Observe statutory and universally accepted regulations. ....	14
3.4.2	Defining personnel .....	15

3.4.3	Adherence to inspection schedules and accident prevention regulations .....	15
3.5	Dangers .....	16
3.5.1	Safely dealing with sources of danger .....	16
3.5.2	Safe machine operation .....	19
3.5.3	Organisational Measures .....	21
3.5.4	Danger areas .....	22
3.6	Safety Devices .....	22
3.7	Safety signs .....	22
3.8	Emergency situations .....	25
3.8.1	Correct fire fighting .....	25
3.8.2	Contact with operating fluids/materials .....	25
3.9	Warranty .....	25
3.10	Environmental Protection .....	26
<b>4</b>	<b>Design and Function</b>	
4.1	Bodywork .....	27
4.2	Component identification .....	28
4.3	Machine function .....	28
4.4	Operating modes and control modes .....	30
4.4.1	Operating modes .....	30
4.4.2	PART LOAD control .....	30
4.5	Safety devices .....	31
4.5.1	Monitoring functions with shutdown .....	31
4.5.2	Further safety devices .....	31
4.5.3	Battery isolating switch .....	32
4.6	SIGMA CONTROL MOBIL keys and displays .....	33
4.7	SIGMA CONTROL MOBIL function .....	34
4.7.1	Display .....	34
4.7.2	SIGMA CONTROL MOBIL operating sequence .....	36
4.7.3	Menu structure of the SIGMA CONTROL MOBIL .....	38
4.8	List of menus .....	39
4.8.1	SIGMA CONTROL MOBIL main menu .....	41
4.8.2	SIGMA CONTROL MOBIL settings menu .....	42
4.8.3	SIGMA CONTROL MOBIL event memory .....	45
4.9	Air treatment options .....	48
4.9.1	Compressed-air aftercooler .....	49
4.9.2	Cyclone separator .....	49
4.9.3	Heat exchanger .....	49
4.9.4	Filter combination .....	49
4.9.5	Fresh air filter .....	50
4.10	Low temperature equipment option .....	50
4.11	Start/stop/automatic option .....	51
4.12	"External fuel pump" option .....	51
4.13	Transport options .....	52
4.13.1	Chassis .....	52
4.13.2	Chassis .....	52
4.13.3	Chassis .....	52
4.13.4	Stationary frame .....	52
4.13.5	Stationary frame .....	52
4.14	Pedestrian protection option .....	53
<b>5</b>	<b>Installation and Operating Conditions</b>	
5.1	Safety .....	54
5.2	Installation conditions .....	54

<b>6</b>	<b>Installation</b>	
6.1	Safety .....	56
6.2	Reporting Transport Damage .....	56
6.3	Fitting the towbar .....	56
6.3.1	Fitting the height adjustable towbar .....	57
6.3.2	Fitting a non-adjustable towbar .....	58
6.4	Adjusting the chassis .....	60
6.4.1	Adjusting the towbar height .....	61
6.4.2	Changing the towing eye .....	61
<b>7</b>	<b>Initial Start-up</b>	
7.1	Safety .....	65
7.2	Instructions to be observed before commissioning or recommissioning .....	65
7.3	Checking installation and operating conditions .....	65
7.4	Setting the displayed units .....	66
7.5	Entering a password .....	67
7.6	Engine settings .....	68
7.7	Changing the parameters of the start/stop/automatic option .....	70
7.8	After storing the machine for a long period .....	72
7.9	Low-temperature operation (winter) .....	72
7.9.1	Starting assistance .....	72
7.9.2	Starting up low-temperature equipment .....	74
7.10	Activating the battery trickle charging .....	75
<b>8</b>	<b>Operation</b>	
8.1	Safety .....	77
8.2	Starting and stopping .....	77
8.2.1	Follow the brief instructions .....	77
8.2.2	Running the machine .....	78
8.2.3	Starting the engine .....	79
8.2.4	Setting the output pressure .....	80
8.2.5	Shutting down the machine .....	81
8.2.6	Shutting down in an emergency .....	82
8.3	Setting parameters .....	82
8.4	Acknowledging alarm, warning and maintenance messages .....	83
8.4.1	Acknowledge alarm message. ....	83
8.4.2	Acknowledging warning and maintenance messages .....	83
8.5	Resetting maintenance interval counters .....	83
8.6	Displaying machine operating data .....	84
8.7	Using the external fuel pump option .....	85
8.8	Using the low-temperature equipment .....	85
<b>9</b>	<b>Fault Recognition and Rectification</b>	
9.1	Basic instructions .....	86
9.2	SIGMA CONTROL MOBIL messages .....	86
9.2.1	Alarm messages on the controller (machine off) .....	86
9.2.2	Warning message on the controller .....	89
9.3	Engine faults and alarms .....	91
9.3.1	Engine refuses to start or does not turn over .....	91
9.3.2	Engine does not reach full speed .....	92
9.4	Compressor faults and alarms .....	92
9.4.1	Working pressure too high .....	92
9.4.2	Working pressure too low. ....	93
9.4.3	Pressure relief valve blowing off .....	93
9.4.4	Machine overheating .....	94
9.4.5	Too much oil residue in the compressed air .....	94

9.4.6	Oil flows from the compressor air filter after shutdown .....	95
9.4.7	High moisture content in the compressed air .....	95
<b>10</b>	<b>Maintenance</b>	
10.1	Safety .....	96
10.2	Maintenance message on the controller .....	96
10.3	Maintenance schedules .....	97
10.3.1	Logging maintenance work .....	97
10.3.2	Maintenance tasks after commissioning .....	98
10.3.3	Regular maintenance tasks .....	98
10.4	Engine .....	102
10.4.1	Cooler maintenance .....	102
10.4.2	Air filter maintenance .....	107
10.4.3	Fuel system maintenance .....	109
10.4.4	Checking the engine oil level .....	113
10.4.5	Engine oil filling and topping up .....	114
10.4.6	Changing the engine oil .....	115
10.4.7	Changing the oil filter .....	117
10.4.8	Maintaining the drive belt .....	118
10.4.9	Battery maintenance .....	122
10.5	Compressor .....	125
10.5.1	Checking cooling oil level .....	125
10.5.2	Cooling oil filling and topping up .....	126
10.5.3	Changing the cooling oil .....	127
10.5.4	Changing the oil filter .....	130
10.5.5	Oil separator tank dirt trap maintenance .....	131
10.5.6	Changing the oil separator cartridge .....	133
10.5.7	Air filter maintenance .....	135
10.5.8	Checking pressure relief valves .....	137
10.6	Cleaning the coolers and radiator .....	137
10.6.1	Cleaning the compressed air aftercooler .....	138
10.7	Maintenance of rubber sealing strips .....	139
10.8	Chassis .....	140
10.8.1	Wheel checks .....	140
10.8.2	Towbar maintenance .....	140
10.8.3	Brake system maintenance .....	142
10.9	Options .....	145
10.9.1	Cyclone separator maintenance .....	145
10.9.2	Combination filter maintenance .....	147
10.9.3	Fresh air filter maintenance .....	150
10.10	Document maintenance and service work. ....	153
<b>11</b>	<b>Spares, Operating Materials, Service</b>	
11.1	Note the Nameplate .....	154
11.2	Ordering consumable parts and operating materials .....	154
11.3	KAESER AIR SERVICE .....	155
11.4	Service Addresses .....	155
<b>12</b>	<b>Decommissioning, Storage and Transport</b>	
12.1	De-commissioning .....	156
12.1.1	Temporary decommissioning .....	156
12.1.2	Long-term decommissioning .....	157
12.2	Transport .....	158
12.2.1	Towing the compressor on the road .....	158
12.2.2	Parking the compressor .....	165
12.2.3	Transport with a crane .....	167

12.2.4	Transporting with a forklift truck .....	168
12.2.5	Transporting as a load .....	168
12.3	Storage .....	170
12.4	Disposal .....	170
<b>13</b>	<b>Annex</b>	
13.1	Marking .....	171
13.2	Pipeline and instrument flow diagram (P+I diagram) .....	171
13.3	Dimensional drawings .....	176
13.3.1	Dimensional drawing, chassis with height-adjustable tow bar .....	176
13.3.2	Dimensional drawing, chassis with fixed height tow bar .....	178
13.3.3	Dimensional drawing, chassis without parking brake .....	180
13.3.4	Dimensional drawings of stationary machine (skids) .....	182
13.3.5	Dimensional drawings of stationary machine (base frame) .....	184
13.4	Wiring diagrams .....	186
13.4.1	Electrical Diagram .....	186
13.4.2	Lighting and signalling system connection .....	210
13.4.3	Lighting and signalling system connection .....	215
13.4.4	Battery charger electrical diagrams .....	218
13.5	Fuel circulation diagram .....	228
13.6	SIGMA CONTROL MOBIL message codes .....	231
13.7	Operating instructions for compressed air filter (combination filter) .....	234
13.8	Operating instructions for compressed air filter (fresh air filter) .....	255





Fig. 1	Location of safety signs .....	23
Fig. 2	Overview Bodywork .....	27
Fig. 3	Right-hand door opened .....	28
Fig. 4	Left-hand door opened .....	28
Fig. 5	General design .....	29
Fig. 6	Stepless regulation of FAD (standstill) .....	31
Fig. 7	Battery isolating switch .....	32
Fig. 8	Instrument panel keys and displays .....	33
Fig. 9	Opening page .....	34
Fig. 10	Engine preheating .....	34
Fig. 11	Display of operating mode (example) .....	35
Fig. 12	Menu structure of the SIGMA CONTROL MOBIL .....	39
Fig. 13	Machine data symbol .....	41
Fig. 14	Symbolic settings menu .....	44
Fig. 15	Event memory .....	45
Fig. 16	Event memory example: Alarm message .....	47
Fig. 17	Event memory example: Warning message .....	47
Fig. 18	Event memory example: Maintenance message .....	47
Fig. 19	Message code structure .....	48
Fig. 20	Air treatment options .....	49
Fig. 21	Coolant pre-heating .....	51
Fig. 22	Minimum distance from excavations/slopes and walls .....	54
Fig. 23	Height adjustable towbar, fitted .....	57
Fig. 24	Fitting the height adjustable towbar .....	57
Fig. 25	Non-adjustable towbar fitted .....	58
Fig. 26	Fitting the overrun braking mechanism of the non-adjustable towbar .....	59
Fig. 27	Fitting the jockey wheel of the non-adjustable towbar .....	60
Fig. 28	Towbar height adjustment .....	61
Fig. 29	Changing the towing eye (height-adjustable towbar) .....	62
Fig. 30	Changing the towing eye (fixed height towbar, GB chassis version) .....	63
Fig. 31	Changing the towing eye (fixed height towbar, USA chassis version) .....	64
Fig. 32	Temperature display setting .....	66
Fig. 33	Unit of pressure setting .....	67
Fig. 34	Waiting for password entry .....	67
Fig. 35	Password level 1 activated. ....	68
Fig. 36	Engine settings menu .....	69
Fig. 37	Settings in start/stop/automatic .....	71
Fig. 38	Jumper cable connection diagram .....	73
Fig. 39	Coolant pre-heating .....	75
Fig. 40	Battery charger .....	76
Fig. 41	Starting instruments .....	77
Fig. 42	Brief instructions on starting and stopping .....	78
Fig. 43	«Battery isolating switch» .....	78
Fig. 44	Select menu option "set pressure in the oil separator tank" .....	80
Fig. 45	Setting the output pressure .....	81
Fig. 46	Operating data menu .....	84
Fig. 47	External fuel pump switch-on symbol .....	85
Fig. 48	Checking coolant level .....	103
Fig. 49	Draining the coolant from the radiator .....	106
Fig. 50	Radiator with centralised drainage .....	107
Fig. 51	Engine air filter maintenance .....	108
Fig. 52	Cleaning the filter element .....	108
Fig. 53	Fuel system maintenance .....	110
Fig. 54	Warning messages: Fuel filter water level .....	111

Fig. 55	Emptying the fuel pre-filter water trap .....	111
Fig. 56	Changing the fuel pre-filter cartridge .....	112
Fig. 57	Fuel filter maintenance .....	113
Fig. 58	Checking the engine oil level .....	114
Fig. 59	Draining the engine oil .....	116
Fig. 60	Draining the engine oil, central drain point .....	117
Fig. 61	Changing the oil filter .....	118
Fig. 62	Belt guard attachment .....	119
Fig. 63	Manual checking of the belt tension .....	120
Fig. 64	Changing/tensioning the drive belt .....	121
Fig. 65	Safety signs - warning stickers on the battery. ....	122
Fig. 66	Checking cooling oil level .....	125
Fig. 67	Changing the cooling oil .....	127
Fig. 68	Central compressor oil drainage .....	129
Fig. 69	Changing the oil filter .....	130
Fig. 70	Oil separator tank dirt trap maintenance .....	132
Fig. 71	Changing the oil separator cartridge .....	134
Fig. 72	Compressor air filter maintenance .....	136
Fig. 73	Cleaning the filter element .....	136
Fig. 74	Cooler/radiator cleaning .....	138
Fig. 75	Cleaning the compressed air aftercooler .....	139
Fig. 76	Towbar maintenance .....	141
Fig. 77	Ball coupling (EC version) .....	142
Fig. 78	Ball coupling (USA version) .....	142
Fig. 79	Checking the brake lining thickness .....	143
Fig. 80	Brake system adjustment .....	144
Fig. 81	Cleaning the dirt trap .....	146
Fig. 82	Combination filter maintenance .....	147
Fig. 83	Fresh air filter maintenance .....	150
Fig. 84	Towing alignment .....	159
Fig. 85	Ball coupling (ALKO-EU) .....	160
Fig. 86	Ball coupling wear indicator .....	161
Fig. 87	Ball coupling (ALKO-USA) .....	162
Fig. 88	Release the parking brake. ....	163
Fig. 89	Safety sign - secure the chocks .....	164
Fig. 90	Breakaway cable attachment .....	165
Fig. 91	Injury can occur if the towbar is unsupported and allowed to fall. ....	165
Fig. 92	Actuating the parking brake .....	166
Fig. 93	Safety sign - secure the chocks .....	167
Fig. 94	Transporting using a forklift truck .....	168
Fig. 95	Load secured by strapping .....	169
Fig. 96	Marking .....	171

Tab. 1	The levels of danger and their meaning .....	2
Tab. 2	Nameplate .....	3
Tab. 3	Combined label for coupling load and options fitted .....	4
Tab. 4	Air Treatment .....	4
Tab. 5	Compressed air distributor .....	4
Tab. 6	Check valve function .....	5
Tab. 7	Low temperature equipment .....	5
Tab. 8	Automatic engine start/stop .....	5
Tab. 9	External fuel pump .....	5
Tab. 10	Chassis .....	5
Tab. 11	Lighting .....	6
Tab. 12	Pedestrian protection .....	6
Tab. 13	Guaranteed sound power level .....	6
Tab. 14	Emission sound pressure level .....	7
Tab. 15	Guaranteed sound pressure level .....	7
Tab. 16	Torques for hex-head screws .....	7
Tab. 17	Ambient conditions .....	7
Tab. 18	Machine weights .....	8
Tab. 19	Tyres .....	8
Tab. 20	Wheel nut/bolt tightening torque .....	8
Tab. 21	Towbar tightening torque .....	8
Tab. 22	Working pressure and FAD .....	9
Tab. 23	Compressed air distributor .....	9
Tab. 24	Relief valve activating pressure .....	9
Tab. 25	Machine temperatures .....	9
Tab. 26	Cooling oil recommendation .....	10
Tab. 27	Cooling oil charge .....	10
Tab. 28	Engine data .....	10
Tab. 29	Engine oil recommendation .....	11
Tab. 30	Engine fluid volumes .....	12
Tab. 31	Batteries .....	12
Tab. 32	Fresh air filter conditions .....	12
Tab. 33	Ambient conditions .....	12
Tab. 34	Batteries .....	13
Tab. 35	Coolant pre-heater .....	13
Tab. 36	Battery charger .....	13
Tab. 37	Mains supply .....	13
Tab. 38	The following questions must be answered in preparation for an ISO 14001 certification/ monitoring (see WI-210001-Preparation for an ISO 14001 audit). .....	16
Tab. 39	Danger areas .....	22
Tab. 40	Safety signs .....	23
Tab. 41	Instrument panel keys and displays .....	33
Tab. 42	Display of messages prior to starting .....	35
Tab. 43	Operating mode display .....	35
Tab. 44	Display of operational state .....	36
Tab. 45	SIGMA CONTROL MOBIL operating sequence .....	36
Tab. 46	Menu structure of the SIGMA CONTROL MOBIL .....	38
Tab. 47	Settings menu .....	39
Tab. 48	Menu selection .....	39
Tab. 49	Menu option list .....	40
Tab. 50	Navigation (menu) .....	40
Tab. 51	Symbolic display of engine oil pressure .....	41
Tab. 52	Engine data display .....	41
Tab. 53	Display of compressor operating data .....	42

Tab. 54	Password level .....	42
Tab. 55	Menu guidance .....	43
Tab. 56	Event memory outline .....	46
Tab. 57	Message code structure .....	48
Tab. 58	Installation and operating conditions checklist .....	65
Tab. 59	Measures for re-commissioning the compressor after a long period of storage .....	72
Tab. 60	Battery charger control .....	76
Tab. 61	Fault messages and actions concerning the engine. ....	86
Tab. 62	Fault messages and actions concerning the compressor unit .....	88
Tab. 63	Fault messages and actions concerning the controller. ....	88
Tab. 64	General fault messages and measures .....	88
Tab. 65	Warning messages and measures relating to the engine. ....	90
Tab. 66	Warning messages and measures relating to the compressor .....	90
Tab. 67	General warning messages and measures .....	91
Tab. 68	Fault: engine refuses to start or comes to a stop. ....	91
Tab. 69	Fault: engine does not reach full speed. ....	92
Tab. 70	Fault: working pressure too high .....	92
Tab. 71	Fault: working pressure too low .....	93
Tab. 72	Fault: pressure relief valve blowing off .....	93
Tab. 73	Fault: machine overheating .....	94
Tab. 74	Fault: too much oil residue in the compressed air .....	94
Tab. 75	Fault: oil flows from the compressor air filter after shutdown .....	95
Tab. 76	Fault: high moisture content in the compressed air .....	95
Tab. 77	Maintenance messages and measures connected with engine maintenance. ....	97
Tab. 78	Maintenance messages and measures connected with compressor maintenance. ....	97
Tab. 79	Maintenance tasks after commissioning .....	98
Tab. 80	Maintenance intervals and regular maintenance tasks .....	98
Tab. 81	Regular maintenance tasks .....	99
Tab. 82	Regular maintenance task options .....	102
Tab. 83	KAESER coolant mixture table .....	105
Tab. 84	Logged maintenance tasks .....	153
Tab. 85	Compressor consumables .....	154
Tab. 86	Consumable engine parts .....	154
Tab. 87	"Temporarily decommissioned" information notice .....	156
Tab. 88	Long-term decommissioning checklist .....	157
Tab. 89	Text for the long-term decommissioned information notice .....	158
Tab. 90	Ball coupling wear indicator .....	162
Tab. 91	Message code range 1100 – 1199: engine faults .....	231
Tab. 92	Message code range 1200 – 1299: compressor unit faults .....	232
Tab. 93	Message code range 1300 – 1399: controller faults .....	232
Tab. 94	Message code range 1400 – 1499: general faults .....	232
Tab. 95	Message code range 2100 – 2199: engine maintenance .....	233
Tab. 96	Message code range 2200 – 2299: compressor unit maintenance .....	233
Tab. 97	Message code range 3100 – 3199: engine warnings .....	233
Tab. 98	Message code range 3200 – 3299: compressor unit warnings .....	233
Tab. 99	Message code range 3400 – 3499: general warnings .....	233

# 1 Regarding this document

## 1.1 Using the Document

The service manual is part of the machine. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the service manual in a safe place throughout the life of the machine.
- Pass the manual on to the next owner/user of the machine.
- Ensure that all amendments received are entered in the manual.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

## 1.2 Further documents

Included with this service manual are additional documents intended to assist in the safe operation of the machine:

- Certificate of acceptance / operating instructions for the pressure vessel
- Manufacturer's declaration / declaration of conformity in accordance with applicable directives
- Engine documentation (compressors driven by internal combustion engine)

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you give the data from the nameplate when ordering documents.

## 1.3 Copyright

This service manual is copyright protected. Queries regarding use or duplication of the documentation should be referred to KAESER. Correct use of information will be fully supported.

## 1.4 Symbols and markings

### 1.4.1 Warning notices

Warning notices indicate three levels of danger signified by the signal word.

- DANGER
- WARNING
- CAUTION



#### **DANGER**

These show the kind of danger and its source.

The possible consequences of ignoring a warning are shown here.

The signal word "DANGER" indicates that death or severe injury can result from ignoring the warning.

- The measures required to protect yourself from danger are shown here.

# 1 Regarding this document

## 1.4 Symbols and markings

- Always read and comply with warning instructions.

Signal word	Meaning	Consequences of non-observance
DANGER	Warns of an imminent threat of danger	Death or serious injury may result
WARNING	Warns of possible danger	Death or serious injury are possible
CAUTION	Warns of a possibly dangerous situation	Light injuries or material damage are possible

Tab. 1 The levels of danger and their meaning

### 1.4.2 Other notices and symbols



This symbol refers to particularly important information.

**Material** Here you will find details on special tools, operating materials or spare parts.

**Precondition** Here you will find conditional requirements necessary to carry out the task.  
Here conditions relevant to safety are named that will help you to avoid dangerous situations.

**Option da** ➤ This symbol is placed by lists of actions comprising one stage of a task.  
In lists of actions with several stages the sequence of actions is numbered.  
Information that refers to only one option is marked with a code (e.g.: "option da" means that this section is only valid for machines with the air treatment components "aftercooler and cyclone separator"). Option codes used in this service manual are explained in chapter 2.2.



Information referring to potential problems are identified by a question mark.  
The cause is named in the help text ...  
➤ ... and a remedy given.



This symbol refers to important information or measures concerning environmental protection.

**Further information** Here, your attention is drawn to further topics.

## 2 Technical Specification

### 2.1 Nameplate

The model designation and important technical information are given on the machine's nameplate. The nameplate is located on the outside of the machine (see illustration in chapter 13.1)

► Enter the data from the nameplate here as a reference.

Characteristic	Value
Vehicle identity no.	
Permissible total weight	
Permissible axle load	
Permissible coupling load	
Compressor model	
Material number	
serial number	
Year of manufacture	
Total weight	
Lifting point load capacity	
Rated engine power	
Engine speed	
Maximum working pressure	

Tab. 2 Nameplate

### 2.2 List of Options

A list of the options fitted to your machine helps to relate the information in this service manual. A list of options fitted is given as code letters on the right side of the coupling load / options label.

The label is to be found

- on the outside of the machine
- on the front (see chapter 13.1)



The following table lists all possible options. Only the codes for those options fitted appear on the label.

- Take a list of fitted options from the combined coupling load / options label.

M170	MATNR	SERNR
Here is given the specified coupling load.		Options fitted
		da db dc dd _
		fa _ _ _ _
		_ _ hc hd _
		ba bb _ _ _
		_ _ _ _ _
		_ ob _ od _
		_ _ _ _ _
		_ _ va si sh
		sa _ sc sd _
		ta tb tc _ te
		_ sg _ _ _

02-M0277

Tab. 3 Combined label for coupling load and options fitted

**2.2.1 Option da, db, dc, dd  
Air Treatment**

- Enter the fitted options as reference in this overview.

Option	Option code	Available?
Aftercooler and cyclone separator	da	
Heat exchanger	db	
Fresh air filter	dc	
Filter combination	dd	

Tab. 4 Air Treatment

**2.2.2 Option fa  
Compressed air distributor**

- Enter the fitted option as reference.

Option	Option code	Exists?
Non-separated compressed air distribution line	fa	

Tab. 5 Compressed air distributor



**2.2.3 Option hc, hd**  
**Check valve function**

➤ Enter the fitted option as reference.

Option	Option code	Exists?
Check valve	hc, hd	

Tab. 6 Check valve function

**2.2.4 Option ba, bb**  
**Low temperature equipment**

➤ Enter the fitted option as reference.

Option	Option code	Exists?
Low temperature equipment	ba	
Low temperature equipment + engine coolant pre-heating	bb	

Tab. 7 Low temperature equipment

**2.2.5 Option ob, od**  
**Automatic engine start/stop**

➤ Enter the fitted option as a reference in this overview:

Option	Option code	Available?
Automatic engine start/stop	ob	
Trickle charging for starter batteries	od	

Tab. 8 Automatic engine start/stop

**2.2.6 Option va**  
**External fuel pump**

➤ Enter the fitted option as a reference in this overview:

Option	Option code	Available?
External fuel pump	va	

Tab. 9 External fuel pump

**2.2.7 Option sa, sc, sd, sh, si**  
**Chassis**

➤ Enter the fitted option as a reference in this overview:

Option	Permissible axle load [kg]	Option code	Available?
Height adjustable towbar	2700	sa	

## 2 Technical Specification

### 2.3 Machine (without options)

Option	Permissible axle load [kg]	Option code	Available?
Fixed-height towbar	2700	sd	
Fixed height towbar without parking brake	2700	sh	
Stationary, on skids	–	sc	
Stationary, on a base frame	–	si	

Tab. 10 Chassis

#### 2.2.8 Option ta, tb, tc, te Lighting

➤ Enter the fitted option as reference.

Option	Option code	Exists?
None (stationary)	ta	
Reflective warning triangle	tb	
EG - 12 V	tc	
USA 12 V (DOT conformity)	te	

Tab. 11 Lighting

#### 2.2.9 Option sg Pedestrian protection

➤ Enter the fitted option as reference.

Option	Option code	Exists?
Pedestrian protection	sg	

Tab. 12 Pedestrian protection

## 2.3 Machine (without options)

### 2.3.1 Sound emission

#### 2.3.1.1 Sound emission

Model	M170
Guaranteed sound power level* [dB(A)]	99

\* To Directive 2000/14/EC

Tab. 13 Guaranteed sound power level

Model	M170
Emission sound pressure level* [dB(A)] According to EN ISO 11203: 1995 number 6.2.3.d.	80.5
Measurement distance: d = 1 m	
Logarithmic surface ratio: Q2 = 18dB(A)	
* Calculated from the guaranteed sound power level (2000/14/EC Directive, Sound Emission Standard ISO 3744)	

Tab. 14 Emission sound pressure level

**2.3.1.2 Sound pressure level**

Model	M170
Sound pressure level* [dB(A)]	76
Measurement distance: 7 m	
* Sound pressure levels comply with the American EPA Standard.	

Tab. 15 Guaranteed sound pressure level

**2.3.2 Torques**
**Recommended values for hexagonal bolts of strength category 8.8**

Hex-head screws							
Thread	M6	M8	M10	M12	M14	M16	M18
Torque [Nm]	9,5	23	46	80	127	195	280

Tab. 16 Torques for hex-head screws

**2.3.3 Ambient conditions**

Installation	Limit value
Maximum altitude AMSL* [m]	1000
Minimum ambient temperature [°C]	-10
Maximum ambient temperature [°C]	+50
* Higher altitudes are permissible only after consultation with the manufacturer.	

Tab. 17 Ambient conditions

**2.3.4 Additional specifications**

For specifications according to the machine's operating license, such as:

- dimensions,
- track width,
- footprint,

see the dimensional drawings in chapter 13.3.



The dimensional drawing also shows the position of the following inlets and outlets:

- Cooling air inlet
- Cooling air outlet
- Compressed air outlet
- Exhaust

## 2.4 Chassis

### 2.4.1 Weights



Maximum weights are shown. Actual weights of individual machines are dependent on equipment fitted (see machine nameplate).

Characteristic	Chassis		Stationary
	with	without	
Height adjustment			–
Actual total weight [kg]*			
Permissible axle load [kg]	2700	2700	–

\* Enter here for reference, the actual total weight taken from the nameplate.

Tab. 18 Machine weights

### 2.4.2 Tyres

Characteristic/marking	Value
Tyre size	215/75R 17.5
Minimum and recommended tyre pressure [bar]	5.75
Wheel bolts	M 18 x 1.5

Tab. 19 Tyres

Further information See tyre side wall for maximum pressure.

### 2.4.3 Wheel nut/bolt tightening torque

Fixing medium	Thread	Wrench size	Torque [Nm]
Wheel bolt	M 18 x 1.5	34	325

Tab. 20 Wheel nut/bolt tightening torque

### 2.4.4 Towbar tightening torque

Component	Thread	Strength category	Torque [Nm]
Ball coupling	M16	8.8	210
Towing eye	M16	8.8	210

Component	Thread	Strength category	Torque [Nm]
Towbar	M20	10.9	540–560
	M24	8.8	670–690

Tab. 21 Towbar tightening torque

## 2.5 Compressor

### 2.5.1 Working pressure and FAD

Maximum working pressure [bar]	8.6	10	12	14
SIGMA airend	293 G			
Free air delivery [m <sup>3</sup> /min]	17	15.5	13.5	11.5

Tab. 22 Working pressure and FAD

### 2.5.2 Compressed air outlet

Outlet valve ["]	Number
G 3/4	3
G 2	1

Tab. 23 Compressed air distributor

### 2.5.3 Pressure relief valve

Further information Maximum working pressure: see nameplate

Maximum working over-pressure [bar]	Activating pressure [bar]
8.6	11
10	13
12	15
14	16

Tab. 24 Relief valve activating pressure

### 2.5.4 Temperature

Machine temperatures	Values
Recommended airend discharge temperature for switching to load [°C]	30
Typical airend discharge temperature during operation [°C]	75 ..... 100
Maximum airend discharge temperature (automatic safety shut-down) [°C]	117

Tab. 25 Machine temperatures

### 2.5.5 Cooling oil recommendation

A sticker showing the type of oil used is located near the oil separator tank filler.  
 Information on ordering cooling oil is found in chapter 11.

Characteristic	SIGMA FLUID	
Oil grade	S-460	MOL
Classification	Silicone-free, synthetic oil	Mineral oil
Application	Standard oil for all applications except in connection with foodstuffs. Particularly suitable for machines with a high duty cycle.	Standard oil for all applications except in connection with foodstuffs. Particularly suitable for machines with a low duty cycle.
Approval	—	—
Viscosity at 40 °C	45 mm <sup>2</sup> /s (D 445; ASTM test)	44 mm <sup>2</sup> /s (DIN 51562-1)
Viscosity at 100 °C	7.2 mm <sup>2</sup> /s (D 445; ASTM test)	6.8 mm <sup>2</sup> /s (DIN 51562-1)
Flash point	238 °C (D 92; ASTM test)	220 °C (ISO 2592)
Density at 15 °C	864 kg/m <sup>3</sup> (ISO 12185)	—
Pour point	-46 °C (D 97; ASTM test)	-33 °C (ISO 3016)
Demulsibility at 54 °C	40/40/0/10 min (D 1401; ASTM test)	—

Tab. 26 Cooling oil recommendation

### 2.5.6 Cooling oil charge

Cooling oil	Fluid volume [l]
Machine	43
Compressor unit + heat exchanger (option db)	46

Tab. 27 Cooling oil charge

## 2.6 Engine

### 2.6.1 Engine data

Feature	Specification
Make/Model	Deutz / TCD 2012 L06

\* Use only diesel fuel to EN 590 or ASTM D975. Consult the engine manufacturer on the use of other fuels if necessary.

Feature	Specification
Engine control	Electronic
Fuel injection	Common rail system
Rated engine power [kW]	127
Speed under FULL LOAD [min <sup>-1</sup> ]	1800
Speed at IDLE [min <sup>-1</sup> ]	1300
Type of fuel	Diesel *
Fuel consumption under FULL LOAD [l/h]	32.5
Oil consumption related to fuel consumption [%]	approx. 0.5

\* Use only diesel fuel to EN 590 or ASTM D975. Consult the engine manufacturer on the use of other fuels if necessary.

Tab. 28 Engine data

### 2.6.2 Oil recommendation

The engine oil must meet the following classification:

- ACEA, class E4, E7
- API, class CF, CI-4



The engine is filled initially with engine oil of viscosity class SAE 10 W / 40.

Ambient temperature [°C]	Viscosity class
-30 ..... 30	SAE 0 W / 30 SAE 5 W / 30
-30 ..... 50	SAE 0 W / 40 SAE 5 W / 40
-20 ..... 30	SAE 10 W / 30
-30 ..... 50	SAE 10 W / 40
-15 ..... 50	SAE 15 W / 40
-5 ..... 50	SAE 20 W / 50

Tab. 29 Engine oil recommendation

### 2.6.3 Engine coolant recommendation

Engine coolant must meet the requirements of specification ASTM D4985.



Do not use a common coolant / antifreeze that meets only the requirements of ASTM D3306. Such coolants are intended only for light use in vehicles and could shorten the useful life of the engine.

The engine service manual gives further information on coolant application.

**2.6.4 Fluid volumes**

Name	Fluid volume [l]
Engine oil	17.5
Fuel	200.0
Engine coolant	21.5

Tab. 30 Engine fluid volumes

**2.6.5 Batteries**

Characteristic	Value
Voltage [V]	24 (2 x 12)
Capacity [Ah]	2 x 100
PTC testing current [A] (according to EN 50342)	850

Tab. 31 Batteries

Further information Depending on machine equipment, a higher capacity battery may be required. See chapter 2.7.2 for low temperature equipment.

**2.7 Options**
**2.7.1 Option dc  
Fresh air filter**

Feature	Value
Maximum working pressure [bar]	16
Minimum ambient temperature [°C]	1.5
Maximum ambient temperature [°C]	30

Tab. 32 Fresh air filter conditions

**2.7.2 Option ba  
Low temperature equipment**
**2.7.2.1 Ambient conditions**

Positioning	Limit value
Maximum altitude AMSL* [m]	1000
Minimum ambient temperature [°C]	-25
Maximum ambient temperature [°C]	+50

\* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 33 Ambient conditions



**2.7.2.2 Batteries**

Feature	Value
Voltage [V]	24 (2 x 12)
Capacity [Ah]	2 x 135
PTC testing current [A] (according to EN 50342)	1000

Tab. 34 Batteries

**2.7.2.3 Option bb  
Coolant pre-heating**

Coolant pre-heater	Value
Voltage [V]	240
Power [W]	1000
Rated current [A]	6.0

Tab. 35 Coolant pre-heater

**2.7.3 Option od  
Trickle Charging Starter Batteries**

Battery charger	Value
Model	24V DC/10A
Charging voltage [V]	26.6
Charging current [A]	>0.5
Maximum charging current [A]	10
Degree of protection	IP 54
Motor overload protection switch	3 poles
Setpoint [A]	4
Miniature circuit breaker [A]	16

Tab. 36 Battery charger

Mains supply	Value
Mains voltage [V/3~/N/PE]	400
Frequency [Hz]	50
Supply cable cross-section [mm <sup>2</sup> ] (Cu multi-core)	5 x 1.5
User's fusing [A]	16

Tab. 37 Mains supply

## 3 Safety and Responsibility

### 3.1 Basic Information

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- danger to life and limb of the operator or third parties,
- impairments to the machine and other material assets.

**DANGER**

Disregard of these instructions can result in serious injury.

- Read the service manual carefully and take note of the contents for safe machine operation.
- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual.
- Immediately rectify (have rectified) any faults that could be detrimental to safety.

### 3.2 Specified use

The machine is intended solely for generating compressed air for industrial use. Any other use is considered incorrect. The manufacturer is not liable for any damages that may result from incorrect use. The user alone is liable for any risks incurred.

- Keep to the specifications listed in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.
- Do not use compressed air for breathing purposes unless it is specifically treated.
- Do not use compressed for any application that will bring it into direct contact with foodstuffs unless it is specifically treated.

### 3.3 Improper Use

- Never direct compressed air at persons or animals.
- Do not use untreated compressed air for breathing purposes.
- Do not allow the machine to breath in toxic, acidic, flammable or explosive gases or vapours.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in force.

### 3.4 User's Responsibilities

#### 3.4.1 Observe statutory and universally accepted regulations.

These are, for example, nationally applied European directives and/or valid national legislation, safety and accident prevention regulations.

- Observe relevant statutory and accepted regulations during operation, transporting and maintenance of the machine.

### 3.4.2 Defining personnel

Suitable personnel are experts who, by virtue of their training, knowledge and experience as well as their knowledge of relevant regulations can assess the work to be done and recognize the possible dangers involved.

Authorised operators possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to operation,
- have received adequate training and authorisation to operate vehicles and electrical and compressed air devices.

Authorised maintenance personnel possess the following qualifications:

- are of legal age,
- have read, are conversant with and adhere to the safety instructions and sections of the service manual applicable to installation and maintenance,
- are fully conversant with the safety concepts and regulations of motor vehicle, electrical and compressed air engineering,
- are able to recognise the possible dangers of motor vehicle, electrical and compressed air devices and take appropriate measures to safeguard persons and property,
- have received adequate training in and authorization for the safe installation and maintenance of this machine.

Authorised transport personnel possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to transporting,
- are trained and authorised in safe vehicle transporting,
- are conversant with the safety regulations relating to handling motor vehicles and transport goods,
- are able to recognise the possible dangers of motor vehicles and take appropriate measures to safeguard persons and property.



#### **DANGER**

There is danger of fatal injury caused by contact with live components.

- Only qualified electricians may work on the installation, maintenance and repair of the machine's electrical assemblies. This includes work on current-carrying components.
- Ensure that personnel entrusted with operation, maintenance and transporting are qualified and authorized to carry out their tasks.

### 3.4.3 Adherence to inspection schedules and accident prevention regulations

The machine is subject to local inspection schedules.

#### **Examples of German operation**

- Have the pre-commissioning inspection carried out according to the Ordinance on Safety and Health, paragraph 14.

- Recurring inspections according to BGR 500, chapter 2.11:  
The user must ensure that the machine's safety devices are checked for function as required or at least annually.
- Oil changing according to BGR 500, chapter 2.11.  
The user must ensure that the cooling oil is changed as required or at least annually and the oil change must be documented. Intervals may be varied if an analysis proves that the oil is still usable.
- Keep to inspection intervals in accordance with the Ordinance on Industrial Safety and Health with maximum intervals as laid down in §15.

Inspection	Inspection interval	Inspecting authority
Equipment inspection	Before commissioning	Approved supervisory body
Internal inspection	Every 5 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)
Strength test	Every 10 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)

Tab. 38 The following questions must be answered in preparation for an ISO 14001 certification/monitoring (see WI-210001-Preparation for an ISO 14001 audit).

#### Checking the lifting eye

The user is responsible for ensuring that the machine's lifting eye and fixings are inspected according to national regulations for wear and damage.

- Have the lifting eye checked.  
If the lifting eye or fixings are not fully in order the machine may not be lifted in this way. Have the machine repaired immediately.

## 3.5 Dangers

### Basic Information

Information concerning the various forms of danger that can arise during machine operation are found here.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled 'Safety'.

Warning instructions are found before a potentially dangerous task.

### 3.5.1 Safely dealing with sources of danger

Information is found here concerning how to counter the various types of danger that can arise during machine operation.

#### Exhaust fumes:

Exhaust fumes from combustion engines contain carbon monoxide; this gas is odourless and can cause death.

Furthermore, diesel exhaust contains soot particles, some of which are noxious.

- Use the machine only outdoors!

- Do not inhale exhaust fumes.
- Direct the exhaust fumes to the open air with a pipe of at least 100 mm dia.

**Fire and explosion:**

Spontaneous ignition and combustion of fuel can result in serious injury or death.

- Allow no open flames or sparks at the place of use.
- Do not smoke while re-fueling.
- Never refuel the machine when it is running.
- Do not allow fuel to overflow.
- Wipe up spilled fuel immediately.
- Keep fuel away from hot machine parts.
- Make sure that the ambient temperature at the machine's place of use is within permissible limits.

**Hot coolant:**

The cooling system of a liquid-cooled engine at running temperature is under high pressure.

If the filler cap is unscrewed, hot coolant can spray out under pressure and cause severe scalding.

- Let the machine cool down before opening the cooling system.
- Unscrew the filler cap carefully by a quarter to half a turn at first. Remove the filler cap only when pressure has escaped completely.

**Forces of compression:**

Escaping compressed air can cause serious injury. The following information concerns work on components that could be under pressure.

- Wait until the compressor has automatically vented (check the pressure gauge: it must read 0 bar)
- Then open an outlet valve carefully to ensure that the line between the minimum pressure / check valve and the compressed air outlet is vented.
- Do not carry out welding, heat treatment or mechanical modifications to pressurised components (e.g. pipes and vessels) as this affects the component's resistance to pressure. The safety of the machine is no longer ensured.

**Spring forces:**

Sudden release of springs under tension can cause serious injuries.

Minimum pressure / check valves, pressure relief valves and inlet valves are powerfully spring-loaded.

- Do not open or dismantle any valves.

**Air quality:**

Compressed air from oil-injected compressors may not be used for breathing or processing foodstuff without suitable treatment.

- Never directly inhale compressed air.
- Use appropriate systems for air treatment before using the compressed air from this machine as breathing air (fresh air reinforcement) and/or in the processing of foodstuffs.
- Use foodstuff-compatible cooling oil whenever compressed air is to come into contact with foodstuffs.

**Rotating components:**

Touching the fan wheel, the coupling or the belt drive while the machine is running can result in serious injury.

- Operate the machine only with closed safety guards, access doors and panels.
- Shut down the machine before opening a door or canopy.
- Wear close-fitting clothes and a hair net if necessary.
- Install all safety devices and panels before starting the engine.

**Electricity:**

- Allow only qualified and authorised electricians or trained personnel under the supervision of a qualified and authorised electrician to carry out work on electrical equipment according to electrical engineering regulations.
- Check regularly that all electrical connections are tight and in proper condition.

**Temperature:**

- Avoid contact with hot components. These include, for example, engine, compressor airend, oil and compressed air lines, coolers and oil separator tank. Any objects in or near the flow of exhaust gas or discharged cooling air will become very hot.
- Wear long-sleeved garments (no synthetics such as polyester) and protective gloves.
- Wear protective gloves when connecting or disconnecting compressed air hoses.
- Allow the machine to cool down before commencing any maintenance work.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting fuel or oil vapours or parts of the machine.

**Noise:**

- Operate the machine only with intact sound insulation.
- Wear hearing protection if necessary. The pressure relief valve blowing off, for example, can be particularly loud.

**Operating materials:**

- Strictly forbid fire, open flame and smoking.
- Follow safety regulations when dealing with fuel, lubricants and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale fumes or vapours from fuel or oil.
- Do not eat or drink while handling fuel, cooling and lubricating fluids.
- Have suitable fire extinguishing materials at hand and clearly indicate the location and use of fire extinguishers.
- Use only KAESER approved operating materials.

**Unsuitable spare parts:**

- Use only spare parts approved by the manufacturer for use in this machine. Unsuitable spare parts compromise the safety of the machine.
- Use only genuine KAESER replacement parts on pressure bearing parts.

**Conversion or modification of the machine:**

- Do not permit conversion or modification of the machine as this can compromise function and safe working.
  - Do not install any non-approved additional components.
  - Do not make any changes to the machine that will increase its weight beyond the permissible limit and/or endanger its safe use or transportation.



Any such changes invalidate the approval to use the machine or tow it on the road.

**3.5.2 Safe machine operation**

The following is information supporting you in the safe handling of the machine during individual product life phases.

**WARNING**

Danger of injury from hot, rotating and electrically live components!  
Serious injury can be caused by touching such components.

- Operate the machine only with closed doors/canopy.
- Carry out maintenance and checks only with the machine shut down.

**Transportation**

- Shut down and fully disconnect the machine before transporting it.
- Allow transportation only by personnel trained in safe dealing with motor vehicles and the transporting of goods.
- Ensure that no persons are on the machine when transporting.
- If the machine is towed on public roads:
  - Ensure all running gear, including chassis, wheels, brakes, signaling and lighting, is in safe condition.
  - The local laws and regulations regarding the use of public roads must be observed.
- Follow the basic rules for safe towing:
  - The maximum permissible load for the towing vehicle coupling and the maximum coupling load given for the machine must not be exceeded.
  - Avoid causing a shift in the centre of gravity by an excessive or incorrectly distributed load.
  - Do not tow in a manner that will impose excessive stress on the machine or chassis.
  - Adjust towing speed to accommodate ground conditions. This applies particularly to unpaved roads and when negotiating curves.
- The towbar must be parallel with the ground otherwise towing instability can develop, resulting in damage to the machine and/or towing vehicle.
- Before moving the machine, make sure any security devices (e.g. anti-theft chain) are disassembled or turned off.

- When moving the machine using a crane: Observe regulations when using hoisting gear and load suspension equipment:
  - Do not enter the danger zone while the machine is being lifted.
  - Never lift and move the machine over people or occupied buildings.
  - Secondary or attached loads may not:
    - cause excessive load on the machine's lifting point (lifting eye),
    - adversely affect the machine's centre of gravity so that it is slanted.
  - Only the designated lifting point should be used to attach lifting gear and under no circumstances are handles, towbar or other components to be used.
  - Use only load suspension devices that are suitable for the stresses to which they will be subjected.
  - Use only hooks and shackles that comply with local safety regulations
  - Do not attach cables, chains or ropes directly to the machine's lifting eye.
  - Never tamper with the machine's lifting eye or its fixing.
  - Avoid jerking when lifting, as this may damage components.
  - Loads must be slowly lifted and carefully set down.
  - Never allow the load to hang from the crane longer than necessary.
- The following are forbidden:
  - transporting by slinging beneath a helicopter,
  - dropping by parachute.

**Positioning:**

- Do not position the machine directly against a wall. A build-up of heat from the exhaust can damage the machine.
- Do not operate in areas in which specific requirements regarding explosion protection are in force, e.g., the requirements of the ATEX directive 94/9/EC "Equipment and Protective Systems for use in Explosive Atmospheres".
- Ensure adequate ventilation.
- Ensure that required ambient conditions are maintained with regard to:
  - Ambient temperature
  - Clean inlet air with no damaging contaminants
  - Inlet air free of explosive or chemically unstable gases or vapours
  - Inlet air free of exhaust gasses from internal combustion engines
  - Inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Do not position the machine in warm cooling outlet air from other machines.
- Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.
- Chock the wheels to prevent unwanted movement.
- Do not place additional loads on the machine (e.g. excavator bucket as anti-theft measure).

**Operation:**

- Use the machine only when all safety devices, emergency stop devices and sound damping measures are in place and fully functioning.
- Before starting the machine, make sure that nobody will be at risk from the starting machine.



- Keep the access doors closed and panels in place for safety, quiet running and to ensure correct cooling air flow.
- Immediately stop and secure the machine against restarting if any malfunctions occur. Have any malfunctions corrected immediately.
- Carry out regular inspections:
  - for visible damage and leakage,
  - of safety devices,
  - of components needing to be monitored.
- Never operate machines without an air filter when drawing in air from the surroundings.
- Outlet valves must be closed when no consumers are connected.
- Use only suitable compressed air hoses:
  - that are of the right type and size for the highest permissible machine working pressure,
  - that are not damaged, worn or of reduced quality,
  - that have hose couplings and connections of the right type and size.
- Make sure compressed air hoses are de-pressurised before disconnecting from the machine.
- Secure the open end of an air hose before applying air pressure. An unsecured hose may whip and cause injury.
- At working pressures >7 bar, compressed air hoses should be secured by a cable to their respective outlet valves.

**Maintenance:**

- Before commencing any work on the machine, make sure it is shut down, cooled down, pressure-free and locked off against unwanted starting.
- Wear close-fitting, flame-resistant clothing. Wear protective clothing as necessary.
- Do not leave any loose components, tools or cleaning rags on or in the machine.
- Adhere to the planned intervals for maintenance and exchange of wear parts.
- Pressure lines must be fitted correctly. Perform a test run and check for leaks.
- Components removed from the machine can still be dangerous.  
Do not open or destroy removed components as some (inlet valves, for instance) are powerfully spring-loaded.
- Never remove or change sound damping materials. Ensure that sound damping material is not damaged or dirty. Replace as necessary.

**De-commissioning, storage and disposal:**

- Drain off fluids and dispose of them according to environmental regulations.  
These include, for example, fuel, engine oil and compressor cooling oil and engine coolant.
- Dispose of the machine in accordance with local environmental regulations.

**3.5.3 Organisational Measures**

- Designate personnel and their responsibilities.
- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

### 3.5.4 Danger areas

The table gives information on areas dangerous to personnel.  
 Only authorized personnel may enter these areas.

Task	Danger area	Authorized personnel
Transport	Within a 3 m radius of the machine.	Operating personnel to prepare for transport. No personnel during transport.
	Beneath the lifted machine.	No personnel!
Commissioning	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	
Operation	Within a 1 m radius of the machine.	Operating personnel
Maintenance	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	

Tab. 39 Danger areas

## 3.6 Safety Devices

Safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Check safety devices for correct function regularly.
- Do not remove or obliterate labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4, section 4.5.

## 3.7 Safety signs

The diagram shows the positions of safety signs on the machine. The table lists the various safety signs used and their meanings.



During cleaning or maintenance work, a check should be made that safety signs have not been removed or obliterated. Have missing or illegible signs replaced.












Fig. 1 Location of safety signs

Item	Symbol	Meaning
160*		Incorrect oil levels can cause damage to the machine or excessive oil content in the compressed air! ➤ Check the oil level regularly and correct as necessary.
310 311		It is forbidden to operate the machine with open doors or cover panels! Injuries or machine damage may result if the machine is operated when open. ➤ Operate only with the enclosure fully closed. ➤ Transport only with the enclosure fully closed.
320*		Loud noise and oil mist! Hearing damage and burns from relief valve blow off. ➤ Wear hearing protectors and protective clothing. ➤ Close the canopy or doors. ➤ Work carefully.
330 331		Hot surface! Risk of burns caused by contact with hot components! ➤ Do not touch the surface. ➤ Wear long-sleeved garments (no synthetics such as polyester) and protective gloves.
332		Hot surfaces and dangerous gasses! Burns from contact with hot components or gasses. ➤ Do not touch the surface. ➤ Wear long-sleeved garments (no synthetics such as polyester) and protective gloves. ➤ Do not inhale dangerous gasses.

\* Location within the machine

\*\* Portable machines only

\*\*\* Only machines with option dc

Item	Symbol	Meaning
450		Loud noise and compressed air blast! Damage to hearing and injury if ball valve is opened without a compressed air hose being connected. <ul style="list-style-type: none"> <li>➤ Connect a compressed air hose.</li> <li>➤ Open the ball valve.</li> </ul>
500**		Risk of accident from unstable towing! Injury and machine damage possible. <ul style="list-style-type: none"> <li>➤ The compressor towbar must be parallel with the ground when coupled to the towing vehicle.</li> <li>➤ Note instructions in the service manual regarding transporting.</li> </ul>
510**		Malfunction due to insufficient maintenance. Injury and machine damage possible. <ul style="list-style-type: none"> <li>➤ Regularly maintain the chassis.</li> <li>➤ Note the instructions in the operating manual regarding the chassis.</li> </ul>
600*		Risk of fatal injury caused by dismantling valves (spring-loaded or under pressure)! <ul style="list-style-type: none"> <li>➤ Do not open or dismantle valves.</li> <li>➤ Call an authorised Service Technician in the event of a fault.</li> </ul>
620 621		Risk of serious lacerations or even severing of extremities (fingers) from rotating components. <ul style="list-style-type: none"> <li>➤ Operate the machine only with closed safety guards, access doors and panels.</li> <li>➤ Shut down the machine before opening a door or canopy.</li> </ul>
1222***		Danger! Mortal danger from CO, CO <sub>2</sub> or toxic gasses. <ul style="list-style-type: none"> <li>➤ Draw in only surrounding air of breathing quality.</li> </ul>
		Danger! Danger to health from discharge of oily compressed air. <ul style="list-style-type: none"> <li>➤ Maintain surrounding air temperature between +1.5 °C and 30 °C.</li> <li>➤ Check the oil indicator at least once a day.</li> </ul>
1650*		Machine damage if switched while the engine is running! <ul style="list-style-type: none"> <li>➤ Use the «battery isolating switch» only with the engine stopped.</li> <li>➤ Do not use the «battery isolating switch» as a main or emergency switch.</li> </ul>

\* Location within the machine

\*\* Portable machines only

\*\*\* Only machines with option dc

Tab. 40 Safety signs

## 3.8 Emergency situations

### 3.8.1 Correct fire fighting

Suitable extinguishing media:

- foam
- carbon dioxide
- sand or earth

Unsuitable extinguishing agents:

- Strong jet of water
1. Keep calm.
  2. Give the alarm.
  3. If possible: Turn off engine using control devices.
  4. To ensure safety:
    - warn persons in danger,
    - help incapacitated persons,
    - leave the danger area as fast as possible.
  5. When trained accordingly: Attempt to extinguish the fire.

### 3.8.2 Contact with operating fluids/materials

The following operating fluids/materials are in the machine:

- fuel
- lubricating oils
- compressor cooling oil
- engine coolant
- battery acid



If necessary, request a copy of the applicable safety data sheet for KAESER SIGMA FLUID cooling oil.

- Eye contact:  
Rinse eyes thoroughly with lukewarm water and seek medical assistance.
- Skin contact:  
Wash off immediately.

## 3.9 Warranty

This service manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

In addition, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorised modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of original spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

### 3.10 Environmental Protection

- Store and dispose of operating materials and replaced parts in accordance with local environmental protection regulations.
- Observe relevant national regulations.



This applies particularly to parts contaminated with fuel, oil, coolants and acids.



- Do not allow operating materials to escape to the environment or into the sewage system.

## 4 Design and Function

### 4.1 Bodywork

Bodywork is understood to be the exterior of the machine mounted on the chassis.




Fig. 2 Overview Bodywork

- |                                   |                         |
|-----------------------------------|-------------------------|
| ① Right-hand wing door            | ⑤ Lower body            |
| ② Sound damping louvre for cooler | ⑥ Left-hand wing door   |
| ③ Snap fastener                   | ⑦ Cover for lifting eye |
| ④ Handle                          |                         |

The bodywork has several functions when it is closed:

- Weather protection
- Sound insulation
- Guarding against touching
- Cooling air flow

The bodywork is not suitable for the following uses:

- Persons walking, standing or sitting on the machine.
- Use as resting place or storage of any kind of load.

Safe and reliable operation is only ensured when the bodywork is closed.

The wing doors are provided with handles for opening. Release the doors by the snap fasteners.

The doors are held open by gas springs.

## 4.2 Component identification




Fig. 3 Right-hand door opened

- |                                   |                               |
|-----------------------------------|-------------------------------|
| ① Instrument panel (cover closed) | ⑥ Fuel filter                 |
| ② Quick-stop pushbutton           | ⑦ Fuel filter with water trap |
| ③ Inlet valve                     | ⑧ Coolant expansion tank      |
| ④ Fuel tank                       | ⑨ Engine air filter           |
| ⑤ Engine                          | ⑩ Compressor air filter       |




Fig. 4 Left-hand door opened


- |                            |  |
|----------------------------|--|
| ⑪ Fan                      | ⑮ Control valve with proportional controller |
| ⑫ Control cabinet          | ⑯ Minimum pressure/check valve               |
| ⑬ Battery isolating switch | ⑰ Lifting eye                                |
| ⑭ Oil separator tank       |  |

## 4.3 Machine function

Machine function (without options)

Item numbers correspond to the pipe and instrument flow diagram in chapter 13.2.




**Fig. 5 General design**

- |  |  |
|--|--|
| ① Compressor air filter                    | ⑲ Combination valve (oil temperature thermostat) |
| ③ Inlet valve                              | ⑳ Oil cooler                                     |
| ④ Airend                                   | ㉑ oil filter                                     |
| ⑤ Oil separator tank                       | ㉒ Proportional controller                        |
| ⑦ Oil separator cartridge                  | ㉓ Engine air filter                              |
| ⑩ Compressed air distributor               | ㉔ Venting valve                                  |
| ⑬ Pressure relief valve                    | ㉕ Fan  |
| ⑭ Pressure gauge (on the instrument panel) | ㉖ Minimum pressure/check valve                   |
| ⑮ Engine                                   | ㉗ Control valve                                  |
| ⑯ Oil return line                          |  |

Ambient air is cleaned as it is drawn in through the filter ①.

The air is then compressed in the airend ④.

The airend is driven by an internal combustion engine ⑮.

Cooling oil is injected into the airend. It lubricates moving parts and forms a seal between the rotors themselves and between them and the airend casing. This direct cooling in the compression chamber ensures a very low airend discharge temperature.

Cooling oil recovered from the compressed air in the oil separator tank ⑤ gives up its heat in the oil cooler ⑳. The oil then flows through the oil filter ㉑ and back to the point of injection. Pressure within the machine keeps the oil circulating. A separate pump is not necessary. A thermostatic valve ⑲ regulates the compressor's temperature.

Compressed air, freed of cooling oil in the oil separator tank ⑤, flows through the minimum pressure / check valve ㉖ into the air distributor ⑩. The minimum pressure / check valve ensures that there is always a minimum internal pressure sufficient to maintain cooling oil circulation in the machine.

The cooling fan ㉕ ensures optimum cooling of all components within the enclosure.

## 4.4 Operating modes and control modes

### 4.4.1 Operating modes

The machine operates in the following modes:

- **LOAD**
  - The inlet valve is open.
  - The engine runs at maximum speed.
  - The airend delivers compressed air.
- **MODULATING**
  - With the help of a control valve (the proportional controller) the degree of opening of the inlet valve is steplessly varied in response to the air demand.
  - The load and fuel consumption of the engine rises and falls with the air demand.
  - The airend delivers compressed air.
- **IDLE**
  - The inlet valve is closed.
  - The control valve opens, allowing pressure in the oil separator tank to be applied to the inlet valve.
  - Compressed air then flows in a closed circuit through the airend, the oil separator tank and the control valve.
  - The pressure in the oil separator tank remains constant.
  - The engine runs at minimum speed.
- **STANDSTILL (shut down)**
  - The inlet valve closes.
  - The venting valve opens to de-pressurise the machine.
  - The engine stops.

### 4.4.2 PART LOAD control

The control system regulates the volume of air generated to match the actual demand. The machine keeps the working pressure constant by varying the volume of compressed air delivered, thereby matching the air demand.

With the help of an electrical control valve (the proportional controller), the opening and closing of the inlet valve is continuously varied in response to the actual air demand. The airend provides compressed air for connected consumers.

This stepless delivery regulation minimises fuel consumption of the engine. The load and fuel consumption of the engine rises and falls with the air demand.




Fig. 6 Stepless regulation of FAD (standstill)

- |    |                                    |    |                                    |
|----|------------------------------------|----|------------------------------------|
| ③  | Inlet valve                        | ②⑦ | Venting valve                      |
| ④  | Compressor block                   | ④⑥ | Nozzle                             |
| ⑤  | Oil separator tank                 | ⑤② | Control valve                      |
| ②③ | Proportional controller (electric) | ⑥③ | Control valve (proportional valve) |

## 4.5 Safety devices

### 4.5.1 Monitoring functions with shutdown

The SIGMA CONTROL MOBIL monitors the important machine parameters. The machine is automatically shut down if an alarm occurs.

The SIGMA CONTROL MOBIL saves the alarm message.

Further information Further information on alarm messages is to be found in chapter 9.2.1.

### 4.5.2 Further safety devices

The following safety devices are provided and may not be modified in any way.

- Quick stop button  
For immediate shutdown of the machine. The engine comes to a stop. The pressure system is vented.

- Pressure relief valves  
Pressure relief valves protect the system against unacceptable pressure rise. They are factory set.
- Enclosures and covers over moving parts and electrical connections:  
These protect against accidental contact.

### 4.5.3 Battery isolating switch

The «battery isolating switch» disconnects the battery completely from the machine's electrical system (electronic controller protection, fire protection, battery discharge protection).

**CAUTION**

Danger of short circuit

Damage to the machine electrics is possible.


- Use the «battery isolating switch» only when the machine is at standstill.
- Do not use the «battery isolating switch» as a main or emergency switch.





04-M0022

Fig. 7 Battery isolating switch

- ① «Battery isolating switch»

**4.6 SIGMA CONTROL MOBIL keys and displays**

**Fig. 8 Instrument panel keys and displays**

Item	Sign	Name	Function	Background LED
1		«Acknowledge » key.	Acknowledge key Acknowledges active and displayed messages.	Flashes when a message is active and waiting for acknowledgement.
2		«Information» key	Displays the event memory.	Flashes if a message is active.
3		«Menu» key	Displays the main menu.	–
4		«Horizontal arrows» change values «LEFT» and «RIGHT» keys	Change parameter values, cursor movement when entering a password.	–
5		«UP» and «DOWN» keys	Vertical movement in menus. Change values in password entry.	–
6		«esc» key	Returns to the menu, interrupts an entry.	–
7		«Enter» key	Selects a menu option, confirms an entry.	–
8		«Stop» key	Stops the machine.	Lights when an alarm occurs

Item	Sign	Name	Function	Background LED
9		«Start» key	Starts the machine	Flashes when ready to start. Illuminates when the engine is running.
10		«Load» key	Toggles between warm up and load.	Flashes when ready to switch to LOAD. Illuminates when the machine is operating under LOAD.
11	–	Indicator field or display	Graphic display	–

Tab. 41 Instrument panel keys and displays

## 4.7 SIGMA CONTROL MOBIL function

### 4.7.1 Display

Description of display field

- Graphic display
- Monochrome display
- 128 x 64 pixels

#### Opening page

The following is shown on this page while the controller is booting up:




Fig. 9 Opening page

#### Preheating




At temperatures below zero the engine is preheated, regulated by the engine control unit. The preheating period is influenced by an ambient temperature sensor.



Fig. 10 Engine preheating

**Display of messages before the machine is ready to start**

If there are messages in the event memory from the last machine operation, these will be displayed.

Message type	Function
Alarm	<ul style="list-style-type: none"> <li>➤ Displayed alarm rectified</li> <li>➤ Press the «Acknowledge» key .</li> </ul> <p>The message is deleted and the engine can be started.</p>
Warning	<ul style="list-style-type: none"> <li>➤ Press the «Acknowledge» key .</li> </ul> <p>The message is deleted and the engine can be started.</p>
Maintenance	<ul style="list-style-type: none"> <li>➤ Press the «Acknowledge» key .</li> </ul> <p>The message is deleted and the engine can be started.</p>

Tab. 42 Display of messages prior to starting



See chapter 4.8.3 for explanation of messages.

**Operating mode display**

As soon as the machine is started, the display changes to show the operating mode.



The display changes automatically with each change in the machine's operating mode.

The display can be composed of symbols and alpha-numeric characters that together give a clear and logical meaning.

The display of operating mode is in two parts. The common display in the upper screen **always** shows the current airend discharge temperature. The lower half shows the machine's operating mode.



Fig. 11 Display of operating mode (example)









-  Airend discharge temperature (ADT)
-  Operational state

Meaning of the display	Explanation
Airend discharge temperature	The airend discharge temperature can be displayed in °C, °F or K as selected by the user.
Operational state	See table for displays of operational states.

Tab. 43 Operating mode display

**Display of operational state**



The machine's current operational state is shown in the lower half of the display. The following states are available:

Item	Operational state	Meaning of the display	Explanation
B1		Ready to start	The machine can be started.
B2		IDLE	The machine is running in IDLE.
B3		Start-up	The engine is run up.
B4		LOAD	The machine is running under LOAD.
B5		Run-on phase	Cool-down function The timer setting is 60 seconds.
B6		Cool-down phase when machine overheated	Cool-down phase when the compressor and/or engine coolant overheated.
B7		Back pressure	The remaining pressure in the OST* is displayed and the machine cannot be started. The display is in bar or psi as selected by the user.
B8		Start inhibit	A start sequence is inhibited and the display shows the time remaining until the next start sequence is allowed. The timer setting is 20 seconds.

OST\* = oil separator tank

Tab. 44 Display of operational state

**4.7.2 SIGMA CONTROL MOBIL operating sequence**













Operating sequence	Key	Indication	Explanation
Ready to start			The «Start» key flashes.

\* ADT = airend discharge temperature

\*\* ECT = engine coolant temperature

\*\*\* OST = oil separator tank









Operating sequence	Key	Indication	Explanation
<b>Start</b> ➤ Press the «Start» key.			The engine starts automatically. Maximum starting time 15 seconds. The starter disengages automatically when the engine picks up speed.
<b>Engine running</b>			The «Start» key illuminates.
<b>Warm-up / IDLE phase</b>			The machine runs in IDLE until the ADT* and ECT** reach 30 °C. While either of the temperatures is > 30 °C, the machine cannot be switched to LOAD. The machine may be switched to LOAD when the «Load» key flashes.
<b>LOAD</b> ➤ Press the «Load» key.			The machine switches over to LOAD. The «Load» key illuminates.
<b>Setting pressure</b>	 	 	The outlet pressure is set.
<i>either</i> <b>Run-on phase</b> ➤ Press the «Load» key.			The machine switches over to unloaded run-on. The engine runs at IDLE speed. The machine is vented. The «Load» key flashes.

\* ADT = airend discharge temperature

\*\* ECT = engine coolant temperature

\*\*\* OST = oil separator tank

Operating sequence	Key	Indication	Explanation
<i>or</i> <b>Stop</b> ➤ Press the «Stop» key and hold for more than a second.		 60 s  7 bar  20 s	The machine switches over to unloaded run-on. The cool-down period is displayed The engine runs at IDLE speed. The machine is vented. The «Load» key flashes. Pressure in the OST** > 1 bar: back-pressure displayed. Pressure in the OST** ≤ 1 bar: display indicates "ready to start".
<b>Failed start, starting sequence interrupted</b>		 20 s	The start inhibit function is activated if the machine fails to start or if the starting sequence is interrupted. The display shows the time remaining until the next starting sequence is allowed.

\* ADT = airend discharge temperature

\*\* ECT = engine coolant temperature

\*\*\* OST = oil separator tank

Tab. 45 SIGMA CONTROL MOBIL operating sequence

### 4.7.3 Menu structure of the SIGMA CONTROL MOBIL

#### Menu structure

Main menu	Menu level 1	Menu level 2
Display of operating modes	Main menu	Operating data
		Compressor engine
		Settings menu
		Password input
		Engine test mode (ECU)
	Generator operating data	
	Event memory	Alarm messages
Warning messages		
Maintenance messages		


Tab. 46 Menu structure of the SIGMA CONTROL MOBIL

**Settings menu**

Menu level 2	Menu level 3	Menu level 4
Settings menu	Setting indicator unit	–
	Controller functions (password-protected)	Compressor model
		Options
		Service functions
Engine settings	–	
Options	"Start/stop/automatic" option	
	"External fuel pump" option	
	"GSM/GPS module" option	

Tab. 47 Settings menu

**4.8 List of menus**

Pressing the «Menu» key  (Fig. 8, item ③) opens the main menu.

By looking through the menu options, the engine and compressor unit data can be seen and adjustments made. The event memory can also be viewed.

**Format**











Fig. 12 Menu structure of the SIGMA CONTROL MOBIL

- ① Menu selection
- ② Display password level
- ③ Menu option list
- ④ Navigation (menu)
- A Display field size (white background)
- B Selection choice (grey background)








**Menu selection**

Selection	Menu	Sign	Description
1a	Main menu		Home page Display of machine data

Selection	Menu	Sign	Description
1b	Settings menu		Parameter settings for machine data
1c	Controller menu	 	Not available to user. Password protected.
1d	Event memory		The following events (messages) are saved: <ul style="list-style-type: none"> <li>■ Alarms,</li> <li>■ warnings,</li> <li>■ maintenance due.</li> </ul>
1e	Fault memory		Display of alarms. An alarm shuts the machine down automatically.
1f	Maintenance memory		Display of maintenance due







Tab. 48 Menu selection

**Menu option list**

Selection	Sign	Meaning
3a		Engine data
3b		Compressor unit data
3c		Parameter settings
3d		Messages
3e		Password
3f		Engine control unit (for Service personnel)
3g		Generator data (only machines with generators)

Tab. 49 Menu option list

**Navigation (menu)**

Selection	Sign	Meaning	Key
4a		Menu option above	
4b		Menu option below	
4c		Key to confirm or change to the next menu option.	

Tab. 50 Navigation (menu)

4.8.1 SIGMA CONTROL MOBIL main menu

By selecting menu options from the main menu, the machine's current operating data can be viewed. The data display consists of graphic symbols and parameter values (value + unit). The graphic symbol can be made up of pictograms that together make up a logical meaning. Two machine parameters are shown on each display page.




Fig. 13 Machine data symbol

- |                            |                        |
|----------------------------|------------------------|
| M1 Engine speed            | M7 Battery             |
| M2 Engine intake/turbo air | V1 Compressor (airend) |
| M3 Engine coolant          | A1 Pressure            |
| M4 Engine oil              | A2 Temperature         |
| M5 Fuel level              | A3 Temperature high    |
| M6 Operating hours counter | A4 Sensor              |

Example of a composed symbol

Indication	Symbol meaning	Parameter
4,6 bar	Engine oil + pressure = engine oil pressure	4.6 bar



Tab. 51 Symbolic display of engine oil pressure

Engine data

The engine operating data is presented on numerous display pages. With the aid of the arrow keys, one can page through the menu guide between the display pages.

The following data are shown:

Display page	Figure	Motor data
1. Page	4,6 bar <hr/> 76 °C	Oil pressure Coolant temperature
2. Page	110,5 h <hr/> 1000 U/min	Operating hours Speed
3. Page	65 % <hr/> 25,5 V	Fuel level Battery voltage





Display page	Figure	Motor data
4. Page	 2,2 bar	Turbo air pressure Turbo air temperature
	 23 °C	

Tab. 52 Engine data display

**Compressor data**

The compressor unit operating data is presented on numerous display pages. With the aid of the arrow keys, one can page through the menu guide between the display pages.

The following data are shown:

Display page	Figure	Compressor unit data
1. Page	 88 °C	Airend discharge temperature Pressure in the oil separator tank (OST)
	 7,5 bar	
2. Page	 7,5 bar 	Set pressure in the oil separator tank (OST)

Tab. 53 Display of compressor operating data

**4.8.2 SIGMA CONTROL MOBIL settings menu**

Selecting the hand symbol (table 48, item (1b)) in the main menu will open the settings menu.

**Password level**



Entries and changes in the settings menu are only possible with the correct password.

The password level is reached by means of the "key" symbol in the individual menu views.



The password level is reset 3 minutes after the last key has been depressed. Temporary settings are not saved and are lost!

There are more than one password levels

Password level	Symbol	Authorization
0		No password <ul style="list-style-type: none"> <li>Only user settings possible</li> </ul>
1		Renter password <ul style="list-style-type: none"> <li>Engine basic settings.</li> <li>Confirm maintenance carried out.</li> <li>Temporary pressure increase of 1.5 bar above working pressure.</li> </ul>

\* Maximum machine working pressure

Password level	Symbol	Authorization
2	0→2	Customer service password <ul style="list-style-type: none"> <li>■ Engine basic settings.</li> <li>■ Confirm maintenance carried out.</li> <li>■ Release options.</li> <li>■ Temporary pressure increase of 1.5 bar above working pressure.</li> </ul>
3	0→3	Service password <ul style="list-style-type: none"> <li>■ All settings possible.</li> </ul>







\* Maximum machine working pressure

Tab. 54 Password level

Further information See chapter 7.5 for information on entering passwords.

### Operation

The following keys are used in the settings menu:

Symbol	Key name	Location on the operating panel	Function
	«UP and DOWN »arrows	5	Navigation to parameters.
			
 	«Value changing» keys	4	Change parameter value
	«Enter» key	7	Save settings.
	«esc »key	6	Interrupts an entry. Returns to menu.

Tab. 55 Menu guidance

List of menus




Fig. 14 Symbolic settings menu

- |    |   |    |  |
|----|---|----|--|
| ①b | Settings menu   | ⓔ5 | GSM/GPS module option (option illustrated as inactive, in preparation) |
| ③  | Navigation  | ⓔ6 | Fuel pump option (illustrated as inactive)                             |
| ⓔ1 | Unit of temperature   | ⓔ7 | Start-stop-automatic option (illustrated as inactive)                  |
| ⓔ2 | unit of press.  | ⓐ  | Display field size (white background)                                  |
| ⓔ3 | Controller settings (with key symbol, so long as the right password is not entered) | ⓑ  | Selection choice (grey background)                                     |
| ⓔ4 | Engine settings   |    |  |

**Unit of temperature**

The temperature unit is selected in the Temperature unit menu option ⓔ1.

Temperature can be displayed in the following units:

- °C
- °F
- K

**Unit of pressure**

The displayed unit of pressure is selected in the pressure unit menu option ⓔ2.

Pressure can be displayed in the following units:

- bar
- psi

**Controller settings**

This menu option is not available to users. Changes in this menu option can only be made with the correct password.

**Engine settings**

Settings are made in the menu option "engine settings" ⓔ4.



This menu option is not available to users. Changes in this menu option can only be made with the correct password.

The following parameters can be set:

- Starter running time
- Cool-down run-on time of the engine (machine in IDLE).
- FULL LOAD engine speed.
- IDLE engine speed.

**Option ob "Start/stop/automatic" option**

The symbol is stricken through if this option is not available on the machine. The menu option cannot be entered.

Changes to the parameter are made in the start/stop/automatic menu option (E7).

The following parameters can be changed:

- Run-on period under LOAD.
- Run-on period in IDLE.
- Manual or automatic operation (only in Service password level 3).

**Option va "External fuel pump" option**

The symbol is stricken through if this option is not available on the machine. The menu option cannot be entered.

By selecting the fuel pump menu option (E6) the fuel tank can be filled with an external pump.

**4.8.3 SIGMA CONTROL MOBIL event memory**

Selecting the i symbol (table 48, item (1d)) in the main menu will open the event menu menu option.





















Fig. 15 Event memory

- |                                    |   |
|------------------------------------|---|
| (1d) Event memory                  | (R5) Fault memory                         |
| (R1) Alarms                        | (3) Navigation                            |
| (R2) Warnings                      | (A) Display field size (white background) |
| (R3) Maintenance                   | (B) Selection choice (grey background)    |
| (R4) Machine data information page |   |

The event memory is sub-divided into menu options:

Category	Short description	Sign	Note
Alarms	R1		<p>The machine will be shut down.</p> <p>The «Acknowledge» key  flashes.</p> <p>The «Information» key  and «Stop» key  are illuminated.</p> <p>If acknowledgement of the alarm by pressing the «Acknowledge» key  is possible, both lamps are extinguished.</p> <p>The machine can only be restarted when the cause of the alarm is corrected.</p>
Warnings	R2		<p>The machine will not be shut down.</p> <p>The «Acknowledge» key  flashes.</p> <p>The «Information» key  illuminates.</p> <p>These are extinguished by pressing the «Acknowledge» key .</p> <p>The «Information» key  remains illuminated, even after restarting, until the cause of the warning is rectified.</p>
Maintenance	R3		<p>The machine will not be shut down.</p> <p>The «Acknowledge» key  flashes.</p> <p>The «Information» key  illuminates.</p> <p>These are extinguished by pressing the «Acknowledge» key .</p> <p>The «Information» key  remains illuminated, even after restarting, until the maintenance is carried out and the maintenance interval counter reset.</p>
Machine data information page	R4		<p>The following data are shown:</p> <ul style="list-style-type: none"> <li>■ Compressor model</li> <li>■ Pressure</li> <li>■ Speeds</li> <li>■ Equipment number</li> <li>■ Software version</li> </ul>
Fault memory	R5		<p>Display of the last 10 faults with</p> <ul style="list-style-type: none"> <li>■ fault code</li> <li>■ operating hours</li> </ul>

Tab. 56 Event memory outline



Selection keys are used to navigate through the event memory.

### Make up of messages

The following illustrations show how typical examples of how individual message categories are produced.

Alarm message




Fig. 16 Event memory example: Alarm message

- R1 Event memory category: Alarm
- R6 Message code
- R7 Operating hours since this occurred last time
- R8 Symbolic fault location (example: coolant - temperature fault)

Warning messages




Fig. 17 Event memory example: Warning message

- R2 Message category: Warning
- R6 Message code
- R7 Operating hours since this occurred last time
- R8 Symbolic fault location (example: airend discharge temperature too high)

Maintenance message




Fig. 18 Event memory example: Maintenance message

- R3 Message category: Maintenance
- R6 Message code
- R9 Time when maintenance is due.
- RX Maintenance interval

**Message code**

The key to the 4-character message code **R6** is as follows.




Fig. 19 Message code structure

- a** Type of message
- b** Location of occurrence
- c** Key

The following table gives further information on message code structure.

Item	Position	Explanation
a	1. Position	Type of message <ul style="list-style-type: none"> <li>■ 1 – Alarm</li> <li>■ 2 – Maintenance</li> <li>■ 3 – Warning</li> </ul>
b	2. Position	Location of occurrence <ul style="list-style-type: none"> <li>■ 1 – Engine</li> <li>■ 2 - Compressor unit</li> <li>■ 3 – Controller</li> <li>■ 4 – General</li> </ul>
c	3. and 4. positions	Key from 00 ... 99

Tab. 57 Message code structure

Further information See chapter 13.6 for a list of all SIGMA CONTROL MOBIL message codes.

## 4.9 Air treatment options

For some applications, the compressed air generated by this machine must be treated before use. The following describes the possible air treatment options that may be fitted to the machine.




Fig. 20 Air treatment options

- |  |                                  |
|--|----------------------------------|
| ① Compressed air aftercooler (option da) | ④ Heat exchanger (option db)     |
| ② Cyclone separator (option da)          | ⑤ Filter combination (option dd) |
| ③ Tool lubricator (option e)             | ⑥ Fresh air filter (option dc)   |

#### 4.9.1 Option da Compressed-air aftercooler

The aftercooler lowers the compressed air temperature to only 5 K to 10 K above ambient. Most of the moisture carried in the air is removed in the aftercooler.

#### 4.9.2 Option da Cyclone separator

Condensate accumulating during the air cooling process is separated, fed to the exhaust gas silencer and evaporated there.

#### 4.9.3 Option db Heat exchanger

The oil/air heat exchanger is fed with hot compressor cooling oil that warms the outgoing compressed air. This warm, dry compressed air is ideal for sand blasting, for example.

#### 4.9.4 Option dd Filter combination

The dried compressed air passes through a combination of pre-filter and micro-filter and emerges oil-free.

### 4.9.5 Option dc Fresh air filter

Compressed air from oil-injected compressors may not be used directly as breathing air.

Any contamination in the intake air is concentrated in the compressed air. Furthermore, during passage through the machine, the air may pick up traces of cooling oil and particles resulting from wear and this makes subsequent air treatment essential.

Dried compressed air must be filtered to remove all contaminants, such as fine dust and oil vapours as well as odours, before it can be used for breathing purposes.

To achieve this, part of the compressed air output from the compressor is passed through a combination of micro-filter and activated carbon filter.

The connection to air treated in this way is specially marked. It is designed as a quick-release coupling next to the outlet valves on the compressed air distributor.

**DANGER**

Danger of toxic contamination of the air!

Danger of respiratory arrest because the filter does not remove CO/CO<sub>2</sub>, methane or other toxic gasses or vapours.

- Never use the machine in enclosed spaces, only in the open.
- Clean inlet air without hazardous contaminants. Engine exhaust must not be drawn into the compressor.

The treated air does not meet the local Standard for 'Compressed air for breathing apparatus'. Therefore, it must not be used as pure breathing air but may be used to reinforce the flow of fresh air when working in dusty or dirty conditions such as sand blasting.

Further information See chapter 2.7.1 for ambient conditions under which the fresh air filter can be used.

## 4.10 Option ba Low temperature equipment option

Special equipment is provided for operation in extremely low temperatures.

This equipment guarantees trouble-free operation in ambient temperatures from -25 °C to +50 °C. The electrical system starts the engine without problem at ambient temperatures down to -20 °C.

### Option bb Coolant pre-heating

The engine coolant can be pre-heated to improve starting under cold conditions.

A separate mains power connection provides power to the coolant pre-heater. A flexible power cable joins the machine's power plug to the user's power socket.

The coolant pre-heater works according to the principle of self-circulation.

Option bb




Fig. 21 Coolant pre-heating

- |   |                       |
|---|-----------------------|
| ① Instrument panel                      | ③ Engine block        |
| ② Connection for the coolant pre-heater | ④ Coolant pre-heating |

The ideal coolant pre-heating period is 2-3 hours before the machine is started. A pre-heating period of more than 3 hours is not necessary, as the maximum effect has already been achieved within this period (thermal balance).

## 4.11 Option ob, od Start/stop/automatic option

### Option ob Automatic engine start/stop

The start/stop automatism can be set in the SIGMA CONTROL MOBIL controller for automatic machine start.

### Option od Trickle charging the starter batteries

For the starter batteries of the machine to be sufficiently charged for the starting the drive engine even after longer standstill times, a battery charger is used. This battery charger is connected to the user's electrical system.

## 4.12 Option va "External fuel pump" option

The machine may be connected to an external controller. The external fuel pump required is operated with the SIGMA CONTROL MOBIL controller.

## **4.13 Option sa, sc, sd, sh, si Transport options**

### **4.13.1 Option sa Chassis**

The chassis has the following features:

- Single-axle
- Rubber-sprung axle
- Height-adjustable towbar

### **4.13.2 Option sd Chassis**

The chassis has the following features:

- Single-axle
- Rubber-sprung axle
- Fixed height towbar

### **4.13.3 Option sh Chassis**

The chassis has the following features:

- Single-axle
- Rubber-sprung axle
- Fixed height towbar
- without parking brake

### **4.13.4 Option sc Stationary frame**

The frame has the following features:

- Skids
- Use as stationary machine
- Mounted on truck/trailer platform

### **4.13.5 Option si Stationary frame**

The frame has the following features:

- Frame
- Use as stationary machine
- Mounted on truck/trailer platform



#### 4.14 Option sg Pedestrian protection option

The machine is provided with pedestrian protection that functions both as a deflector and against pedestrians being run-over.

## 5 Installation and Operating Conditions

### 5.1 Safety

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting fuel or oil vapours or parts of the machine.
- The machine is not explosion-proof!  
Do not operate in areas in which specific requirements regarding explosion protection are in force. For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Ensure that required ambient conditions are maintained with regard to:
  - ambient temperature,
  - clean inlet air with no damaging contaminants,
  - inlet air free of explosive or chemically unstable gases or vapours,
  - inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Keep suitable fire extinguishing agents ready for use.

### 5.2 Installation conditions

Precondition The ground must be level, firm and capable of bearing the weight of the machine.




Fig. 22 Minimum distance from excavations/slopes and walls

1. Keep sufficient distance (at least 1.5 m) from the edges of excavations and slopes.
2. Ensure that the machine is as level as possible.



The machine can be temporarily operated on a slope of not more than 15°.

3. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.



#### CAUTION

Fire hazard from build-up of heat and hot exhaust system!

Insufficient distance from a wall may well cause heat build-up that could damage the machine.

- Do not position the machine directly against a wall.
- Ensure always sufficient ventilation space around the machine.

4. Position the machine as far as possible from any wall.

5. Ensure there is enough free space around and above the machine.
6. Keep air inlet and outlet openings free of obstructions so that the cooling air can flow freely through the machine.
7. Do not allow wind to blow into the cooling air outlet.
8. Do not allow exhaust gases and heated cooling air to be drawn into the compressor.
9. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.

**CAUTION**

Ambient temperature too low!

Frozen condensate and highly viscous engine or compressor oil can cause damage when starting the machine.

- Use winter grade engine oil.
- Use low viscosity compressor oil.

10. At ambient temperatures below 0 °C, follow instructions in chapter 7.9.

## 6 Installation

### 6.1 Safety

Follow the instructions below for safe installation.

Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Installation work may only be carried out by authorized personnel.

Further information

Information on authorized personnel are found in chapter 3.4.2.

Information on dangers and their avoidance are found in chapter 3.5.

### 6.2 Reporting Transport Damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage found.

### 6.3 Fitting the towbar

If the machine is shipped on a transport frame, it is necessary to dismantle the towbar to save space. The towbar must be re-assembled before removing the transport frame.

Material

Protective gloves

Wrench

Hard rubber hammer

Precondition

The machine is standing firm and level.

The machine is switched off.




#### CAUTION


Danger of pinching!

Severe pinching injury to fingers is possible.

- Always wear protective gloves.
- Work carefully.

**6.3.1 Option sa  
 Fitting the height adjustable towbar**

**Fig. 23** Height adjustable towbar, fitted


- |  |  |
|--|--|
| <ul style="list-style-type: none"> <li>① Overrun braking mechanism</li> <li>② Handle</li> <li>③ Tie bar</li> </ul> | <ul style="list-style-type: none"> <li>④ Locking lever with split pin</li> <li>⑤ Hand brake lever, parking brake</li> <li>⑥ Securing bolt with self-locking nut</li> </ul> |
|--|--|


**Fig. 24** Fitting the height adjustable towbar

1. Remove all transport securing items (duct tape, foam pads) from the towbar components.
2. Undo the self-locking nut and remove the tie bar fixing bolt.
3. Bring the overrun braking mechanism into the horizontal position.
4. Push the tie bar end between the cheeks of the overrun braking mechanism and align the fixing holes.
5. Push in the securing bolt, using light hammer blows if necessary.
6. Secure the bolt with the self-locking nut (see chapter 2.4.4 for tightening torque).
7. Release the parking brake by pushing the hand brake down.
8. Pull out the split pin and unscrew the locking lever to the stop.
9. Use the positioning handle to push the towbar to the required height.
10. Tighten the locking lever. Make sure the teeth in the adjustment joint mesh together.
11. Fully tighten the lever with a few hammer blows and insert the split pin.
12. Reapply the parking brake. (Pull the hand brake lever up.)

**6.3.2 Option sd, sh  
Fitting a non-adjustable towbar**

Option sd, sh



06-M0948


Fig. 25 Non-adjustable towbar fitted

- |   |                           |    |                          |
|---|---------------------------|----|--------------------------|
| ① | Overrun braking mechanism | ⑤  | Parking brake            |
| ② | Towbar                    | ⑥  | Breakaway cable          |
| ③ | Brake rod                 | ⑥* | not for USA type chassis |
| ④ | Jockey wheel              |    |                          |

1. Open the left-hand door.
2. Remove the bag with fastenings (to be found at the lifting eye strut), and unpack and prepare the fastenings.
3. Close the door.
4. Remove all transport securing items (screw fastenings, duct tape, foam pads) from the towbar components.

**Fitting the overrun braking mechanism of the non-adjustable towbar:**

Option sd, sh



06-M0946

**Fig. 26** Fitting the overrun braking mechanism of the non-adjustable towbar


- |   |                            |   |                                   |
|---|----------------------------|---|-----------------------------------|
| ① | Overrun braking mechanism  | ⑥ | Brake transmission lever          |
| ② | Towbar                     | ⑦ | Brake rod                         |
| ③ | Fixing bolt                | ⑧ | Braking cable bracket (equaliser) |
| ④ | U-washer                   | ⑨ | Connecting sleeve                 |
| ⑤ | Hexagon nut (self-locking) | ⑩ | Hexagon nut (locknut)             |

1. Push the overrun braking mechanism onto the towbar and position so that the securing bolts can be pushed on.
2. Push in the securing bolts (using light hammer blows if necessary) and push on U-washers.
3. Secure the bolts with the self-locking nuts (see chapter 2.4.4 for tightening torque).
4. Insert brake actuating rod into the brake cable bracket and screw the connecting sleeve free of play and tension.
5. Lock the sleeve with the hexagonal nut.

**Further information** Further information on setting the brake actuating rod is to be found in chapter 10.8.3.3.

**Fitting the jockey wheel of the non-adjustable towbar:**

Option sd, sh



06-M0947

Fig. 27 Fitting the jockey wheel of the non-adjustable towbar

- |   |                           |   |                            |
|---|---------------------------|---|----------------------------|
| ① | Overrun braking mechanism | ④ | U-washer                   |
| ② | Jockey wheel              | ⑤ | Hexagon nut (self-locking) |
| ③ | Fixing screw              |   |                            |

1. Place a U-washer on each securing screw and insert each of these into the top four securing holes on the jockey wheel mounting plate.
2. Raise the overrun braking mechanism and position such that the securing holes of the jockey wheel mounting plate and the overrun braking mechanism coincide.
3. Push through the securing screws and push on the U-washers.
4. Secure the bolts with self-locking nuts.

## 6.4 Adjusting the chassis

Material Pliers  
Hard rubber hammer

Precondition The machine is shut down.  
The machine is disconnected from the towing vehicle and safely parked.




**6.4.1 Option sa  
 Adjusting the towbar height**


Fig. 28 Towbar height adjustment

- |                 |                               |
|-----------------|-------------------------------|
| ① Locking lever | ③ Split pin properly inserted |
| ② Split pin     | ④ Handle                      |

1. Pull out the split pin and unscrew the locking lever to the stop.


**CAUTION**

Danger of pinching!

Severe injury to fingers is possible if they become trapped in the adjusting mechanism.

- Always wear protective gloves.
- Work carefully.

2. Adjust the towbar with the handle until it is horizontal with the coupling on the towing vehicle and parallel to the ground.

The centre-piece can be moved up to 50° upwards and 10° downwards for height adjustment.

The parallel tie bar ensures that the overrun braking mechanism stays horizontal (Fig. 28).

3. Tighten the locking lever again and secure by striking with a hard rubber hammer.
4. Insert the cotter pin.
5. Check if:
  - The teeth in the adjustment joint are fully engaged.
  - The locking lever is tight.
  - The split pin is correctly inserted to secure the locking lever (see 3 in Fig. 28).
6. Tighten the locking lever again after 50 km.



The serrated joint will not disengage. The serrated washers are corroded.

- Free the serrated washers by jerking the towbar horizontally and vertically.

**6.4.2 Changing the towing eye**

The towbar can be fitted with various towing eyes or couplings.

Material Protective gloves  
Wrench  
Thin metal rod

Precondition The machine is shut down.  
The machine is disconnected from the towing vehicle and safely parked.



**CAUTION**

Danger of pinching!  
Severe injury to fingers is possible if they become trapped in the adjusting mechanism.

- Always wear protective gloves.
- Work carefully.

- Ascertain which towbar is fitted to the machine.

**6.4.2.1 Option sa Changing the towing eye on a height-adjustable towbar**

The following alternative tasks must be carried out to change the towing eye or coupling.




Fig. 29 Changing the towing eye (height-adjustable towbar)

- |                            |                     |
|----------------------------|---------------------|
| ① Self-locking hexagon nut | ④ Protective sleeve |
| ② Hex-head bolt            | ⑤ Ball coupling     |
| ③ Towbar tube              | ⑥ Towing eye        |

Remove the ball coupling	Remove the towing eye.
1. Unscrew the nuts ① and withdraw the fixing bolts ②.	1. Push back the protective sleeve ④.
2. Remove the coupling ⑤ from the towbar tube ③.	2. Unscrew the nuts ① and withdraw the fixing bolts ②.
	3. Remove the towing eye ⑥ from the towbar tube ③.

Fitting the ball coupling	Fitting the towing eye
1. Slide the coupling (5) onto the towbar tube.	1. Slide the towing eye (6) into or onto the towbar tube (3).
2. Position the various parts so that the bolts can be freely inserted.	2. Position the various parts so that the bolts can be freely inserted.
3. Insert the bolts (2) and secure with the self-locking nuts (1).	3. Insert the bolts (2) and secure with the self-locking nuts (1).
	4. Draw the protective sleeve (4) over the fixings.

**6.4.2.2 Option sd, sh**  
**Changing the towing eye on a fixed height towbar**




Fig. 30 Changing the towing eye (fixed height towbar, GB chassis version)

- |                            |                     |
|----------------------------|---------------------|
| ① Self-locking hexagon nut | ⑤ Towbar tube       |
| ② Hex-head bolt            | ⑥ Protective sleeve |
| ③ Damper fixing eye        | ⑦ Ball coupling     |
| ④ Damper                   | ⑧ Towing eye        |




Fig. 31 Changing the towing eye (fixed height towbar, USA chassis version)

- |                            |                     |
|----------------------------|---------------------|
| ① Self-locking hexagon nut | ⑤ Towbar tube       |
| ② Hex-head bolt            | ⑥ Protective sleeve |
| ③ Damper fixing eye        | ⑦ Ball coupling     |
| ④ Damper                   | ⑧ Towing eye        |

1. Push back the protective sleeve ⑥.
2. Unscrew the nuts ① and withdraw the fixing bolts ②.
3. Remove the ball coupling ⑦ or towing eye ⑧ from the towbar tube ⑤.
4. Slide the new coupling ⑦ or towing eye ⑧ into or onto the towbar tube ⑤.
5. Position the various parts so that the bolts can be freely inserted.
6. Push the bolts ② through the front of the two holes in the eye ⑧ or coupling ⑦ and fix with the self-locking nuts ①.



In order to insert the rear bolt, the delayed release of the compressed damper is used. During the delayed return stroke, a suitable metal rod is pushed through the holes as they line up to hold them in place.

7. Push heavily against the towing eye ⑧ or coupling ⑦ to depress the overrun brake.
8. Pull the coupling and the towbar tube forward quickly and insert a suitable thin metal rod through the rear fixing hole ③ and the damper's fixing eye ④.
9. Insert the bolt ② through the hole in the coupling/eye and the blocked fixing eye ③ of the damper ④. At the same time, pull out the metal rod again. Secure the bolt ② with the self-locking nut ①.
10. Tighten the nuts.
11. Draw the protective sleeve ⑥ over the fixings.

**Checking the overrun braking mechanism**

- Push the towbar tube in and out by hand.  
If resistance is felt, the damper is properly connected.

## 7 Initial Start-up

### 7.1 Safety

Here you will find instructions for safe commissioning of the machine. Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Commissioning work may only be carried out by authorized operating and maintenance personnel.

Further information Information on authorized personnel are found in chapter 3.4.2. Information on dangers and their avoidance are found in chapter 3.5.

### 7.2 Instructions to be observed before commissioning or recommissioning



The initial start-up of every machine takes place at the factory. Every machine is also given a trial run and passes a careful check.

Incorrect or improper commissioning can cause injury to persons and damage to the machine.

- Commissioning may only be carried out by authorized installation and service personnel who have been trained on this machine.
- Remove all packing materials and tools on and in the machine.
- Observe the machine during the first few hours of operation to ensure that it is operating correctly.

### 7.3 Checking installation and operating conditions

- Check and confirm all the items in the checklist before starting the machine.

Function	See chapter	Confirmed?
➤ Are the operators fully conversant with safety regulations?	–	
➤ Have all the positioning conditions been fulfilled?	5	
➤ Is there sufficient cooling oil in the separator tank?	10.5.1	
➤ Is there sufficient oil in the engine?	10.4.4	
➤ Is the maintenance indicator on the air intake filters (engine and compressor) OK?	10.4.2, 10.5.7	
➤ Is there sufficient coolant in the coolant expansion tank?	10.4.1	
➤ Is there sufficient fuel in the fuel tank?	–	
➤ Fuel prefilter water trap emptied?	10.4.3	
➤ Are the access doors closed and all body panels in place?	–	
➤ Are the tyre pressures OK?	–	

Tab. 58 Installation and operating conditions checklist

## 7.4 Setting the displayed units

The following units can be changed:

- Unit of temperature
- Unit of pressure



The unit must only be set once and all displays are adjusted accordingly. The settings remain when the controller is switched off.

**Precondition** Controller switched on  
Select <Main menu => settings => unit settings>.

### Setting the unit of temperature

The temperature unit is selected in the temperature unit menu option **E1**.




Fig. 32 Temperature display setting

- |  |  |
|--|--|
| <b>E1</b> Unit of temperature setting menu | <b>3</b> Navigation                            |
| <b>T1</b> Display unit °C (selected)       | <b>A</b> Display field size (white background) |
| <b>T2</b> Display unit °F                  | <b>B</b> Selection choice (grey background)    |
| <b>T3</b> Display unit K                   |  |

1. Use the «UP» and/or «DOWN» arrow keys to select the required unit.
2. Press «Enter» .
- The setting is saved.
3. Press «esc» .

**Result** The display changes to show the operating mode.

### Setting the unit of pressure

The unit of pressure is selected in the pressure unit menu option **E2**.




Fig. 33 Unit of pressure setting

- |    |                               |   |                                       |
|----|-------------------------------|---|---------------------------------------|
| E2 | Unit of pressure setting menu | 3 | Navigation                            |
| D1 | Display unit bar (selected)   | A | Display field size (white background) |
| D2 | Display unit psi              | B | Selection choice (grey background)    |

1. Use the «UP» and/or «DOWN» arrow keys to select the required unit.
2. Press «Enter» .
3. Press «esc» .

Result The display changes to show the operating mode.

## 7.5 Entering a password

No password is set when the machine is delivered.

- — Password level 0

The following password is required to make entries and changes in the settings menu:

- 1 — Password level 1 (reenter password): **4512**

The following displays will require you to enter the password:




Fig. 34 Waiting for password entry

The cursor flashes at the position for the first letter of the password.

1. Keep on pressing the «DOWN» or «UP» key until the required character appears.
  2. Use «RIGHT» to move the cursor to the position of the second letter.  
The cursor flashes in the position for the next letter of the password.
  3. Set the remaining characters of the password until it is complete.
  4. Confirm the password with «Enter» .
- The activated password is displayed. (see example in figure 35).



Password is not activated - incorrect password.

- Re-enter the password.



The cursor can be moved «LEFT» ⏪ or «RECHTS» ⏩ to overwrite and incorrect entries.




Fig. 35 Password level 1 activated.

1. Correct the password.
2. Confirm the correct password with «Enter» ⏏.

The activated password is displayed.



The password level is reset 3 minutes after the last key has been depressed. Temporary settings are not saved and are lost!

Passwords for other levels are entered in the same way.

## 7.6 Engine settings

This menu option is not available to users. Changes in this menu option can only be made with the correct password.

The following parameters can be changed:

- Starter running time (reenter, password level 1).
- Engine cool-down period in unloaded run-on (reenter, password level 1).

The following parameters can only be set by Service Technicians.

- Engine LOAD speed (password level 3).
- Engine IDLE speed (password level 3).



LOAD and IDLE speeds can be temporarily changed for service purposes or necessary tests. These changes are not saved and are lost when the controller is switched off.

Precondition Controller switched on  
<main menu => settings => engine settings> selected.






Fig. 36 Engine settings menu

- |  |  |
|--|--|
| <b>E4</b> Engine settings menu         | <b>U4</b> IDLE speed setting                   |
| <b>U1</b> Starter running time setting | <b>3</b> Navigation (menu)                     |
| <b>U2</b> Cool-down period setting     | <b>A</b> Display field size (white background) |
| <b>U3</b> IDLE speed setting           | <b>B</b> Selection choice (grey background)    |

**Starter running time setting**

The starter running time can be set between 15 and 45 seconds.

1. Use the «UP» and/or «DOWN» arrow keys to select starter running time setting **U1**.
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .

Result The display changes to show the operating mode.

**Cool-down period setting**

When the «Stop» key is pressed, the machine switches to unloaded run-on and stops when the set period has expired.

The COOL-DOWN PERIOD can be set between 30 and 300 seconds.

1. Use the «UP» and/or «DOWN» arrow keys to select cool-down period setting **U2**.
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .



Result The display changes to show the operating mode.

**Setting the engine LOAD speed.**

1. Use the «UP» and/or «DOWN» keys to select LOAD speed setting **U3**.
2. Press «RIGHT» and/or «LEFT» keys to select the required speed.

## 7 Initial Start-up







### 7.7 Changing the parameters of the start/stop/automatic option

3. Press «Enter»   
The setting is saved.
4. Press «esc»   
The display changes to show the operating mode.



This setting is only temporary and is lost when the controller is switched off.

#### Setting the engine IDLE speed.

1. Use the «UP»  and/or «DOWN»  keys to select IDLE speed setting **U4**.
2. Press «RIGHT»  and/or «LEFT»  keys to select the required speed.
3. Press «Enter»   
The setting is saved.
4. Press «esc»   
The display changes to show the operating mode.



This setting is only temporary and is lost when the controller is switched off.

## 7.7 Option ob

### Changing the parameters of the start/stop/automatic option

The following parameters can be changed:

- Run-on period under LOAD.
- Run-on period in IDLE.
- Manual or automatic operation (Service password level 3).



The length of the warm-up period, between starting and switching to LOAD, cannot be changed.  
The controller switches the machine to LOAD as soon as the airend discharge temperature reaches 40 °C.

Precondition Controller switched on  
<Main menu => settings => options => start-stop-automatic > selected.




Fig. 37 Settings in start/stop/automatic

- |   |  |
|---|--|
| <b>[E7]</b> Settings menu start/stop/automatic                        | <b>[3]</b> Navigation and settings               |
| <b>[S1]</b> Run-on under load   | <b>[A]</b> Display field size (white background) |
| <b>[S2]</b> Unloaded run-on   | <b>[B]</b> Selection choice (grey background)    |
| <b>[S3]</b> Manual or automatic operation (Service password level 3). |  |

#### Setting run-on under load

1. Use the «UP» and/or «DOWN» arrow keys to select run-on under load **[S1]**.
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .
- The display changes to show the operating mode.

#### Unloaded run-on setting

1. Use the «UP» and/or «DOWN» arrow keys to select unloaded run-on **[S2]**.
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .
- The display changes to show the operating mode.

## 7.8 After storing the machine for a long period

- Carry out the following before every re-commissioning after a long period of storage.

Storage period longer than	Remedy
5 months	<ul style="list-style-type: none"> <li>➤ Remove the desiccant from the openings in the air intake filters of the engine and compressor.</li> <li>➤ Check the air and oil filters.</li> <li>➤ Drain the preserving oil from the separator tank.</li> <li>➤ Fill with cooling oil.</li> <li>➤ Drain the preserving oil from the engine.</li> <li>➤ Fill with engine oil.</li> <li>➤ Check the engine coolant</li> <li>➤ Check the battery charge.</li> <li>➤ Re-connect the battery (batteries).</li> <li>➤ Check all fuel lines, engine oil lines and compressor cooling oil lines for leaks, loose connections, wear and damage.</li> <li>➤ Clean the bodywork with a grease and dirt cleansing agent.</li> <li>➤ Check the tyre pressures.</li> </ul>
36 months	<ul style="list-style-type: none"> <li>➤ Have the overall technical condition checked by an authorized KAESER Service Technician.</li> </ul>

Tab. 59 Measures for re-commissioning the compressor after a long period of storage

## 7.9 Low-temperature operation (winter)

The machine's electrical equipment is designed for starting at ambient temperatures as low as  $-10\text{ }^{\circ}\text{C}$ .

- At temperatures below  $0\text{ }^{\circ}\text{C}$  use:
  - winter-grade engine oil,
  - low viscosity cooling oil for the compressor,
  - winter-grade diesel fuel



Use air hoses that are as short as possible under extremely cold conditions.

### 7.9.1 Starting assistance

If the machine's starter batteries are discharged, it can be started with the batteries of another vehicle or engine-driven machine.

**Material** Jumper cables

**Precondition** The machine is disconnected from the towing vehicle and safely parked.  
The «battery isolating switch» is off.



**DANGER**

Fire and explosion hazard.

High currents caused by short-circuited battery. Shorted batteries can catch fire or explode. Battery casing may crack and allow acidic fluid to spray out.

- Observe the instructions provided with the battery jumper cables.
- Do not connect the battery jumper cables to the negative pole of the discharged battery or to the bodywork of the machine.
- Work carefully.




Fig. 38 Jumper cable connection diagram

- |  |  |
|--|--|
| Ⓐ Engine batteries (receiving batteries)                           | ⓓ Positive pole clamp (red) on engine battery        |
| Ⓑ Assisting vehicle batteries (external donor batteries)           | ⓔ Negative pole clamp (black/blue) on engine battery |
| ⓑ Negative pole clamp (black/blue) on battery of assisting vehicle | ⓕ Bare metal point on the engine block (earth)       |
| Ⓒ Positive pole clamp (red) on battery of assisting vehicle        |  |

➤ Follow the safety rules when dealing with batteries:

- Connect batteries of the same voltage only.
- The assisting vehicle and the machine to be started must not touch.
- Switch off all consumers prior to connecting and disconnecting the batteries.
- Only use battery jumper cables of sufficient diameter and with insulated terminal clamps.
- Observe the instructions provided with the battery jumper cables.
- Keep jumper cables away from rotating parts.
- Avoid short-circuits due to incorrect poling and/or bridging with tools.
- Do not bend over the batteries when attaching jumper cables.
- Do not attempt to start the machine if its batteries are frozen. Allow the batteries to thaw first.
- Do not try to start the machine with a boost charger.

**Preparations:**

1. Park the assisting vehicle in close distance to the engine, without their bodywork touching each other.
2. Stop the engine of the assisting vehicle.

3. Open the access to the batteries (remove maintenance panels/bonnet and pole caps).
4. Switch off all power consumers.

**Connecting the battery jumper cables**

1. Clamp the first terminal clamp ③ of the red jumper cable to the positive pole of the engine's battery.
2. Clamp the second terminal clamp ② of the red jumper cable to the positive pole of the assisting vehicle's battery.

**DANGER**

Explosion hazard!

A spark may ignite an explosive gas mixture.

- Do not, under any circumstances, connect the minus terminal of the assisting vehicle to the negative terminal of the battery in the machine to be started. This can cause sparks when connecting and disconnecting.
- Work carefully.

3. Connect the first pole clamp ④ of the black jumper cable to the engine block or a connected, solid and unpainted metal component of the engine ⑤ (as distant as possible to the batteries).
4. Clamp the second terminal clamp ① of the black jumper cable to the negative pole of the assisting vehicle's battery.

**Starting the engine**

1. Switch on the «battery isolating switch».
2. Start the engine of the assisting vehicle and run at high speed.
3. Start the compressor engine.



Upon a successful start, run both engines for approximately 10 – 15 minutes.

This is important, in particular for fully discharged batteries. They will pick up little current only in the beginning and have a high internal resistance. Any voltage peaks occurring in the engine generator in this state can be attenuated only by the batteries of the assisting vehicle. The engine electronics in particular, of the machine is sensitive to overvoltages and could be damaged easily.

**Disconnecting the battery jumper cables**

1. Stop the engine of the assisting vehicle.
2. Disconnect the jumper cables in the reverse order, first negative (-) then positive (+).
3. Place the pole caps.
4. Close the maintenance panels and/or bonnet.



A stop of the compressor engine as soon as the cables are disconnected could indicate major damage to the alternator or batteries to be repaired by a specialised workshop.

**7.9.2 Option ba  
Starting up low-temperature equipment****Option bb Coolant pre-heating**

The engine coolant can be pre-heated to improve cold-starting.

The connection for the mains supply is located on the machine's instrument panel.




Fig. 39 Coolant pre-heating

- |   |                       |
|---|-----------------------|
| ① Operating panel                       | ④ Coolant pre-heating |
| ② Connection for the coolant pre-heater | ⑤ Engine block        |
| ③ Power cable                           |                       |



**DANGER**

Danger of fatal injury from electric shock!

Serious injury or death can result from a short-circuit in the electric coolant pre-heater.

- The power cable for the coolant pre-heater may only be plugged into an electrical socket fitted with a protective earth.
- Have the coolant pre-heating and associated wiring checked according to the maintenance schedule.

- Connect the coolant pre-heater to the user's power socket with the power cable supplied.

## 7.10 Option od Activating the battery trickle charging

The supply voltage must be permanently connected as long as the compressor is to be operated in standby mode. Trickle charging the batteries ensures they are always in a condition to start the portable compressor.




Fig. 40 Battery charger

- ① Voltmeter
- ② Ammeter
- ③ Motor overload protection switch
- ④ Safety cut-out

**Activating the battery charger:**

1. Switch on the overload protection switch.
  2. Switch on the safety cut-out.
- The meters indicate the charging voltage and current.

**Checking battery charger function**

The charger function should be checked weekly.

Instruments	Voltmeter	Ammeter
Display	Charging voltage [V DC]	Charging current [A DC]
Value	≥26.6	>0.5

Tab. 60 Battery charger control



**CAUTION**

Cutting the supply voltage of the battery charger. Starter batteries discharge through a connected battery charger. This can result in a total discharge and destruction of the batteries.

- If the supply voltage is switched off: also switch off the motor protection switch and cut-off.
- Check the readings on the voltmeter and ammeter.  
If deviations are found: contact an authorised electrician.



## 8 Operation

### 8.1 Safety

Here are to be found instructions to ensure safe operation of the machine.

Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions



#### WARNING

There is danger of injury from hot, rotating and electrically live components! Serious injury can be caused by touching such components.

- Operate the machine only with closed doors/canopy.
- Shut down the machine before opening any doors/canopy.
- Do not carry out any checks or settings while the machine is running.

Follow the instructions in chapter 'Safety and Responsibility'.

Details of authorized personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

### 8.2 Starting and stopping

Precondition No personnel are working on the machine.





Fig. 41 Starting instruments

- |   |                            |
|---|----------------------------|
| ① Instrument panel cover with sticker giving brief instructions | ⑥ «Quick-stop push-button» |
| ② Compressed air outlet pressure gauge                          | ⑦ «Stop» key               |
| ③ Controller SIGMA CONTROL MOBIL                                | ⑧ «Start» key              |
| ④ «Controller On» switch  | ⑨ «Load» key               |
| ⑤ Fuel gauge  | ⑩ Display                  |

#### 8.2.1 Follow the brief instructions

Brief instructions containing symbolic information on starting and stopping is stuck to the inside of the instrument panel cover.



08-M0581

Fig. 42 Brief instructions on starting and stopping


- ① Starting sequence
- ② Shutdown sequence

➤ Open the instrument panel cover and follow the instructions stuck to the inside.



Each step explained in full.

**8.2.2 Running the machine**



08-M0046

Fig. 43 «Battery isolating switch»

- ① «Battery isolating switch»  
I – on  
0 – off

1. Open the left-hand door.
2. Activate the «battery isolating switch».  
The battery is now connected to the machine's electrical system.
3. Close the door.  
The machine can now be started.

**Notes concerning snow and ice**

Considerable snow or ice may build up on the machine under low temperature conditions.

➤ Remove any snow and ice from the machine before operating.

As a safety measure, check the function of the «quick stop »push-button.


**WARNING**

«Quick-stop» button jammed!

The machine cannot be stopped quickly in an emergency.

- Check the function of the «quick stop »push-button.
- Do not operate the machine if the «quick stop button» does not work.

1. Press the «Quick-stop» button.

Defrost the «quick stop »button if it cannot be pushed in or does not latch. Defrost the «Quick-stop» button.

2. Unlatch the «quick stop» button.



The «quick stop »button still does not function after defrosting.

- Have the «Quick stop» button replaced.

**8.2.3 Starting the engine**

**CAUTION**


Serious damage to the engine from cold starting sprays!


Cold-start assists, such as ether or other sprays, can cause severe engine damage.

- Do not use cold start sprays.

1. Open the control panel cover.

2. Switch on the «Controller».

- The controller boots up and the front page is displayed.
- If the temperature is below zero, the engine control unit will switch on engine pre-heating.
- If no existing message are displayed (see chapter 4.7, table 42) the display changes to operating data and shows ready to start.
- The «Start» key  flashes.


3. Press the «Start» key .

- The engine starts and runs in IDLE until the following conditions are fulfilled:


- The airend discharge temperature (ADT) reaches 30 °C.
- The engine coolant temperature (ECT) reaches 30 °C.

- When the ADT or ECT reaches 30 °C, the machine can be switched to LOAD.


- The «Start» key  illuminates and the «Load» key  flashes.

4. Press the «Load» key .

- The machine switches to LOAD and is ready to deliver compressed air.

- The «Load» key  illuminates.



- If the «Load» key  is pressed before the ADT or ECT reaches 30 °C the engine continues to run at IDLE speed. The controller switches automatically to LOAD when these temperature limits are reached.

- If the starting sequence fails or is interrupted by pressing the «Quick stop» key, the re-start inhibit is activated for 20 seconds. The display shows the remaining time before another start can be attempted.

Further information See chapter 4.7.2 for the operating sequence of the SIGMA CONTROL MOBIL.

### 8.2.4 Setting the output pressure

The output pressure is set from the instrument panel.  
Setting is in increments of 0.1 bar and shown as a scale on the display.



The output setting menu option can be reached in two ways:

- Quick entry
- Entry via the menu structure

#### Quick entry

Precondition LOAD

<Main menu> (operating mode display) selected

- Press either «LEFT»  or «RIGHT» .
- This immediately selects the output setting menu.

#### Entry via menu structure

Precondition LOAD

<Main menu => engine operating data – compressor> selected.

Enter the output pressure in the sub-menu "set pressure in oil separator tank"





Fig. 44 Select menu option "set pressure in the oil separator tank"

- 1a) Main menu
- 2b) Compressor unit data
- 3) Navigation (menu)

1. Select the compressor data symbol and confirm with «Enter» .
2. Select menu option "set pressure in the oil separator tank"  
This immediately selects the output setting menu.

#### Setting pressure



The pressure can only be set at lower than the nominal working pressure of the machine.  
A pressure setting 1.5 bar higher than nominal is possible with the appropriate password. This can only be temporary and falls back to nominal if no key is pressed for 3 minutes or if the controller is switched off.




Fig. 45 Setting the output pressure

- |   |   |   |  |
|---|---|---|--|
| ④ | Select menu option "set pressure in the oil separator tank" | ⑦ | Maximum working pressure (upper setting limit) |
| ⑤ | Minimum working pressure (lower setting limit)              | ⑧ | Current setting                                |
| ⑥ | Setting scale with indicator bar                            |   |  |

- Use «RIGHT» and/or «LEFT» to select the output pressure and check on the instrument panel pressure gauge.



The set pressure is saved when leaving the setting menu option.

- Press «esc» .
- The display changes to show the operating mode.

### 8.2.5 Shutting down the machine



#### CAUTION

Thermal overload of the turbo charger.

Abrupt stopping of the engine under load can cause a fault or damage to the turbo charger.

- Run the engine a few minutes in idle before shutting down to allow the turbo charger to cool.

#### Operating the machine in the cool-down phase

- Press and hold the «Stop» key for longer than one second.
  - The machine switches to unloaded run-on, i.e. the engine runs at IDLE speed and the oil separator tank is vented.
  - When the cool-down period has elapsed (engine setting "unloaded run-on") the machine has cooled enough so that the engine can stop automatically.



- The controller display shows *back pressure* if the pressure in the oil separator tank is still > 1 bar.
- When the machine is fully vented, the display changes to *ready to start*.
- When the OST is fully vented after shutdown, the re-start inhibitor is activated and is indicated by the timer counting down from 20 seconds.

#### Shutting down the machine



If the machine is not to be used again, the «battery isolating switch» should be switched off.



**CAUTION**

Danger of short circuit  
Damage to the machine electrics is possible.

- Use the «battery isolating switch» only when the machine is at standstill.
- Do not use the «battery isolating switch» as a main or emergency switch.

1. Switch off the «Controller».
2. Open the left-hand door.
3. Switch off the battery «battery isolating switch» when the instrument panel display is no longer illuminated.

The battery is disconnected from the machine's electrical system.

4. Close the «compressed air outlet valves» on the air distributor.
5. Close the operating panel cover and all doors. Lock if necessary.




### 8.2.6 Shutting down in an emergency

In case of danger, immediately stop the machine by pressing the «Quick stop» button.



Use the «Quick stop» button to stop the machine only in emergencies.


**Quick shutdown:**




- Press the «Quick-stop» button.
  - The engine stops immediately.
  - The «Quick stop button »remains latched after being pressed.
  - The re-start inhibitor is activated (20 seconds).
  - The «Information key »  and the «Stop key»  are illuminated.
  - The «Acknowledge» key  flashes.

**Reactivating the machine:**

When the fault has been cleared, the machine must be reset.

Precondition The fault has been rectified.

- Unlatch the «Quick-stop button».
- Confirm the message with the «Acknowledge key» .
 






The «Information» , «Stop» , and «Acknowledge»  keys extinguish.

The machine can now be started again.


## 8.3 Setting parameters

Parameter setting and changing takes place in the controller settings menu.

- Select *<Main menu => setting>*.
- See chapter 4.8.2 for using the settings menu.
- Some menu options are password protected.

1. Use the «UP»  and/or «DOWN»  keys to navigate to the menu option containing the parameter to be set.
2. Use the «RIGHT»  and/or «LEFT»  key to set the required parameter value.
3. Confirm and save the setting with «Enter» .



Every action can be cancelled with the «escape»  key.

## 8.4 Acknowledging alarm, warning and maintenance messages




Information from the controller is interpreted as displayed messages.  
 The message is stored in the event memory at the same time.







See chapter 4.8.3 for further information on the event memory.

### 8.4.1 Acknowledge alarm message.

An alarm message is displayed and:



- the machine is shut down and cannot be restarted.
- The «Information key»  and the «Stop key»  are illuminated.
- The «Acknowledge» key  flashes.

Precondition Alarm rectified

- Confirm the message with the «Acknowledge key» .
- The «Information» , «Stop» , and «Acknowledge»  keys extinguish.




### 8.4.2 Acknowledging warning and maintenance messages

A fault warning message or notification of maintenance due is displayed, and:


- The «Information key»  lights up,
- The «Acknowledge» key  flashes.

Precondition The cause of the warning is rectified

Maintenance is carried out

- Confirm the message with the «Acknowledge key» .
- The «Acknowledge key»  is extinguished but the «Information key»  is still illuminated.



The «Information key»  continues to be illuminated when the machine is restarted until the fault is rectified or maintenance has been carried out.  
 Upon maintenance, the maintenance interval counter must be reset.

## 8.5 Resetting maintenance interval counters

Each maintenance interval counter must be separately reset. Only the counter currently displayed can be reset.



Only personnel with passwords of at least level 1 (rener level) can reset the maintenance interval counter.  
See chapter 7.5 for information on entering passwords.

**Precondition** Maintenance is carried out  
Service message is acknowledged.  
Password level is activated.

- Simultaneously press and hold «Acknowledge» and «Enter» for two seconds.  
The displayed maintenance interval counter will be reset.

## 8.6 Displaying machine operating data

**Precondition** Controller switched on  
<Main menu => engine operating data – compressor> selected.




Fig. 46 Operating data menu

- |                          |  |
|--------------------------|--|
| 1a) Main menu            | 4) Further menu options                  |
| 2a) Motor data           | A) Display field size (white background) |
| 2b) Compressor unit data | B) Selection choice (grey background)    |
| 3) Navigation (menu)     |  |

### Display engine data

Engine data is shown in four display menus. With the aid of the arrow keys, one can page through the display.

1. Select the engine data symbol and confirm with «Enter» .
2. Call up the required display menu by pressing and/or .

**Further information** See chapter 4.8.1 for information on engine data display menus.

### Display compressor data


Engine data is shown in two different display menus. With the aid of the arrow keys, one can page through the display.

1. Select the compressor data symbol and confirm with «Enter» .
2. Call up the required display menu by pressing and/or .

**Further information** See chapter 4.8.1 for information on compressor data display menus.



**Menu exit**

- Press «esc» .  
The display changes to show the operating mode.

## 8.7 Option va Using the external fuel pump option

Precondition Controller switched on  
*<main menu => settings => options => external fuel pump>*









Fig. 47 External fuel pump switch-on symbol

-  External fuel pump setting menu
-  External fuel pump on/off  
Confirm with «Enter» 


**Switching the external fuel pump on**

- Press «Enter» .  
The pump switches on and fills the machine's fuel tank.

**Switching the external fuel pump off**

- Press «Enter» .  
The external fuel pump switches off.

**Menu exit**

- Press «esc» .

Result The display changes to show the operating mode.

## 8.8 Option ba Using the low-temperature equipment

- Heed the safety instructions in chapter 3.5.

**Option bb Coolant pre-heating**

- Start the coolant pre-heating as described in chapter 7.9.2.

## 9 Fault Recognition and Rectification

### 9.1 Basic instructions

1. Do not attempt fault rectification measures other than those given in this manual.
2. Inform KAESER Service if the fault cannot be removed by the action suggested.

Further information Observe the instructions in chapter "Safety" and prevailing local safety regulations when rectifying faults and malfunctions.

### 9.2 SIGMA CONTROL MOBIL messages

There are three types of message:

- Alarm messages, see chapter 9.2.1
- Warning messages, see chapter 9.2.2
- Maintenance messages, see chapter 10.2

The messages valid for your machine are dependent on the controller factory settings and individual equipment with which the machine is provided.

#### 9.2.1 Alarm messages on the controller (machine off)

Fault with automatic deactivation of the machine.

The «Acknowledge»  key flashes. The «Information key»  and the «Stop key»  are illuminated.



You must acknowledge the service message upon correction of the fault before you can re-start the machine.

Further information Further information on the acknowledgement of service messages can be found in chapter 8.4.

#### Message code, range 1100 – 1199 "engine faults":

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1100	Oil pressure fault.	Check the engine oil level.	10.4.4	–	–
		Have the engine oil pressure checked.	–	X	–
		Have the oil pressure switch checked.	–	X	X
1101	Oil pressure sensor defective.	Have the sensor changed.	–	X	X
1110	Coolant temperature high.	Check the coolant level.	10.4.1	–	–
		Clean the radiator.	10.6	–	–
		Check the cooling system.	–	X	X
1111	Coolant level too low.	Check the coolant level.	10.4.1	–	–

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1112	Coolant temperature sensor defective.	Have the sensor changed.	–	X	X
1120	Turbo air pressure too high/low.	Have the turbo air pressure sensor checked.	–	X	X
1121	Turbo air temperature too high.	Check operating conditions. Allow the machine to cool down.	5.2	–	–
		Clean the radiator.	10.6	–	–
1122	Turbo air temperature sensor defective.	Have the sensor changed.	–	X	X
1123	Turbo air temperature sensor defective.	Have the sensor changed.	–	X	X
1130	Fuel level low.	Refuel.	–	–	–
1131	Fuel temperature high.	Allow the machine to cool down.	–	–	–
1132	Fuel pressure low.	Have checked.	–	X	X
		Clean / replace the fuel filter.	10.4.3	–	–
1133	Fuel temperature sensor defective.	Have the sensor changed.	–	X	X
1134	Fuel pressure sensor defective.	Have the sensor changed.	–	X	X
1135	Fuel pump fault..	Have checked.	–	X	X
1140	Defective alternator.	Have checked.	–	X	X
1141	Battery voltage too high/low.	Battery maintenance.	10.4.9	–	–
		Check battery charging system.	–	X	X
1150	Engine electronics fault.	Have checked.	–	X	X
1151	Fault in the engine electronic communication - engine electronics side.	Have checked.	–	X	X
1152	Fault in the engine electronic communication - ECM side.	Have checked.	–	–	X
1160	Rail pressure sensor fault.	Have checked.	–	X	X
1161	Speed sensor fault.	Have checked.	–	X	X
1170	Starting fault (after 3 failed attempts).	Have checked.	–	–	X

Tab. 61 Fault messages and actions concerning the engine.

Message code, range 1200 – 1299 “compressor unit faults”:

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1200	Compressor unit overheating.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.			
		Check the cooling oil level.	10.5.2	–	–
		Clean the radiator.	10.6	–	–
1201	Compressor pressure too high.	Have checked.	–	–	X

Tab. 62 Fault messages and actions concerning the compressor unit

Message code, range 1300 – 1399 “controller faults”:

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1300	Memory fault.	Have checked.	–	–	X
1301	Fault in bus communication with engine electronics.	Have checked.	–	–	X
1302	Fault in bus communication with display unit.	Have checked.	–	–	X
1303	Overheating.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.			
1304	Power supply.	Have checked.	–	–	X

Tab. 63 Fault messages and actions concerning the controller.

Message code, range 1400 – 1499 “general faults”:



Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1400	Quick stop	Unblock.	8.2.6	–	–
		Have checked.	–	–	X
1410	Open circuit in the oil separator tank pressure sensor.	Have repaired.	–	–	X
1411	Short circuit in the oil separator tank pressure sensor.	Have repaired.	–	–	X

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1412	Open circuit in the inlet valve pressure sensor.	Have repaired.	–	–	X
1413	Short circuit in the inlet valve pressure sensor.	Have repaired.	–	–	X
1414	Open circuit in the compressor unit temperature sensor.	Have repaired.	–	–	X
1415	Short circuit in the compressor unit temperature sensor.	Have repaired.	–	–	X
1416	Open circuit in fuel level sensor.	Have repaired.	–	–	X
1417	Short circuit in fuel level sensor.	Have repaired.	–	–	X
1420	Open circuit in the venting valve (p+e).	Have repaired.	–	–	X
1421	Short circuit in the venting valve (p+e).	Have repaired.	–	–	X
1422	Open circuit in the auxiliary venting valve (p)	Have repaired.	–	–	X
1423	Short circuit in the auxiliary venting valve (p)	Have repaired.	–	–	X
1424	Open circuit in the inlet valve control valve (e).	Have repaired.	–	–	X
1425	Short circuit in the inlet valve control valve (e).	Have repaired.	–	–	X
1426	Open circuit in the frost protector valve.	Have repaired.	–	–	X
1427	Short circuit in the frost protector valve.	Have repaired.	–	–	X
1430	Manual-stop automatic mode.	Unblock.	8.2.6	–	–
		Have checked.	–	–	X
1450	Controller block, GSM/GPS monitoring.	Unblock GSM/GPS module.	–	–	X
1470	Automatic start fault.	Have checked.	–	–	X

Tab. 64 General fault messages and measures

### 9.2.2 Warning message on the controller

The machine will not be shut down.

The «Acknowledge»  key flashes. The «Information key»  illuminates.



- In the case of an overheating warning, the machine switches automatically to IDLE to cool down.
- You must acknowledge the alarm message upon correction of the fault.

Further information Further information on the acknowledgement of maintenance messages can be found in chapter 8.4.

**Message code, range 3100 – 3199 “engine warning”:**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3100	Engine oil level low.	Check the engine oil level.	10.4.4	–	–
		Have the engine oil pressure checked.	–	X	–
		Have the oil pressure sensor checked.	–	X	X
3110	Coolant temperature high.	Check the coolant level.	10.4.1	–	–
		Clean the radiator.	10.6	–	–
		Check the cooling system.	–	X	X
3121	Turbo air temperature high.	Check operating conditions. Allow the machine to cool down.	5.2	–	–
		Clean the radiator.	10.6	–	–
		Have the turbo air pressure sensor checked.	–	X	X
3130	Fuel level low.	Refuel.	–	–	–
3133	Fuel filter water level.	Empty the fuel pre-filter water trap.	10.4.3	–	–

Tab. 65 Warning messages and measures relating to the engine.

**Message, code range 3200 – 3299 “compressor unit warnings”:**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3200	Compressor overheating.	Check operating conditions. Allow the machine to cool down.	5.2	–	–
		Check the cooling oil level.	10.5.2	–	–
		Clean the radiator.	10.6	–	–

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3201	Compressor final pressure too high.	Have checked.	–	–	X

Tab. 66 Warning messages and measures relating to the compressor

**Message code, range 3400 – 3499 “general warnings”:**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3400	Battery charging voltage.	Have checked.	–	X	X

Tab. 67 General warning messages and measures

## 9.3 Engine faults and alarms

Further information See also the engine service manual.

### 9.3.1 Engine refuses to start or does not turn over

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
«Quick-stop» button latched in.	Unlatch the «quick-stop» button, see chapter 8.2.6.	–	–	–
Defective starter.	Have changed.	X	–	–
Engine electrical fault	Have repaired/changed.	X	–	–
Fuel tank empty.	Fill up the fuel tank	–	–	–
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.4.3).	–	–	X
Fuel filter clogged.	Clean or replace, see chapter 10.4.3.	–	–	X
Fuel line broken.	Have changed.	X	–	–
Defective control fuse or relay.	Have repaired or replaced if necessary.	X	X	–
Airend discharge temperature too high.	Have adjusted.	–	X	–
SIGMA CONTROL MOBIL defective.	Have repaired/changed.	–	X	–
Electrical connections and/or cables loose or broken.	Tighten the connection or have the cable replaced.	X	–	–

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
Defective battery or low charge.	Maintain battery, see chapter 10.7.	–	–	–
Defective alternator.	Have changed.	X	–	–
Defective alternator regulator.	Have changed.	X	–	–
Oil pressure switch indicating insufficient oil pressure.	Check the engine oil level (see chapter 10.4.4).	–	–	X
	Have the engine repaired or exchanged.	X	–	–

Tab. 68 Fault: engine refuses to start or comes to a stop.

### 9.3.2 Engine does not reach full speed

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.4.3).	–	–	X
Fuel filter clogged.	Clean or replace, see chapter 10.4.3.	–	–	X
Fuel line broken.	Have changed.	X	–	–
Speed adjustment cylinder maladjusted or defective.	Repair or have replaced if necessary.	X	X	–
Engine electrical fault	Have repaired/changed.	X	–	–
SIGMA CONTROL MOBIL defective.	Have repaired/changed.	–	X	–

Tab. 69 Fault: engine does not reach full speed.

## 9.4 Compressor faults and alarms

### 9.4.1 Working pressure too high

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Proportional controller defective.	Have repaired or replaced if necessary.	–	X



Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Pressure gauge indicating false pressure.	Have repaired or replaced if necessary.	–	X
Venting valve does not blow off.	Check the connections and function and have repaired or replaced as necessary.	–	X

Tab. 70 Fault: working pressure too high

### 9.4.2 Working pressure too low.

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Proportional controller defective.	Have repaired or replaced if necessary.	–	X
Inlet valve not opening or only opening partially.	Repair or have replaced if necessary.	–	X
Pressure gauge indicating false pressure.	Have repaired or replaced if necessary.	–	X
Pressure relief valve maladjusted and/or leaking.	Have replaced if necessary.	–	X
Venting valve does not close.	Check the connections and function and have repaired or replaced as necessary.	–	X
Engine does not run at FULL LOAD speed.	See chapter 9.3.	–	–
Engine air filter and/or compressor air filter clogged.	Clean or change, see chapters 10.4.2 and 10.5.7.	–	–
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–

Tab. 71 Fault: working pressure too low

### 9.4.3 Pressure relief valve blowing off

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Pressure relief valve maladjusted and/or leaking.	Adjust or have replaced if necessary.	–	X

Tab. 72 Fault: pressure relief valve blowing off

#### 9.4.4 Machine overheating

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Defective cooling fan.	Have the blades or the complete fan wheel replaced.	–	X
Oil cooler clogged.	Clean surface, see chapter 10.6.	–	–
Defective working element in the combination valve.	Have repaired or replaced if necessary.	–	X
Oil separator cartridge heavily clogged.	Measure the pressure differential and change the cartridge if greater than 1 bar (see chapter 10.5.6).	–	X
Compressor oil filter clogged.	Change, see chapter 10.5.4.	–	–
Compressor cooling oil level too low.	Top up (see chapter 10.5.2).	–	–
Oil pipes leaking.	Seal leaks or have pipes changed.	X	X
Engine cooling system or cooling fan defective.	Have repaired.	X	X
Ambient temperature too high.	See installation conditions in chapter 5.2.	–	–

Tab. 73 Fault: machine overheating

#### 9.4.5 Too much oil residue in the compressed air

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Oil separator cartridge scavenge line clogged.	Clean the strainer in the separator cartridge dirt trap or have changed if necessary.	–	X
Fractured oil separator cartridge.	See chapter 10.5.6 for changing.	–	–

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Oil level in the oil separator tank too high.	Reduce to maximum level, see chapters 10.5.1 and 10.5.3.	–	–

Tab. 74 Fault: too much oil residue in the compressed air

#### 9.4.6 Oil flows from the compressor air filter after shutdown

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Defective non-return function of the inlet valve.	Repair or have replaced if necessary.	–	X

Tab. 75 Fault: oil flows from the compressor air filter after shutdown

#### 9.4.7 Option da, db, dc, dd High moisture content in the compressed air

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Blocked condensate drain on the cyclone separator.	Clean the cyclone separator dirt trap or replace the strainer and nozzle if necessary. Replace (see chapter 10.9.1).	–	X

Tab. 76 Fault: high moisture content in the compressed air

## 10 Maintenance

### 10.1 Safety

Follow the instructions below to ensure safe machine maintenance.

Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions:

**WARNING**

Danger of injury from hot, rotating and electrically live components!  
Serious injury can be caused by touching such components.

- Shut down the machine before opening any doors/canopy.
- Do not carry out any checks or maintenance while the machine is running.

1. Follow the instructions in chapter 'Safety and Responsibility'.
2. Allow maintenance work to be performed by authorised personnel only.
3. Before restarting the machine, make sure that:
  - No personnel are working on the machine,
  - All protective devices and cover panels are in place and secured,
  - All tools have been removed from the machine.

The access doors are held up by gas struts.

- Check that the doors remain open.  
If door does not remain opened: Have the gas-filled spring changed.

#### Working on pressure system:

1. Check that all air consumers are disconnected.
2. Wait until the compressor has automatically vented (check that the pressure gauge indicates 0 bar).
3. Open outlet valves carefully to ensure that the line between the minimum pressure/check valve and the compressed air outlet is vented.
4. Do not open or dismantle any valves.



#### Working on the drive system:

- Before commencing work make sure that:
  - The «battery isolating switch» is off.
  - The machine has cooled down.

Further information Details of authorised personnel are found in chapter 3.4.2.  
Details of dangers and their avoidance are found in chapter 3.5.

### 10.2 Maintenance message on the controller

The controller displays maintenance intervals. Display begins 25 hours before the interval will expire.

When the machine is switched on, the «Information key »  illuminates. The «Acknowledge key »  flashes.

Further information Further information on the acknowledgement of maintenance messages can be found in chapter 8.4. Resetting the maintenance timer is described in chapter 8.5.

#### Message code, range 2100 – 2199 “engine maintenance”

Code	Meaning	Remedy	See chapter
2100	Change engine oil and filter (500h).	Change the engine oil.	10.4.6
		Change the engine oil filter.	10.4.7
2101	Clean or change the engine air filter (500h).	Clean or change air filter.	10.4.2

Tab. 77 Maintenance messages and measures connected with engine maintenance.

#### Message code, range 2200 – 2299 “compressor unit maintenance”

Code	Meaning	Remedy	See chapter
2200	Change the compressor cooling oil and filter (1000h).	Change the cooling oil.	10.5.3
		Change the oil filter.	10.5.4
2201	Clean or change the compressor air filter (250h).	Clean or change air filter.	10.5.7

Tab. 78 Maintenance messages and measures connected with compressor maintenance.

## 10.3 Maintenance schedules

The maintenance schedules provide an overview of the maintenance instructions for the machine.

- Read the relative section before undertaking maintenance.

### 10.3.1 Logging maintenance work



The maintenance intervals given are those recommended for average applications and operating conditions.  
 Maintenance schedules may be modified to take into account the application, the environment and the quality of maintenance.



#### WARNING

Wear and machine damage through unusual applications or operating conditions.

- Maintenance tasks must be carried out more frequently when operating conditions are unfavourable (e.g. dusty atmosphere) or when the equipment is in constant use.
- Adjust the maintenance intervals with regard to local installation and operating conditions.
- Keep a log of all properly carried out maintenance and service work.  
 This enables the frequency of individual maintenance tasks and deviations from our recommendations to be determined.

Further information A prepared list is provided in chapter 10.10.

**10.3.2 Maintenance tasks after commissioning**

The table below lists maintenance tasks required after commissioning (initial start-up).

- Perform maintenance tasks according to the following schedule.

Component: Task	After the first 10 h	After the first 50 h	See chapter	Note
<b>Engine:</b>				
Check belt tension and re-tension if necessary.		X	10.4.8	Engine SM
Check coolant level.		X	10.4.1	Engine SM
<b>Wheels/chassis:</b>				
Re-tighten the wheel nuts/bolts.		X		
h = operating hours; Engine SM = engine manufacturer's service manual				

Tab. 79 Maintenance tasks after commissioning

**10.3.3 Regular maintenance tasks**

The following table lists the various maintenance intervals.

Maintenance interval	Short description
Daily	–
Every 250 h, at least annually.	A250
Every 500 h, at least annually.	A500
Every 1000 h, at least annually.	A1000
Every 1500 h, at least annually.	A1500
Every 2000 h, at least every 2 years.	A2000
Every 3000 operating hours	A3000
Every 6000 operating hours	A6000
Every 36,000 h, at least every 6 years.	A36000

Tab. 80 Maintenance intervals and regular maintenance tasks

The table below lists regular maintenance tasks.

- Carry out maintenance tasks punctually taking ambient and operating conditions into consideration.

**10.3.3.1 Maintenance schedule**

➤ Perform maintenance tasks according to the following schedule.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
<b>Engine:</b>											
Check inlet air filter maintenance indicator	X									10.4.2	
Check engine oil level.	X									10.4.4	Engine SM
Clean the engine air filter			X							10.4.2	
Change the engine oil			X							10.4.6	
Change the engine oil filter.			X							10.4.7	Engine SM
Check and re-tension the drive belt.			X							10.4.8	Engine SM
Change engine air filter.				X						10.4.2	
Have intercooler maintained.			X								SW
Have the turbocharger checked.				X							SW
Have the crankcase venting valve checked.				X							SW
Have the engine mounts checked.				X							SW Engine SM
Have the valve clearance adjusted.					X						SW Engine SM
Replace the drive belts.							X			10.4.8	SW Engine SM
Have the multi-ribbed belt / jockey wheel checked/replaced.							X				Engine SM SW
Have the crankcase venting valve replaced.							X				SW
Check the engine coolant level.	X									10.4.1	Engine SM
Clean the radiator.		X								10.6	
Check coolant hoses and clamps.			X								

Engine SM = engine manufacturer's service manual; SW = specialised workshop.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
Check antifreeze concentration.			X							10.4.1	Engine SM
Change the coolant.				X						10.4.1	Engine SM
Fill up the fuel tank.	X										
Empty the fuel pre-filter water trap.	X									10.4.3	
Clean the fuel filter.			X							10.4.3	Engine SM
Have the fuel pump cleaned.				X							SW
Clean the tank fuel strainer.			X								
Clean the fuel tank.			X								
Check fuel lines and hose clamping bands, replace if necessary.				X							SW
Change the fuel pre-filter.				X						10.4.3	Engine SM
Replace the fuel micro-filter.				X						10.4.3	Engine SM
Check the fuel return line for leakage and firm fixing.			X								
Have the fuel injectors checked.							X				SW
Have the fuel injector pump checked.							X				SW
Check the battery electrolyte level and connections.			X							10.4.9	
Have an electronic test made on the injectors.								X			SW
<b>Compressor unit</b>											
Check inlet air filter maintenance indicator.	X									10.5.7	
Check the cooling oil level.	X									10.5.1	
Clean the compressor air filter.		X								10.5.7	
Clean the oil cooler.		X								10.6	
Have the pressure relief valve(s) checked.			X							10.5.8	
Check/clean the oil separator tank dirt trap.			X							10.5.5	
Change engine air filter.				X						10.5.7	

Engine SM = engine manufacturer's service manual; SW = specialised workshop.



Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
Change the cooling oil.				X						10.5.3	
Change the compressor oil filter.				X						10.5.4	
Change the separator cartridge in the oil separator tank.						X				10.5.6	
<b>Wheels/chassis/bodywork:</b>											
Check the tyre pressures.		X									
Check wheel fixings are tight.		X									
Carry out chassis maintenance.			X							10.8	
Grease the ball coupling, joints and towbar.			X							10.8.2	
Brake maintenance			X							10.8.3	
Check wear on the brake linings.			X							10.8.3.2	
Have the wheel brakes adjusted.			X								SW
Check all screw connections, hinges, locks, handles and snap fasteners of the doors for wear and secure fixing.		X									
Grease the door hinges.			X								
Carry out rubber sealing strip maintenance.			X							10.7	
Have lifting eye and fixings checked.			X								SW
<b>Other maintenance tasks</b>											
Check all accessible screw fit- tings, pipes and clamps for wear and tightness.			X								
Check hoses for proper seating, leaks and wear.			X								
Have hose lines replaced.								X			SW
Check that all electrical connec- tions are tight.			X								
Engine SM = engine manufacturer's service manual; SW = specialised workshop.											

Tab. 81 Regular maintenance tasks

### 10.3.3.2 Maintenance schedule for options

- Perform maintenance tasks according to the following schedule.

Option: Function	Daily	A250	A500	See chapter	Note
<b>Options da, db, dc, dd – cyclone separator:</b>					
Clean and check the dirt trap.			X	10.9.1	
<b>Options da, db, dc, dd – compressed air aftercooler:</b>					
Clean the radiator.		X		10.6.1	
<b>Option dd – filter combination:</b>					
Drain condensate.	X			10.9.2	
Change the filter elements			X	10.9.2	
<b>Option dc – fresh air filter:</b>					
Drain condensate.	X			10.9.3	
Check the oil indicator.				10.9.3	
Change the filter elements			X	10.9.3	
<b>Option ba – low-temperature equipment:</b>					
Have the coolant pre-heating and associated wiring checked.			X		SW
SW = specialised workshop					

Tab. 82 Regular maintenance task options

## 10.4 Engine

- Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.4.1 Cooler maintenance

Material Coolant  
Coolant tester  
Receptacle  
Drain hose  
Funnel  
Cleaning cloth

Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.



**WARNING**

Danger of scalding by hot coolant!  
Serious injuries can be caused by hot coolant.

- Allow the machine to cool down before opening the enclosure.



**CAUTION**

Risk of chemical burns from coolant containing antifreeze!

- Avoid eye and skin contact with coolant. If the eyes are affected, rinse immediately with running water.
- Wear protective glasses and gloves.



**CAUTION**

Insufficient coolant can damage the engine.

Insufficient coolant will cause the engine to overheat. Overheating can cause serious damage to the engine.

- Check the coolant level daily.
- Top up the coolant as necessary.

- Open the right-hand access door.

10.4.1.1 Checking coolant level

Check the coolant level of the engine daily before starting.

The level is checked on the coolant expansion tank.

- The tank is semi-transparent so the coolant level can be seen from outside.
- The level should be between the minimum and maximum markings with the engine cooled down.




Fig. 48 Checking coolant level

- |   |                          |   |                     |
|---|--------------------------|---|---------------------|
| ① | Filler neck with cap     | ⑤ | Coolant level       |
| ② | Overflow                 | Ⓐ | Maximum mark (FULL) |
| ③ | Coolant expansion tank   | Ⓑ | Minimum mark (LOW)  |
| ④ | Radiator connection hose |   |                     |

1. Check the level of coolant in the expansion tank.

Top up when the coolant level falls below the minimum level (B). Replenish the coolant.

2. Close the door.




Determine and rectify the cause of coolant loss.

#### 10.4.1.2 Checking the coolant

The coolant should be checked according to the maintenance schedule to ensure quality and operational life.

Coolant quality can be determined by the following parameters:

- Visual check
  - Antifreeze concentration measurement
- Unscrew and remove the expansion tank filler cap .

##### Visual check

The coolant should be checked for its colour and any particles or sediments floating in it.

- Take a coolant sample and analyze.
- The coolant is discoloured and/or has contains floating particles. Change the coolant.

##### Antifreeze concentration measurement

An instrument (e.g. refractometer) is used to check antifreeze concentration.

Maximum frost protection is ensured with an antifreeze concentration of 55% by volume, as frost protection and heat transfer properties deteriorate beyond this point. Higher concentration also leads to higher operating temperature.



##### CAUTION

The engine can be damaged if the antifreeze concentration is insufficient.

Corrosion

Damage to the cooling system

Engine casing fracture

- Check coolant.
- Protect the coolant against frost.
- Top up as necessary.

1. Use the coolant tester as instructed by the manufacturer to test the coolant.

When the concentration of antifreeze is too low: Change the coolant.

1. Screw on the filler cap.
2. Close the door.

#### 10.4.1.3 Mixing coolant

Do not use water without coolant additive. Water alone is corrosive at engine operating temperature. Water also offers no protection from boiling or freezing.

The coolant is a mixture of clean, fresh water and antifreeze with corrosion inhibitor.

For reasons of corrosion protection and the need to raise the boiling point, the coolant must remain in the cooling system throughout the year.

The maximum permissible coolant life is 2 years.

- Follow coolant recommendations in chapter 2.6.3.

### Preparing coolant

Precondition Coolant must meet the specification of ASTM D4985.

- The coolant should be mixed in the proportions given by the manufacturer.

KAESER coolant mixture table

Antifreeze	Water	Frost protection to [°C]
1 part	2 parts	-20
1 part	1.5 parts	-27
1 part	1 part	-37

Tab. 83 KAESER coolant mixture table



The concentration of antifreeze should not be less than 33% for ensured corrosion protection.

#### 10.4.1.4 Filling and topping up the coolant

The proportion of antifreeze in the coolant should not fall below 33% to ensure frost and corrosion protection and prevent the build up of deposits in the cooling circuit. Topping up with water alone dilutes the antifreeze concentration and is forbidden.



Make sure that there is sufficient room for hot coolant to expand without overflowing.

Precondition The «battery isolating switch» is off.

1. Twist and remove the expansion tank filler cap.
2. Mix a quantity of coolant according to the table and top up to the mark.  
Top up until the coolant level is just below the maximum mark **A**
3. Screw on the filler cap.
4. Activate the «battery isolating switch».
5. Close the door.
6. Start the engine and allow to IDLE for about 1 minute.
7. Stop the engine.
8. Open the right-hand access door.
9. Check the coolant level.  
If the coolant level in the expansion tank has decreased: Replenish the coolant.
10. Visually inspect for leaks.
11. Close the door.

#### 10.4.1.5 Draining the coolant

The complete volume of coolant contained in the circuit can be drained from the radiator. This is done from a drain valve with the aid of a separate drain hose.

Precondition Machine cooled down.  
The «battery isolating switch» is off.




Fig. 49 Draining the coolant from the radiator

- |                          |                                |
|--------------------------|--------------------------------|
| ① Filler cap             | ⑤ Drain valve (ball)           |
| ② Coolant expansion tank | ⑥ Quick-release coupling       |
| ③ Water cooler           | ⑦ Drain hose with male fitting |
| ④ Radiator drain         |                                |

1. Unscrew and remove the expansion tank filler cap ①.
2. Position a coolant receptacle beneath the radiator (hole in the floor panel).
3. Connect a suitable drain hose ⑦ to the radiator quick-release coupling ⑥.
4. Lead the hose through the hole in the floor panel and into the receptacle, securing it in place.
5. Open the drain valve ⑤ and drain the coolant.
6. Close the drain valve and remove the drain hose.
7. Screw on the filler cap.
8. Close the door.



- Dispose of used coolant in accordance with environmental protection regulations.

**Further information** The operating manual supplied by the engine manufacturer provides further information on coolant change and cleaning the cooling system.

**Option sc, si Draining coolant (stationary compressors):**

Compressor cooling oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Coolant is drained via a hose screwed into the radiator drain point. The hose is provided with a shut-off valve and a plug.

**Precondition** Machine cooled down.  
The «battery isolating switch» is off.




Fig. 50 Radiator with centralised drainage

- |                          |                      |
|--------------------------|----------------------|
| ① Filler cap             | ⑤ Screw plug         |
| ② Coolant expansion tank | ⑥ Drain valve (ball) |
| ③ Water cooler           | ⑦ Drain hose         |
| ④ Radiator drain         |                      |

1. Unscrew and remove the expansion tank filler cap ①.
2. Place the coolant receptacle below the radiator drain point ④.
3. Remove the plug ⑤, open the shut-off valve ⑥ and collect the coolant.
4. Close the valve and replace the plug with sealing ring.
5. Close the door.



➤ Dispose of used coolant in accordance with environmental protection regulations.

Further information

The operating manual supplied by the engine manufacturer provides further information on coolant change and cleaning the cooling system.

### 10.4.2 Air filter maintenance

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years at the latest or after it has been cleaned 5 times.



Using the engine without an air filter element is not permitted! Do not use an air filter element with damaged folds or gasket.

Material

- Compressed air for blowing out
- Spare parts (as required)
- Cleaning cloth

Precondition


- The machine is shut down.
- The machine is fully vented, the pressure gauge reads 0 bar.
- Machine is cooled down.
- All compressed air consumers are disconnected and the air outlet valves are open.



**WARNING**

Damaged air filter element.  
Wear in the engine from intake of contaminated air.


- Do not try to clean the filter element by striking or knocking it.
- Do not wash the filter element.



10-M0158

Fig. 51 Engine air filter maintenance

- |  |                  |
|--|------------------|
| ① Maintenance indicator                          | ⑤ Filter element |
| ② Red zone indicator scale                       | ⑥ Retaining clip |
| ③ Indicating piston of the maintenance indicator | ⑦ Filter cap     |
| ④ Reset knob for the maintenance indicator       |                  |



10-M0843

Fig. 52 Cleaning the filter element

- |   |
|---|
| ① Compressed air gun with blast pipe bent to 90° at the end |
| ② Filter element  |

**Checking contamination of the air filter:**

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

1. Open the left-hand door.
2. Check the air filter maintenance indicator.  
If the yellow piston reaches the red zone, clean or renew the filter element.
3. Close the door.



**Cleaning the air filter:**

1. Open both doors.
2. Release the retaining clip. Lift off the cap and extract the element.
3. Carefully clean the inside of the housing, the cover and sealing faces with a damp cloth.
4. Cleaning the filter element:
  - Use dry compressed air ( $\leq 5$  bar!) at an angle to blow dust from the element from inside to outside until no further dust develops.
  - The blast pipe must be long enough to reach the bottom of the element.
  - The tip of the blast pipe must not touch the element.
  - Cleaning sealing faces.
5. Inspect the element carefully for any damage.  
Damaged filter element: replace filter element.
6. Insert the cleaned or new filter element into the filter housing. Make sure it is properly in place and sealed by its gaskets.
7. Replace the cap and secure with the clip.

**Resetting the maintenance indicator:**

- Repeatedly press the reset knob on the maintenance indicator.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the doors.



Dispose of old parts and contaminated materials according to environmental regulations.

**10.4.3 Fuel system maintenance**

Make sure no dirt enters the fuel system during maintenance. Clean components and their surroundings before dismounting.

Material Spare parts  
Receptacle  
Cleaning cloth

Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.


**DANGER**

Danger of fire from spontaneous ignition of fuel!  
 Serious injury or death could result from the ignition and combustion of fuel.

- Allow no open flames or sparks at the place of use.
- Stop the engine.
- Wipe up escaped fuel.
- Keep fuel away from hot machine parts.
- Ensure that the maximum ambient temperature is not exceeded at the place of use.




Fig. 53 Fuel system maintenance

- |   |  |
|---|--|
| <ul style="list-style-type: none"> <li>① Fuel tank</li> <li>② Fuel fine filter</li> </ul> | <ul style="list-style-type: none"> <li>③ Fuel pre-filter with water trap</li> <li>④ Manual fuel pump with bayonet fitting</li> </ul> |
|---|--|

- Open the right-hand access door.

**10.4.3.1 Bleeding the fuel system**

Air can enter the fuel system if the fuel tank is empty, after a fuel filter change or when carrying out work on the fuel lines.

Bleed the fuel system if the engine refuses to start despite a full fuel tank.

1. Open the right-hand access door.
2. Unlatch the manual fuel pump bayonet lock by pressing and turning anti-clockwise.  
The pump piston is pushed out by the spring.
3. Pump the piston until high resistance is felt.
4. Keep pumping until the return line is filled.
5. Activate the «battery isolating switch».
6. Close the door.



Start the engine as soon as the fuel system has been bled and allow to run for at least 5 minutes in IDLE.

7. Open the right-hand access door.
8. Latch the manual fuel pump bayonet lock by pressing and turning clockwise.
9. Check the fuel pre-filter for leaks.  
Fuel has escaped: Re-tighten filter cartridge and all screw connections.
10. Close the door.

10.4.3.2 Fuel pre-filter maintenance


**Emptying the water trap**

The fuel pre-filter is equipped with a water trap. Contaminating water is trapped in the water receptacle. The water trap is connected by a sensor to the controller. If the water in the trap reaches a set level, the controller displays a warning.

- The display indicate water in the fuel filter.
- The «Information key » ⓘ lights up,
- The «Acknowledge» key Ⓢ flashes.




The water trap receptacle must be emptied when this warning is given.



10-M0413

Fig. 54 Warning messages: Fuel filter water level

- Ⓜ R2 Message category: warning
- Ⓜ R4 Message code
- Ⓜ R9 Fuel filter water level



10-M0414


Fig. 55 Emptying the fuel pre-filter water trap

- ① Fuel pre-filter with water trap
- ② Water receptacle
- ③ Drainage tap

1. Place a receptacle beneath the fuel pre-filter.
2. Open the drainage tap and allow water and dirt to drain out into the receptacle.
3. Close the drainage tap.
4. Activate the «battery isolating switch».
5. Close the door.

Maintenance must be acknowledged after the water trap has been emptied.

Precondition Draining the water trap


- Confirm the maintenance with the «Quit »  key.

The illuminated «Quit »  and «Information» keys  are extinguished.








The mixture of fuel and water and any materials contaminated with fuel must be disposed of in accordance with environment protection regulations.

### Changing the filter cartridge



10-M0855

Fig. 56 Changing the fuel pre-filter cartridge

- |  |                  |   |  |
|--|------------------|---|--|
|   | Filter head      |  | Drainage tap                             |
|   | Filter cartridge |  | Connection for filter maintenance sensor |
|  | Water receptacle |   |  |

- Place a receptacle beneath the fuel pre-filter.
- Open the drainage tap and allow water and dirt to drain out into the receptacle.
- Disconnect the filter maintenance sensor.
- Unscrew the filter cartridge and water trap anti-clockwise and remove.
- Disconnect the water trap from the filter cartridge by unscrewing anti-clockwise.
- Clean any fuel from the receptacle and clean the water trap.
- Close the drainage tap.
- Screw the water trap onto the new filter cartridge.
- Clean the sealing faces of the filter cartridge and filter head with a damp cloth.
- Coat the sealing face of the new cartridge lightly with fuel and screw into the filter head.
- Reconnect the filter maintenance sensor.
- Activate the «battery isolating switch».
- Close the door.



The fuel system must be bled after the filter cartridge has been changed.



Dispose of fuel and any materials and components contaminated with it in accordance with environmental protection regulations.

Further information The engine service manual gives further information on fuel filter changing.

**10.4.3.3 Fuel filter maintenance**


10-M0164

Fig. 57 Fuel filter maintenance

- ① Filter holder
- ② Filter cartridge
- ③ Turn in this direction to unscrew the filter cartridge.

1. Place a container beneath the fuel filter.
2. Use a filter wrench to loosen then unscrew the filter cartridge. Catch fuel in the receptacle.
3. Carefully clean the filter holder sealing face using lint-free cloth.
4. Lightly coat the filter holder rubber gasket with fuel.
5. Lightly coat the new fuel filter cartridge with fuel and screw tight by hand.
6. Activate the «battery isolating switch».
7. Close the door.



The fuel system must be bled after the filter cartridge has been changed.



Dispose of fuel and any materials and components contaminated with it in accordance with environmental protection regulations.

Further information The engine service manual gives further information on fuel filter changing.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 1 minute.
2. Shut down the machine.
3. Open the right-hand access door.
4. Visually check the fuel system for leaks.
5. Tighten all fittings.
6. Close the door.

**10.4.4 Checking the engine oil level**

The engine oil is indicated by a dipstick in the oil sump. The oil level should ideally be between the two marks on the dipstick. The oil level should not be allowed to fall below the «minimum level».

Material Cleaning cloth

Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Engine cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.




Fig. 58 Checking the engine oil level

- |                         |                                |
|-------------------------|--------------------------------|
| ① Engine oil filler cap | Ⓐ Mark for «maximum oil level» |
| ② Oil dipstick          | Ⓑ Mark for «minimum oil level» |

1. Open the right-hand access door.
2. Withdraw the dipstick, wipe with a lint-free cloth and replace fully.
3. Withdraw the dipstick once more and read off the oil level.  
Oil level between both markings: Oil level OK.  
The level has reached the «minimum level» or is below the mark: Replenish engine oil.
4. Close the door.



The marked «maximum oil level »should not be exceeded in order for the level of oil in the crankcase not to reach the crankshaft. If this were to occur, it could create oil bubbles that would reduce the oil's lubricating capability and impair engine performance.

### 10.4.5 Engine oil filling and topping up

Material Engine oil  
Cleaning cloth  
Funnel

Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.

**Filling with engine oil**


See chapter 2.6.4 for engine oil filling volume.  
 The oil dipstick is marked with the «maximum oil level».

1. Open the right-hand access door.
2. Remove the filler cap and fill with fresh oil.
3. Wait 5 minutes then check the oil level.



It takes a few minutes for oil to reach the sump.

Low oil level: Replenish engine oil.

4. Replace the filler cap.
5. Activate the «battery isolating switch».
6. Close the door.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
 Pressure gauge reads 0 bar!
4. After approximately 5 minutes: Check the engine oil level.  
 Low oil level: Add more engine oil.
5. Visually inspect for leaks.

**10.4.6 Changing the engine oil**

The engine oil should be changed:

- according to the maintenance schedule,
- according to the degree of contamination of the intake air,
- at least once a year.



See chapter 2.6.4 for engine oil filling volume.  
 See engine service manual for oil change under dusty conditions.

**Material** Engine oil  
 Receptacle  
 Cleaning cloths

**Precondition** The machine is shut down.  
 The machine is standing level.  
 The machine is fully vented, the pressure gauge reads 0 bar.  
 Engine at operating temperature.  
 All compressed air consumers are disconnected and the air outlet valves are open.  
 The «battery isolating switch» is off.



**CAUTION**

Danger of burns from hot components and escaping engine oil!

- Wear long-sleeved clothing and gloves.




Fig. 59 Draining the engine oil

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>① Floor pan</li> <li>② Engine oil sump</li> </ul> | <ul style="list-style-type: none"> <li>③ Drain plug</li> <li>④ Drain hole in the floor pan</li> </ul> |
|--|---|

**Draining the engine oil**

1. Open the right-hand access door.
2. Place the oil receptacle below the drain hole in the floor pan.
3. Unscrew the drain plug.  
Engine oil flows into the receptacle.
4. Clean the drain plug and screw in with a new gasket.
5. Close the access door.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

Further information See chapter 10.4.5 for oil filling.


The engine service manual gives instructions on oil changing.

**Option sc, si Draining the engine oil (stationary machine)**

Compressor cooling oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Engine oil is drained via a hose connected to a drain point on the engine block. The hose is provided with a shut-off valve and a plug.



Option sc, si



10-M0838

Fig. 60 Draining the engine oil, central drain point

- |                      |                   |
|----------------------|-------------------|
| ① Engine oil drain   | ④ Drain hose      |
| ② Screw plug         | ⑤ Engine oil sump |
| ③ Drain valve (ball) |                   |

1. Place the oil receptacle below the drain point ①.
2. Remove the plug ②, open the shut-off valve ③ and collect the oil.
3. Close the valve and replace the plug with sealing ring.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

Further information

See chapter 10.4.5 for oil filling.

The engine service manual gives instructions on oil changing.

### 10.4.7 Changing the oil filter

Material

- Spares
- Chain pipe wrench (part no. 8.8095.0)
- Cleaning cloth
- Receptacle

Precondition

- The machine is shut down.
- The machine is fully vented, the pressure gauge reads 0 bar.
- Engine cooled down.
- All compressed air consumers are disconnected and the air outlet valves are open.
- The «battery isolating switch» is off.



**CAUTION**

Danger of burns from hot components and escaping engine oil!

- Wear long-sleeved clothing and gloves.




Fig. 61 Changing the oil filter

- ① Engine
- ② Direction of rotation to unscrew the filter
- ③ Chain wrench

1. Open the right-hand access door.
2. Prepare a receptacle.
3. Loosen the filter with the chain wrench and screw off. Catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the engine oil level.  
Low oil level: Replenish engine oil.
8. Activate the «battery isolating switch».
9. Close the door.

Further information The engine service manual gives further information on oil filter changing.



Dispose of old oil filters, old oil and materials contaminated with oil according to environmental protection regulations.

### 10.4.8 Maintaining the drive belt

The life of the drive belts is affected by the belt tension.

- Slack belts can slip and become damaged and may result in engine overheating.
- Over-tight belts stretch and wear quicker. Over-tight belts also place unnecessary stress on bearings and shorten their life.

Material Ratchet  
Locking pin  
V-belt tension measuring device  
Spares

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.



**WARNING**

Beware of rotating pulleys and moving belts.  
There is danger of serious injury from pinching.

- Never check the drive belts unless the engine is at standstill.
- Never run the machine without a belt guard.

- Open both doors.

**Removing the belt guard:**




Fig. 62 Belt guard attachment

- ① Engine
- ② Hexagon screws (belt guard attachment)
- ③ Belt guard

- Unscrew the securing screws of the belt guard and remove the belt guard.

**10.4.8.1 Visual inspection**

1. Check the belts thoroughly for cracks, fraying or stretching.  
When damaged or worn: Replace the drive belt immediately.
2. Replace the belt guard.
3. Activate the «battery isolating switch».
4. Close the doors.

10.4.8.2 Checking belt tension

Check belt tensions only when they are warm, not hot, to avoid length differences due to temperature differences.

The engine manufacturer recommends a tension measuring device for belts. For operation see the engine service manual.

The belt tension may also be checked by hand if no tension measuring device is available.




Fig. 63 Manual checking of the belt tension

- A** Permissible intrusion depth of the belt
- \*** Approximate pressure exerted: 10 kg  
Permissible movement: 10 – 15 mm

Checking belt tension with tension measuring device.	Belt tension checking by hand
<ol style="list-style-type: none"> <li>1. Check belt tension with the tension measuring device.</li> <li>2. Increase the tension on a loose belt.</li> </ol>	<p>Press the belts in with the thumb at the mid-point between pulleys.</p> <ol style="list-style-type: none"> <li>1. Check belt tension by hand (see Fig. 63).</li> <li>2. Increase the tension on a loose belt.</li> </ol>

**Putting in operation:**

1. Replace the belt guard.
2. Activate the «battery isolating switch».
3. Close the doors.

10.4.8.3 Changing/tensioning the drive belt

The drive belt is pre-tensioned by the spring force in the jockey wheel. By turning the jockey wheel you can adjust the belt tension.




Fig. 64 Changing/tensioning the drive belt

- |                |               |
|----------------|---------------|
| ① Drive belt   | ③ Locking pin |
| ② Jockey wheel | ④ Ratchet     |

**Tensioning the drive belt:**

1. Insert the ratchet square in the corresponding hole in the jockey wheel.
2. Using the ratchet, press the jockey wheel opposite the arrow direction. Ensure that the drive belt is correctly positioned in its guide.
3. Check the belt tension (see Fig. 63).  
 Belt tension too low: Using the ratchet, further press the jockey wheel opposite the arrow direction.  
 Belt tension too high: Using the ratchet, slightly press the jockey wheel in arrow direction.

**Changing the drive belt:**

1. Insert the ratchet square in the corresponding hole in the jockey wheel.
2. Using the ratchet, press the jockey wheel in arrow direction until the locking pin can be fastened in the mounting hole.
3. Insert locking pin in mounting hole.  
 The drive belt is free of tension.
4. Pull the drive belt first off the smallest or the jockey wheel.
5. Check the pulleys for dirt and wear.  
 Dirty pulley: Clean pulley.  
 Worn pulley: Have the pulley changed.
6. Manually route the new drive belt over the pulleys without using force.
7. Hold up the jockey wheel with the ratchet and remove the locking pin.  
 The jockey wheel is pushed upwards by spring tension and pre-tensions the drive belt.
8. Tension the drive belt. Ensure that the drive belt is correctly positioned in its guide.



A belt that has been replaced may not be used again.  
 Check the belt tension after running for approximately 15 minutes.



Old belts should be disposed of in accordance with the latest environmental regulations.

**Putting in operation:**

1. Replace the belt guard.
2. Activate the «battery isolating switch».
3. Close the doors.

Further information The operating manual of the engine manufacturer provides further information on removing, changing and tensioning drive belts.

**10.4.9 Battery maintenance**

- Check the charging system if batteries discharge without reason.

**10.4.9.1 Safety**




**WARNING**

Danger of acid burns from escaping electrolyte!

- Wear appropriate protective clothing including acid-proof rubber gloves.
- Always wear eye and face protection.
- Do not tip the battery. Electrolyte may run out of the vent holes.
- Work carefully.

**Observe the following points when working on the batteries:**



10-M0167

Fig. 65 Safety signs - warning stickers on the battery.

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>① Fire, sparks, open flame and smoking are forbidden!</li> <li>② Wear eye and face protection! Danger of chemical burns!</li> <li>③ Keep children well away from batteries and electrolytes!</li> </ul> | <ul style="list-style-type: none"> <li>④ Batteries are filled with caustic electrolyte!</li> <li>⑤ Observe the battery manufacturer's instructions!</li> <li>⑥ Explosion hazard!</li> </ul> |
|--|---|

- Note and adhere to any safety signs on the battery warning labels.

**Further instructions on working with batteries:**

1. Do not remove battery terminal covers unnecessarily.
2. Do not place tools on the battery. This can lead to short circuiting, overheating and bursting of the battery!
3. Take particular care when the battery has been in service for a long time or has just been charged as highly explosive gas is emitted.  
Ensure good ventilation.

**10.4.9.2 Battery checking and care**

Even so-called 'maintenance-free' batteries need a degree of care to obtain their maximum operational life.

The outside of the battery and the terminals should be cleaned regularly with a soft cloth. This avoids current leaks and minimises the discharge rate.

Material Terminal grease  
Distilled water  
Cleaning cloth  
Protective gloves  
Eye protection

Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.

- Open the left-hand door.
- 1. Clean the casing and terminals.
- 2. Lightly grease the terminals to prevent corrosion.
- 3. Check that connections are tight and tighten if necessary.

**Check the battery electrolyte level:**

The acid quantity is generally sufficient for the life of the battery. Nevertheless, the fluid level should be checked annually. The level should be up to the mark, 1 cm above the plates.



Replace the battery immediately if the casing leaks.

**WARNING**

Battery destruction!

Topping up with pure acid will increase the electrolyte concentration and can destroy the battery.

➤ Top up only with distilled water.

➤ Check the electrolyte level.



If the level does not reach the mark -

➤ top up with distilled water.

➤ Close the door.

**Winter operation:**

Batteries are particularly stressed in winter. Only a fraction of the normal starting energy is available at low temperatures.

**CAUTION**

Danger of battery freezing!

Discharged batteries are subject to frost damage and can freeze at  $-10\text{ }^{\circ}\text{C}$ .

- Check battery charge with a acid density tester.
- Recharge the battery.
- Clean the cable connections and apply terminal grease.

1. Check the battery charge weekly.

Recharge as necessary.

2. For machine standstill times of several weeks: Remove the batteries and store in a frost-free room.



In extreme cases, the use of heavy-duty cold-start batteries and/or additional batteries is recommended.

**10.4.9.3 Battery removal and installation**

Precondition The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine is cooled down.

The «battery isolating switch» is off.

**WARNING**

Risk of battery bursting!

If a battery is short circuited it will overheat and can burst.

Battery electrolyte will be sprayed out in such an event.

- Never short-circuit a battery (e.g. with a hand tool).
- Wear gloves and eye protection.

**CAUTION**

Excessive voltage produced by the alternator.

Voltage peaks can destroy the alternator regulator and diodes.

- The battery serves as a buffer and must not be disconnected while the engine is running.

1. Open the left-hand door.
2. Disconnect the negative cable first, then the positive cable.
3. Unscrew the battery fixing clamp.
4. Replace in the reverse order.
5. Activate the «battery isolating switch».
6. Close the door.

**Replacing batteries**

Replacement batteries must have the same capacity, current strength and form as the original batteries.

- Always replace a battery with one of the same type.



Old batteries are special waste and must be disposed of correctly in accordance with local environment protection regulations.



## 10.5 Compressor

- Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.5.1 Checking cooling oil level

The oil level is checked at the oil separator tank filling port. Oil must be visible in the port when the filler plug is removed.

Material Cleaning cloths

Precondition The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

All compressed air consumers are disconnected and the air outlet valves are open.




Fig. 66 Checking cooling oil level

- ① Oil separator tank
- ② Oil filler port
- ③ Screw plug

- Ⓐ Minimum level
- Ⓑ Maximum level

1. Open the left-hand door.
2. Slowly unscrew and withdraw the plug from the oil filler port.
3. Check that oil is visible.  
Top up if no oil is visible.
4. Replace the filler plug.
5. Close the access door.

**10.5.2 Cooling oil filling and topping up**

Material	Cooling oil Funnel Cleaning cloth Wrench
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.


**Filling with cooling oil**

A sticker on the oil separator tank specifies the type of oil used.

**CAUTION**

The machine could be damaged by unsuitable oil!

- Never mix incompatible types of oil.
- Never top up with a different type of oil than that already used in the machine.

1. Open the left-hand door.
2. Slowly unscrew and withdraw the plug from the oil filler port.
3. Top up the cooling oil to the maximum level  with the help of a funnel.
4. Check the oil level.
5. Check the filler plug gasket for damage.  
Damaged gasket: replace gasket.
6. Replace the plug in the filler port.
7. Activate the «battery isolating switch».
8. Close the door.

**Starting the machine and performing a test run:**

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
5. Open the outlet valves.
6. Open the left-hand door.
7. Check the oil level after about 5 minutes.  
Cooling oil level too low: Replenish with more cooling oil.
8. Visually inspect for leaks.
9. Close the door.

### 10.5.3 Changing the cooling oil

Drain all cooling-oil from:

- Oil separator tank
- Oil cooler
- Oil pipes

Material cooling oil  
 Receptacle  
 Drain hose  
 New gasket for the drain plug  
 Funnel  
 Cleaning cloths

Precondition The machine is shut down.  
 The machine is standing level.  
 The machine is fully vented, the pressure gauge reads 0 bar.  
 The machine is at operating temperature.  
 All compressed air consumers are disconnected and the air outlet valves are open.  
 The «battery isolating switch» is off.



**CAUTION**

There is risk of burns from hot components and escaping oil.

- Wear long-sleeved clothing and gloves.




Fig. 67 Changing the cooling oil

- |                                 |                                |
|---------------------------------|--------------------------------|
| ① Oil separator tank            | ⑤ Quick-release coupling       |
| ② Oil filler plug               | ⑥ Drain hose with male fitting |
| ③ Oil separator tank drain plug | ⑦ Oil cooler                   |
| ④ Shut-off valve (ball)         |                                |

- Heed the safety instructions in chapter 3.5.

**10.5.3.1 Draining the cooling oil**

1. Open both doors.
2. Remove the plug ② from the oil separator tank filling port.

**Draining the oil from the separator tank:**

The oil separator tank can be drained from a point accessible through a hole in the floor panel.

1. Position a receptacle below the separator tank drain plug ③.
2. Unscrew the drain plug ③ and allow the cooling oil to drain into the receptacle.
3. Fit a new gasket on the drain plug and screw it back in again.

**Draining the oil from the cooler:**

This is done from a drain valve with the aid of a separate drain hose.

1. Position a receptacle beneath the oil cooler drain point (accessible through a hole in the floor panel).
2. Connect a suitable drain hose ⑥ to the oil cooler quick-release coupling ⑤.
3. Lead the hose through the hole in the floor panel and into the receptacle, securing it in place.
4. Open the drain valve ④ slowly and drain the cooling oil.
5. Close the drain valve and remove the drain hose.

**Performing final work steps:**

1. Replace the plug ② in the oil separator tank filling port.
2. Close the doors.



Dispose of used oil and oil-contaminated working materials according to environmental protection regulations.

Further information See chapter 10.5.2 for oil filling.

**10.5.3.2 Option sc, si  
Draining cooling oil (stationary compressors)**

Compressor cooling oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Oil drainage is via hose lines screwed into the drain ports of the oil separator tank and the airend. Each hose line is provided with a shut-off valve and a plug.




Fig. 68 Central compressor oil drainage

- |                                       |                      |
|---------------------------------------|----------------------|
| ① Oil filler plug                     | ④ Screw plug         |
| ② Oil separator tank drain connection | ⑤ Drain valve (ball) |
| ③ Oil cooler drain connection         | ⑥ Drain hose         |

1. Open both doors.
2. Remove the plug ① from the oil separator tank filling port.

**Draining the oil from the separator tank:**

1. Place the oil receptacle below the oil separator tank drain point ②.
2. Remove the plug, open the shut-off valve and collect the oil.
3. Close the valve and replace the plug with sealing ring.

**Draining the oil from the cooler:**

1. Place the oil receptacle below the oil cooler drain point ③.
2. Remove the plug, open the shut-off valve and collect the oil.
3. Close the valve and replace the plug with sealing ring.

**Performing final work steps:**

1. Replace the plug ① in the oil separator tank filling port.
2. Close the doors.



Dispose of used oil and oil-contaminated working materials according to environmental protection regulations.

Further information See chapter 10.5.2 for oil filling.

### 10.5.4 Changing the oil filter

Material Spares  
Receptacle  
Cleaning cloth

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.



**CAUTION**

Danger of burning from hot components and oil.

➤ Wear long-sleeved clothing and gloves.




Fig. 69 Changing the oil filter

- ① Oil filter
- ② Direction of rotation to unscrew the oil filter.
- ③ Combination valve

**Changing the oil filter:**

1. Open the left-hand door.
2. Prepare a receptacle.
3. Loosen the filter by turning counter-clockwise and catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the oil level in the oil separator tank.  
Cooling oil level too low: Replenish the cooling oil.
8. Activate the «battery isolating switch».
9. Close the door.



Dispose of old cooling oil and any materials or parts contaminated with oil according to environment protection regulations.

**Starting the machine and performing a test run:**

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
5. Open the outlet valves.
6. Open the left-hand door.
7. After approximately 5 minutes: Check the cooling oil level.  
Cooling oil level too low: Replenish with more cooling oil.
8. Visually inspect for leaks.
9. Close the door.

**10.5.5 Oil separator tank dirt trap maintenance**

The control valve is mounted on the oil separator tank cover. The control valve has two different dirt traps that must be cleaned at least once a year.

**Material** Cleaning cloth  
Wrench  
Small screwdriver  
Maintenance kit, control valve  
Petroleum ether or spirit

**Precondition** The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.




Fig. 70 Oil separator tank dirt trap maintenance

- |   |   |
|---|---|
| ① Oil separator tank cover                | ⑦ Screw-in connector                              |
| ② Control valve                           | ⑧ Nozzle  |
| ③ Union nut                               | ⓑ Detail of the proportional controller dirt trap |
| ④ Oil scavenge tube                       | ⑨ Screw plug                                      |
| Ⓐ Detail of the oil return line dirt trap | ⑩ O-ring  |
| ⑤ Strainer                                | ⑪ Strainer  |
| ⑥ Sealing ring                            |   |

➤ Open the left-hand door.

#### 10.5.5.1 Oil return line dirt trap maintenance

See Fig. 70; detail: A for the component positions.

1. Undo the union nut ③ and bend the oil return line ④ to one side.
2. Unscrew the screw-in connector ⑦.
3. Unscrew the strainer ⑤ from the screw-in connector.
4. Use a screwdriver to unscrew the nozzle ⑧ from the screw-in connector.
5. Clean the housing, strainer and sealing ring ⑥ with cleaning solvent or spirit.
6. Check the nozzle, strainer and sealing ring for wear.  
When clearly worn: replace components.
7. Fit the nozzle and strainer to the screw-in connector.
8. Screw in the connector making sure the sealing ring seats properly.
9. Refit the oil scavenge line.

#### 10.5.5.2 Maintenance of the proportional controller dirt trap

See Fig. 70; detail: B for the component positions.

1. Unscrew the plug ⑨ and remove the strainer ⑪.
2. Clean the plug, strainer and O-ring ⑩ with cleaning solvent or spirit.
3. Check the strainer and O-ring for wear.  
When clearly worn: replace components.
4. Place the strainer on the screw plug.
5. Screw in the plug making sure the O-ring seats properly.



**Putting in operation:**

1. Switch the «battery isolating switch» on.
2. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
4. Open the outlet valves.
5. Open the left-hand door.
6. Visually inspect for leaks.
7. Shut down the machine.
8. Close the door.

**10.5.6 Changing the oil separator cartridge**

The oil separator element cannot be cleaned.

The life of the oil separator cartridge is influenced by:

- Contamination in the air drawn into the compressor
- and adherence to the changing intervals for:
  - Cooling oil
  - Oil filter
  - Air filter

Material Spare parts  
Cleaning cloth  
Wrench

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.




Fig. 71 Changing the oil separator cartridge

- |   |                            |
|---|----------------------------|
| ① Control air line union nut  | ⑨ Control valve            |
| ② Oil scavenge pipe (screwed to the cover)                              | ⑩ Solenoid valve           |
| ③ Oil scavenge pipe union nut (lower fitting, screwed to the dirt trap) | ⑪ Sealing ring             |
| ⑤ Air pipe  | ⑬ Oil separator cartridge  |
| ⑦ Cover   | ⑭ Pressure transducer      |
| ⑧ Fixing screw  | ⑮ Relief valve guard plate |

➤ Open the left-hand door.

### Changing the oil separator cartridge

1. Unscrew the union nuts ① and ③ and place the components with connections carefully to one side.
2. Pull out the plug to the solenoid valve ⑩ and withdraw the cable.
3. Pull out the plug to the sensor ⑭ and withdraw the cable.
4. Remove the screws ⑧ securing the cover ⑦ to the tank.
5. Remove the protective guard ⑮ from the relief valve.
6. Carefully lift the cover and put to one side.



Take particular care with the following components:

- The oil scavenge line ② screwed to the underside of the cover.
- The pressure relief valve, covered by the guard plate ⑮.

7. Take out the old cartridge ⑬ and sealing rings ⑪.
8. Clean all sealing surfaces, taking care that no foreign bodies (dirt particles) fall into the oil separator tank.
9. Insert the new oil separator cartridge with sealing rings and screw down the cover.
10. Replace the relief valve guard plate ⑮.
11. Replace and tighten all fittings.
12. Reconnect cables.

13. Check the oil level in the oil separator tank.

Cooling oil level too low: Replenish the cooling oil.



Maintenance of the control valve dirt trap must be carried out whenever the oil separator cartridge is changed.

Further information Information on control valve dirt trap maintenance is given in chapter 10.5.5.

**Putting in operation:**

1. Switch the «battery isolating switch» on.
2. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

**Starting the machine and performing a test run:**

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
5. Open the outlet valves.
6. Open the left-hand door.
7. Check the oil level after about 5 minutes.  
Top up if necessary.
8. Visually inspect for leaks.
9. Close the door.

**10.5.7 Air filter maintenance**

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years at the latest or after it has been cleaned 5 times.



Using the machine without an air filter element is not permitted! Do not use an air filter element with damaged folds or gasket.

Material Compressed air for blowing out  
Spare parts (as required)  
Cleaning cloth


Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.



**WARNING**

Damaged air filter element.  
Wear in the engine from intake of contaminated air.


- Do not try to clean the filter element by striking or knocking it.
- Do not wash the filter element.



10-M0156

Fig. 72 Compressor air filter maintenance

- |  |                  |
|--|------------------|
| ① Maintenance indicator                          | ⑤ Filter element |
| ② Red zone indicator scale                       | ⑥ Retaining clip |
| ③ Indicating piston of the maintenance indicator | ⑦ Filter cap     |
| ④ Reset knob for the maintenance indicator       |                  |



10-M0843

Fig. 73 Cleaning the filter element

- |   |
|---|
| ① Compressed air gun with blast pipe bent to 90° at the end |
| ② Filter element  |

- Open both doors.

**Checking contamination of the air filter:**

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

- Check the air filter maintenance indicator.  
If the yellow piston reaches the red zone, clean or renew the filter element.

**Cleaning the air filter:**

1. Release the retaining clip. Lift off the cap and extract the element.
2. Carefully clean the inside of the housing, the cover and sealing faces with a damp cloth.
3. Cleaning the filter element:
  - Use dry compressed air ( $\leq 5$  bar!) at an angle to blow dust from the element from inside to outside until no further dust develops.
  - The blast pipe must be long enough to reach the bottom of the element.
  - The tip of the blast pipe must not touch the element.
  - Cleaning sealing faces.
4. Inspect the element carefully for any damage.  
Damaged filter element: replace filter element.
5. Insert the cleaned or new filter element into the filter housing. Make sure it is properly in place and sealed by its gaskets.
6. Replace the cap and secure with the clip.

**Resetting the maintenance indicator:**

- Repeatedly press the reset knob on the maintenance indicator.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the doors.

**10.5.8 Checking pressure relief valves**

- Have pressure relief valves checked by KAESER Service in accordance with the maintenance schedule.

**10.6 Cleaning the coolers and radiator**

The compressor oil cooler and engine coolant radiator are combined in a single cooler block. The frequency of cleaning is mainly dependent on local operating conditions. Heavy clogging of the cooler/radiator can cause oil overheating and overheating of the engine. Check the cooler/radiator regularly for clogging. Avoid creating dust eddies. Wear breathing protection if necessary. Do not clean the cooler/radiator with a sharp instrument, otherwise it could be damaged. A severely contaminated cooler/radiator should be cleaned by KAESER Service.

Material	Compressed air Water or steam jet blaster
Precondition	Machine placed over a washing point equipped with an oil separator. The machine is shut down. Machine cooled down. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.




**CAUTION**

Damage to the machine can be caused by water or steam jets.

Direct water or steam jets can damage or destroy electrical components and indicating instruments.

- Cover up electrical components such as the control cubicle, alternator, starter and instruments.
- Do **not** direct water or steam jets at sensitive components such as alternator, starter or indicating instruments.



10-M0157

Fig. 74 Cooler/radiator cleaning

- |   |              |
|---|--------------|
| ① Front end of compressor, sound insulation (radiator grill) removed  | ④ Air cooler |
| ② Direction of impacting water or steam jet (from outside to inside). | ⑤ Radiator   |
| ③ Oil cooler  |              |

1. Open both doors.
2. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
3. Remove the sound damping louver in front of the cooler/radiator.
4. Clean the cooling fins with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
5. Replace the sound damping louver.
6. Remove the protective coverings from the air filters.
7. Switch the «battery isolating switch» on again.
8. Close the doors.
9. Start the machine and run up to operating temperature so that excess water is evaporated.



Clean the cooler/radiator only in a washing area equipped with an oil separator.

**10.6.1 Option da, db, dc, dd  
Cleaning the compressed air aftercooler**

The compressed air aftercooler is located near the air treatment devices.

Material Compressed air  
 Water or steam jet blaster

Precondition Machine placed over a washing point equipped with an oil separator.  
 The machine is shut down.  
 Machine cooled down.  
 The machine is fully vented, the pressure gauge reads 0 bar.  
 All compressed air consumers are disconnected and the air outlet valves are open.  
 The «battery isolating switch» is off.




#### CAUTION

Damage to the machine can be caused by water or steam jets.  
 Direct water or steam jets can damage or destroy electrical components and indicating instruments.

- Cover up electrical components such as the control cabinet, alternator, starter and instruments.
- Do **not** direct water or steam jets at sensitive components such as operating and indicating instruments.

Option da, db, dc, dd



10-M0779

Fig. 75 Cleaning the compressed air aftercooler

- ① Compressed air aftercooler
- ② Direction of impacting water or steam jet (from inside to outside).

1. Open both doors.
2. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
3. Clean the aftercooler with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
4. Remove the protective coverings from the air filters.
5. Switch the «battery isolating switch» on again.
6. Close the doors.
7. Start the machine and run up to operating temperature so that excess water is evaporated.

## 10.7 Maintenance of rubber sealing strips

The rubber sealing strips between the body panels and the access doors serve both as a sound-proofing measure and to prevent ingress of rain water.

Care of the rubber sealing strips is especially necessary in winter to prevent the strips from sticking and tearing when the access panels are opened.

Material Cleaning cloth  
Silicone or Vaseline

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.

1. Open all the doors.
2. Clean the rubber sealing strips with a lint-free cloth and check for cracks, holes and other damage.  
Damaged gasket: have gasket replaced.
3. Properly grease the rubber strips.
4. Close the doors.

## 10.8 Chassis

➤ Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.8.1 Wheel checks

Check the wheels and tyres after the first 50 km and after every wheel change, but at least every six months for tightness, visible damage and tyre pressures.

Material Torque wrench  
Tyre pressure gauge

Precondition Machine shut down and secured against restarting.

1. Check that the wheel fixings are tight.
2. Check the tyres and wheels for any defect.  
When damaged or worn: replace tyre/wheel rim.
3. Check the tyre treads for sufficient depth according to local roadworthy regulations (at least 1.6 mm in most countries).
4. Check the tyre pressures.

Further information See chapter 2.4.3 for wheel fixing torques.  
See chapter 2.4.2 for tyre pressures.  
A sticker on each wheel arch provides the recommended tyre pressure.

### 10.8.2 Towbar maintenance

Clean and lubricate all sliding and rotating bearings as necessary but at least every 6 months.

Material Lithium-enriched multi-purpose grease  
Acid-free oil  
Cleaning cloth

Precondition The machine is shut down.  
The machine is disconnected from the towing vehicle and safely parked.



Option sa




Fig. 76 Towbar maintenance

- |                  |                      |
|------------------|----------------------|
| ① Handle         | ③ Lubricating points |
| ② Transfer cable | ④ Lubricating points |

**10.8.2.1 Check the towbar**

1. Check the towbar for correct function and movement.
2. Clean and oil all sliding and rotating bearings.

**Option sa Check the height setting of the towbar**

- Check the towbar height adjustment function.



The locking teeth on the towbar height adjustment joint are corroded and jammed and the towbar height cannot be adjusted.

- If necessary, free the teeth by jerking the towbar horizontally and vertically.
- Clean the toothed coupling and smear with water-repellent grease.

Further information See chapter 6.4.1 for towbar height adjustment.

**Option sa, sd Maintaining the parking brake**

- Lightly lubricate the pins and adjustment joints.

**10.8.2.2 Overrun braking mechanism maintenance**

**Overrun braking mechanism greasing**

- Pump fresh grease into the nipple until old grease is squeezed out.

Further information For greasing points see figure 76.

**Checking the shock absorber**

1. Loosen the transfer cable one side.

2. Press in the shock absorber against its damping force.  
Have the shock absorber replaced by a specialist workshop if:
  - there is little resistance to pushing in,
  - air has entered the device,
  - there is little resistance to pulling out,
  - oil leaks out.

**10.8.2.3 Ball coupling maintenance**

Option sa, sd




Fig. 77 Ball coupling (EC version)

- ① Lubricating points
- ② Lubricating points

Option sh




Fig. 78 Ball coupling (USA version)

- ① Lubricating points
- ② Lubricating points

1. Check the ball coupling for correct function and movement.
2. Clean the ball coupling. Grease or oil the ball cup, joints and bearings.

**10.8.3 Brake system maintenance**

The brake adjusting procedure ensures even wear on the brake linings by adjusting the brake shoes.

The following points must be observed:

- Carry out the adjustment procedure on all wheel brakes, one after the other.
- During adjustment, turn the wheel in the 'forward' direction only.

Material Screwdriver  
Torch  
Lithium-enriched multi-purpose grease


Precondition The machine is switched off.

1. Jack up the machine and lower it onto supports.
2. Release the parking brake and completely pull out the overrun braking mechanism.  
The brake cables are not tensioned.

### 10.8.3.1 Checking the brake system settings

1. Pull up the parking brake to first notch.
2. Turn the wheels in the forward direction.
3. Check that there is the same braking resistance on both wheels.  
Adjust the braking system if the resistance is not the same.
4. Release the parking brake.

### 10.8.3.2 Checking wheel brake lining wear



10-M0160

Fig. 79 Checking the brake lining thickness

- ① Inspection hole
- ② Brake linings

1. Remove the plug from the inspection hole.
2. With the aid of a torch, check the brake lining thickness.  
Have the brake linings replaced by a specialist workshop if they are less than 2 mm thick.
3. Replace the plug in the inspection hole.

### 10.8.3.3 Brake system adjustment

There is an arrow pressed into the brake back plate near the adjustment hole.

- Turning in the direction of the arrow increases brake force.
- Turning in the opposite direction to the arrow releases brake force.




Fig. 80 Brake system adjustment

- |                                 |                            |
|---------------------------------|----------------------------|
| ① Wheel brakes                  | ④ Equaliser                |
| Ⓐ Brake system adjustment       | ⑤ Brake rod tensioning nut |
| ② Screwdriver as adjusting tool | ⑥ Brake rod                |
| ③ Adjusting wheel               | ⑦ Cable tensioning nut     |
| Ⓑ Brake rod adjustment          | ⑧ Brake cable (Bowden)     |

1. Remove the plug from the adjusting hole.
2. Use a screwdriver to turn the adjusting wheel ③ until the wheels no longer turn in the forward direction.
3. Apply the parking brake a number of times to centralize the brake linings.
4. Use the screwdriver to turn the adjusting wheel back (3 to 5 notches) until there is no more braking resistance to the wheels turning forward.
5. Pull on the parking brake.
6. Check the position of the equaliser ④ on the brake rod ⑥.  
If the equaliser is perpendicular to the brake rod, the brake clearance is the same on each wheel.  
If the equaliser is oblique to the brake rod, adjust the brake rod.
7. Pull the parking brake lightly on and compare the braking force on the wheels.  
If the braking force on the wheels is not equal, re-adjust brake system.
8. Replace the plug in the adjustment hole.



A light rubbing sound when the wheels turn is permissible if it does not affect free turning.

**Brake rod adjustment:**

1. To loosen the braking rod ⑥ undo the nut ④ on the equaliser ⑤.
2. Grease the brake rod threads.
3. Adjust the rod so there is no play or tension.  
The equaliser is perpendicular to the brake rod.
4. Tighten the nut.
5. Tighten all counter nuts.
- Test by applying the brake a number of times.

**10.8.3.4 Greasing the brake rods**

Grease the brake rods when necessary (stiff movement) but at least annually.

Material Lithium enriched multi-purpose grease  
Cleaning cloths

Precondition The machine is shut down.  
The machine is disconnected from the towing vehicle and safely parked.

- Clean and grease the brake rods sliding and adjustment joints.

**10.9 Options**


- Carry out maintenance according to the schedule in chapter 10.3.3.2.

**10.9.1 Option da, db, dc, dd  
Cyclone separator maintenance**

Clean the cyclone separator dirt trap if the moisture content in the compressed air is too high.

Material Cleaning cloth  
Wrench  
Small screwdriver  
Dirt trap maintenance kit  
Petroleum ether or spirit

Precondition The machine is shut down.  
Machine is cooled down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.


**Fig. 81** Cleaning the dirt trap

- |                         |                                   |
|-------------------------|-----------------------------------|
| ① Cyclone separator     | ⑥ Strainer                        |
| ② Dirt trap             | ⑦ Condensate drain hose union nut |
| ③ Condensate drain hose | ⑧ Nozzle                          |
| ④ Screw plug            | ⑨ Dirt trap housing               |
| ⑤ O-ring                |                                   |

➤ Open the right-hand access door.

**Cleaning the dirt trap:**

1. Unscrew the plug ④ and remove the strainer.
2. Loosen the union nut ⑦ and detach the condensate drain hose ③ from the dirt trap.
3. Use the small screwdriver to unscrew the nozzle ⑧ from the dirt trap housing.
4. Clean the nozzle, strainer, screw plug, O-ring ⑤ and dirt trap housing ⑨ with cleaning solvent or spirit.
5. Check the nozzle, strainer and O-ring for wear.  
When clearly worn: replace components.
6. Place the strainer on the screw plug.
7. Screw in the plug making sure the O-ring seats properly.
8. Screw in the nozzle and re-attach the condensate drain hose.

**Putting in operation:**

1. Switch the «battery isolating switch» on.
2. Close the door.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
4. Open the outlet valves.
5. Open the right-hand access door.

6. Check the cyclone separator housing and hose line for leaks.
7. Close the door.

### 10.9.2 Option dd Combination filter maintenance

**Precondition** The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.



**WARNING**

Danger of injury from compressed air!  
Filter combination is pressurised during operation. Serious injury can result from loosening or opening components under pressure.

- Make sure there is no electrical power present on the machine. Check: Pressure gauge reads 0 bar!
- De-pressurise the combination filter.

Option dd




Fig. 82 Combination filter maintenance

- |   |  |
|---|--|
| ① Filter combination                          | ⑤ Pressure differential gauge (check fittings for Service personnel) |
| ② Shut-off ball valve for condensate drainage | ⑥ Filter head  |
| ③ Condensate drain hose fittings              | ⑦ Casing gasket  |
| ④ Cyclone separator                           | ⑧ Filter element   |
|   | ⑨ Filter housing   |

- Open the right-hand access doors.

**10.9.2.1 Draining condensate**

Material Receptacle  
Cleaning cloth

1. Place the receptacle under the combination filter hose lines.
2. Open the pre-filter and micro-filter condensate drain shut off valves.
3. Close the door.
4. Switch the machine on and run it in IDLE mode.  
The condensate collecting in the filter housings is blown out.
5. Stop the compressor as soon as air escapes.
6. Open the right-hand access doors.
7. Close the shut-off valve.
8. Close the doors.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

**10.9.2.2 Changing the filter elements**

The pre-filter and micro-filter contain different elements and these must be changed as a pair. Note their positioning!



Do not touch the new filter elements with bare fingers, as this will impair their function!

Using the combination filter without an element installed is not permitted.

Material Spare parts  
Filter wrench  
Wrench  
Cleaning cloth  
Clean fabric gloves

Precondition Machine is cooled down.  
The «battery isolating switch» is off.

**Ensure that the combination filter is not under pressure.**

- Slowly open the pre-filter and micro-filter condensate drain shut off valves.  
Remaining pressure escapes.

**Changing the pre-filter element:**

1. Unscrew and remove the drain hose from the filter housing.
2. Unscrew the filter housing counter-clockwise.
3. Draw the filter element down and out.
4. Clean the filter head, housing and sealing surface with a lint-free cloth.
5. Check the housing gasket.  
Housing gasket is damaged: replace gasket.



6. Insert the new filter element.



Wear gloves!

7. Screw on the filter housing clockwise.
8. Screw on the condensate drain hose.

**Changing the micro-filter element:**

1. Unscrew and remove the drain hose from the filter housing.
2. Unscrew the filter housing counter-clockwise.
3. Draw the filter element down and out.
4. Clean the filter head, housing and sealing surface with a lint-free cloth.
5. Check the housing gasket.  
Housing gasket is damaged: replace gasket.
6. Insert the new filter element.



Wear gloves!

7. Screw on the filter housing clockwise.
8. Screw on the condensate drain hose.

**Putting in operation:**

1. Close the condensate drain shut-off valves.
2. Tighten the filter combination fittings.
3. Activate the «battery isolating switch».
4. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

Further information

Further information on changing elements can be found in the filter instructions in chapter 13.7.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
4. Open the outlet valves.
5. Open the right-hand access doors.
6. Check the combination filter housing and hose lines for leaks.
7. Close the door.

**10.9.3 Option dc  
Fresh air filter maintenance**

Before commencing work on the fresh air filter, read and understand the operating instructions for pressurised air filters (fresh air filters) provided in chapter 13.8.



Using the fresh air filter without installed filter elements is not permitted!

- Precondition**
- The machine is shut down.
  - The machine is standing level.
  - The machine is fully vented, the pressure gauge reads 0 bar.
  - All compressed air consumers are disconnected and the air outlet valves are open.

Option dc




Fig. 83 Fresh air filter maintenance

- |  |   |
|--|---|
| ① Fresh air filter                             | ⑤ Upper element (adsorption element)              |
| ② Lower housing                                | ⑥ Upper housing                                   |
| ③ Lower filter element (high capacity element) | ⑦ Oil indicator                                   |
| ④ Body   | ⑧ Condensate drain (with tap for manual draining) |

- Open the right-hand access door.

**10.9.3.1 Draining condensate**

- Material**
- Receptacle
  - Cleaning cloth

1. Place the receptacle below the fresh air filter condensate drain point.
2. Open the drain tap.
3. Close the door.
4. Switch the machine on and run it in IDLE mode for approx. 2 minutes.  
The condensate collecting in the filter housings must be blown out.
5. Shut down the machine.
6. Open the right-hand access door.
7. Close the drain valve.
8. Carefully remove the receptacle.
9. Close the door.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

**10.9.3.2 Checking the oil indicator**

The fresh air filter is fitted with an oil indicator. When the indicator is blue, the filtration function can no longer be ensured and the filter must not be used. Both filter elements and the indicator must be changed (regardless of the maintenance schedule).

The oil indicator must be checked at least once daily.



The oil indicator does not give information on the filter element changing interval.

1. Check the oil indicator.  
Indicator is blue: Replace both filter elements + oil level indicator.
2. Close the door.

**10.9.3.3 Changing consumable parts**

The fresh air filter contains two different elements which must be changed as a pair. Note their positioning!



Do not touch the new filter elements with bare fingers, as this will impair their function!

Material Spare parts  
Filter wrench  
Wrench  
Cleaning cloth  
Clean fabric gloves

Precondition Machine is cooled down.  
The «battery isolating switch» is off.

**Ensuring the fresh air filter is de-pressurised:**

- Open the fresh air filter drain tap to release any remaining pressure.

**Changing the lower filter element (high performance element):**

1. Unscrew the lower housing anti-clockwise.
2. Draw the filter element down and out.
3. Clean the lower housing and sealing surface with a lint-free cloth.
4. Check the housing gasket.  
Housing gasket is damaged: replace gasket.
5. Insert a new lower filter element.



Wear gloves!

6. Screw on the lower housing clockwise.

**Changing the upper filter element (adsorption insert):**

1. Unscrew the upper housing anti-clockwise.
2. Draw the filter element up and out.

3. Clean the lower housing and sealing surface with a lint-free cloth.
4. Check the housing gasket.  
Housing gasket is damaged: replace gasket.
5. Insert a new filter element.



Wear gloves!

6. Screw on the upper housing clockwise.

**Changing the oil indicator:**

1. Unscrew the oil indicator.
2. Clean the housing and sealing surface with a lint-free cloth.
3. Screw in the new oil indicator.

**Putting in operation:**

1. Close the drain valve.
2. Activate the «battery isolating switch».
3. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

**Further information**

Further information on changing elements can be found in the operating instructions for pressurised air filters (fresh air filters) in chapter 13.8.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar!
4. Open the outlet valves.
5. Open the right-hand access door.
6. Check the fresh air filter housing and hose line for leaks.
7. Close the door.



# 11 Spares, Operating Materials, Service

## 11.1 Note the Nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every enquiry and order for spares.

## 11.2 Ordering consumable parts and operating materials

KAESER consumable parts and operating materials are all genuine KAESER parts. They are selected for use in KAESER machines.



### WARNING

There is risk of personal injury or damage to the machine resulting from the use of unsuitable spare parts or operating materials.

Unsuitable or poor quality consumable parts and operating materials may damage the machine or impair its proper function.

In the event of damage, personal injury may result.

- Use only genuine KAESER spares and operating materials.
- Have an authorized KAESER Service Technician carry out regular maintenance.

### Compressor

Name	Quantity	Number
Air filter element	1	1260
Oil filter	1	1210
Oil separator cartridge set	1	1450
Cooling oil	1	1600

Tab. 85 Compressor consumables

### Deutz engine parts

Name	Quantity	Number
Air filter element	1	1280
Fuel prefilter insert	1	1915
Main fuel filter cartridge	1	1920
Oil filter	1	1905
Oil drain plug sealing ring	1	4496
Injector nozzle	1	4475
Injector sealing ring	1	4476
V-belt	1	4470
Engine oil	1	1925

Tab. 86 Consumable engine parts

## 11.3 KAESER AIR SERVICE

KAESER AIR SERVICE offers:

- Authorized service technicians with KAESER factory training.
  - Increased operational reliability ensured by preventive maintenance.
  - Energy savings achieved by avoidance of pressure losses.
  - The security of genuine KAESER spare parts.
  - Increased legal certainty as all regulations are kept to.
- Why not sign a KAESER AIR SERVICE maintenance agreement.  
The advantages:  
Lower costs and higher compressed air availability.

## 11.4 Service Addresses

Addresses of KAESER agents are given at the end of this manual.

## 12 Decommissioning, Storage and Transport

### 12.1 De-commissioning

De-commissioning is necessary, for example, under the following circumstances:

- The machine is temporarily not needed
- The machine will not be needed for a considerable time.
- The machine is to be scrapped.

Precondition The machine is shut down.

Machine dry and cool.

1. Carry out the following de-commissioning procedures.
2. Place a notice on the instrument panel describing the de-commissioning procedures carried out.

#### 12.1.1 Temporary decommissioning

Decommissioning for about 4 months.

Material Plastic foil

Moisture-resistant adhesive tape

1. Disconnect the battery (the minus terminal first and then the plus terminal).
2. Close off the following openings with plastic foil and moisture-resistant adhesive tape.
  - Engine air inlet
  - Compressor air inlet
  - Exhaust
3. Hang the following notice on the instrument panel informing of the decommissioning measurements taken.

#### Attention!

1. The machine is temporarily decommissioned.
2. The following machine openings have been covered:

- Engine air inlet
- Compressor air inlet
- Exhaust

3. Recommission according to service manual.

Date / signature

Tab. 87 "Temporarily decommissioned" information notice

#### Decommissioning of the compressor for several weeks during severe frost



#### CAUTION

Danger of batteries freezing.

Discharged batteries are subject to frost damage and can freeze at  $-10\text{ °C}$ .

- Store batteries in a frost-free place.
- Store batteries preferably fully charged.



1. Remove the battery (batteries) and store in a frost-free room.
2. Make sure batteries are fully charged.

### 12.1.2 Long-term decommissioning

Decommissioning the machine for 5 months or longer.

Material Receptacle  
 Preserving oil  
 Preservative  
 Desiccant  
 Plastic sheeting  
 Moisture-resistant adhesive tape

- The following measures must be taken for long-term decommissioning.

Long-term decommissioning tasks	See chapter	Confirmed?
➤ Check engine coolant.	10.4.1	
➤ Drain the engine oil.	10.4.6	
➤ Drain the oil from the oil separator tank and the oil cooler.	10.5.3	
➤ Fill the separator tank and engine with preserving oil.	10.5.2 10.4.5	
➤ Run the machine for about 10 minutes to coat all parts with a protective oil film.	–	
➤ Disconnect the battery, the minus terminal first and then the plus terminal, and store in a frost-free room.	–	
➤ Check the battery fluid level.	10.7	
➤ Check the battery charge monthly and recharge if necessary to prevent the battery fluid freezing.	–	
➤ Clean the battery terminals and coat with acid-resistant grease.	–	
➤ Close the compressed air outlet valves.	–	
➤ Use plastic sheeting and moisture-resistant adhesive tape to seal off the following openings: – Engine air intake – Compressor air intake – Exhaust outlet	–	
➤ Clean the bodywork and treat with preservative.	–	
➤ Hang a notice on the instrument panel informing of the decommissioning measurements taken.	–	

Tab. 88 Long-term decommissioning checklist

- Hang the following notice on the instrument panel informing of the decommissioning measurements taken.

**Attention!**

1. The machine is decommissioned.
2. It is filled with preserving oil.
3. For recommissioning:
  - Take measures for recommissioning after a long period of storage.
  - Recommission according to service manual.

Date / signature

Tab. 89 Text for the long-term decommissioned information notice

- Store in a dry place with even temperature.

## 12.2 Transport

Precondition Machine switched off and locked off  
(«battery isolating switch »off)

The machine is fully vented, the pressure gauge reads 0 bar.

Machine is cooled down.

All consumer hoses disconnected, all other lines and hoses disconnected and removed.

Any loose or movable parts that may fall when transporting, removed or secured.

Allow transportation only by personnel trained in safe dealing with motor vehicles and the transporting of goods.

**WARNING**

There is danger of being run over or crushed by an overturning vehicle.

Death or serious injury can result from being crushed or run-over by a machine under tow.

- Riding on the machine while it is under tow is strictly forbidden.

- Make sure the danger area is clear of personnel.

### 12.2.1 Towing the compressor on the road

Machines with appropriate chassis versions and running gear are approved for towing on public roads. The machine is designed for a maximum towing speed of 100 km/h. National and local regulations must be observed when towing the machine on public highways.

- Observe the safety instructions in chapter 3.5.2 "Safe machine operation".

#### 12.2.1.1 Preparing for transport

**Stowing payload:**

Do not exceed the permissible loading (overall weight, coupling load, axle load).

Observe national traffic laws. If additional loading is not permitted, the load must be transported in the towing vehicle.

1. Check that loading the machine with tools or accessories during transport is permissible.
2. Place additional loads only in the spaces provided and secure carefully.

**Additional precautions for a very dirty machine**

The machine can become very dirty after prolonged use on a construction site. A machine in such condition is not suitable for towing on public roads.

1. Clean the machine, particularly the chassis and running gear.
2. Check the function of wheels, brakes, lights and signaling equipment.  
Malfunctions: Correct any defects before towing.

**Additional precautions for conditions of snow and ice**

Considerable snow or ice may build up on the machine under low temperature conditions.

**CAUTION**

Accident hazard due to snow or ice falling off the machine. Snow or ice falling from the towed machine can endanger following vehicles. Problems with driving dynamics and damage to the machine could occur. The maximum permissible axle load could be exceeded.

- Do not tow the machine if it is covered by snow or ice.


- Remove any snow or ice before towing.

**Observe / carry out the following before towing:**

1. Make sure the towing hitch is compatible with the ball or eye coupling on the towed machine.
2. Check that the machine is shut down and secured against accidental restarting.
3. Detach all connecting lines and hoses.
4. Make sure there are no unsecured tools lying on or in the machine.
5. Close and lock the access doors.

**Option sa Adjust the towbar to suit the height of the towing vehicle hitch.**

When the machine is coupled up, the towbar must be parallel with the ground.



12-M0148

Fig. 84 Towing alignment



**WARNING**

Danger from problematic driving dynamics!  
The permissible loading range may be exceeded or undercut.  
Personal injury may result from towing.  
Damage to the machine and/or towing vehicle is possible.

- Do not couple up the machine at an angle to the towing vehicle.
- Ensure that the towbar is horizontal when coupled to the towing vehicle.

- Adjust the towbar height to suit the height of the hitch on the towing vehicle.

Further information See chapter 6.4.1 for towbar height adjustment.

**12.2.1.2 Coupling-up**

**Option sa, sd Ball coupling (EC version):**

To hitch up the machine, lower the open coupling onto the ball of the towing vehicle so that it clicks into place. The coupling is fully locked when the green locking indicator protrudes and is visible from the side.




Fig. 85 Ball coupling (ALKO-EU)

- |                   |                                  |
|-------------------|----------------------------------|
| ① Coupling handle | ③ Towing vehicle ball hitch      |
| ② Ball coupling   | ④ Locking indicator (protruding) |



**CAUTION**

There is considerable danger of injury caused by trapped fingers.  
They can be trapped in the spring-loaded closing mechanism.

- Never place your fingers inside an open ball coupling.
- Always wear protective gloves.

1. Pull up the coupling handle.  
The coupling opens.



**WARNING**

Danger of accident from an incorrectly closed ball coupling.  
If the coupling is not fully closed the compressor can become uncoupled from the towing vehicle and cause an accident.

- Check correct coupling.

2. Place the open coupling over the towing vehicle ball hitch.  
The weight on the coupling will cause it to audibly close. The coupling locks automatically. Closing and locking is automatic.

3. Push the handle down to be certain of locking.  
The coupling is fully locked when the handle is fully down and can be pushed no further.
4. Check correct coupling.
  - Check that the coupling handle cannot be pushed further down.
  - Check that the locking indicator is protruding and visible.



The locking indicator is not visible.

- Lift the handle and uncouple.
- Set the coupling back on the towing vehicle ball hitch and push down.

**Checking the ball coupling wear indicator (EU version):**

The ball coupling is equipped with a wear indicator.

The wear indicator shows:

- Wear on the ball hitch.
- Wear on the coupling.




Fig. 86 Ball coupling wear indicator

- |   |                |   |                                    |
|---|----------------|---|------------------------------------|
| ① | Ball coupling  | + | Green zone (OK)                    |
| ② | Wear indicator | - | Red zone (wear tolerance exceeded) |



**WARNING**

Danger of accident from worn coupling!  
The machine may detach from the towing vehicle.

- Do not tow the machine.
- Have the ball coupling and ball hitch checked.
- Replace worn parts.

1. Couple-up the machine and tow slowly and carefully for about 500 m.  
The action of towing sets the coupling mechanism to maximum closure and gives a true reading on the wear indicator.

2. Interpret the wear indicator as follows:

Wear indicator	Meaning
Green zone showing	<ul style="list-style-type: none"> <li>■ Coupling in new condition.</li> <li>■ Towing vehicle ball hitch wear within acceptable limits.</li> <li>➤ No action necessary.</li> </ul>
Red zone showing	<ul style="list-style-type: none"> <li>■ Ball hitch wear at acceptable limit, ball coupling unworn.</li> <li>■ Ball hitch in new condition; ball coupling showing increased wear.</li> <li>■ Both ball and coupling showing increased wear.</li> <li>■ Ball coupling damaged.</li> <li>➤ Have the ball coupling and ball hitch checked by a specialist workshop.</li> <li>➤ Replace worn parts.</li> </ul>

Tab. 90 Ball coupling wear indicator

**Option sh Ball coupling (USA version):**

To couple up the compressor, lower the open coupling onto the ball hitch of the towing vehicle so that it clicks into place.




Fig. 87 Ball coupling (ALKO-USA)

- |                             |                                  |
|-----------------------------|----------------------------------|
| ① Coupling handle           | ④ Safety pin                     |
| ② Ball coupling             | ⑤ Fixing hole for the safety pin |
| ③ Towing vehicle ball hitch | ⑥ Ball coupling properly secured |



**CAUTION**

There is considerable danger of injury caused by trapped fingers. They can be trapped in the spring-loaded closing mechanism.

- Never place your fingers inside an open ball coupling.
- Always wear protective gloves.

1. Check if the security pin is removed from the coupling and draw it out if not.
2. Pull up the coupling handle.  
The coupling opens.


**WARNING**

Incorrectly coupled machine

If the machine is not correctly coupled and locked it may break away from the towing vehicle and cause an accident.

- Check correct coupling.
- Check correct location of the security pin.

3. Place the open coupling over the towing vehicle ball hitch.  
The weight on the coupling will cause it to audibly close. The coupling locks automatically. Closing and locking is automatic.
4. Push the handle down to be certain of locking.  
The coupling is fully locked when the handle is fully down and can be pushed no further.
5. Insert the security pin in the ball coupling fixing opening.


**12.2.1.3 Tasks to be performed after coupling**


Fig. 88 Release the parking brake.

- |   |  |
|---|--|
| <p>Ⓐ Parking brake with gas spring assistance</p> <p>① Parking brake lever</p> <p>② Dead point zone</p> | <p>Ⓑ Parking brake with ratchet and spring loading</p> <p>③ Brake lever release button</p> |
|---|--|

**Option sa Height-adjustable chassis:**


1. Check that the towbar is adjusted to the correct height. See also chapter 6.4.1.  
Check that:
  - The teeth in the tow bar height adjusting joints are fully engaged
  - The locking levers are tightened
  - The security pin is fully inserted.
2. Wind the jockey wheel to its uppermost position.
3. Check that the wheels are securely fitted and the tyres are in good condition.
4. Check the tyre pressures.
5. Connect the cable for the lighting and indicator systems and carry out a function check.
6. Release the parking brake:  
(see Fig. 88/a).
  - Pull the brake lever a little further on and press the release button.
  - Hold the release button in and push the lever down past the dead point zone.
7. Remove the chocks.

**Option sd Fixed-height chassis (with parking brake):**

1. Wind the jockey wheel to its uppermost position.
2. Check that the wheels are securely fitted and the tyres are in good condition.
3. Check the tyre pressures.
4. Connect the cable for the lighting and indicator systems and carry out a function check.
5. Release the parking brake:  
(see Fig. 88/b).
  - Pull the brake lever a little further on and press the release button.
  - Hold in the release button and push the lever fully down.
6. Remove the chocks.

**Option sh Fixed-height chassis (without parking brake):**

Option sh



12-M0393

Fig. 89 Safety sign - secure the chocks


**WARNING**

Missing chocks

Serious injury or death can result from an unsecured machine rolling away.

- Secure the chocks in the transport securing device before transporting the machine.
- Replace missing chocks immediately.

1. Wind the jockey wheel to its uppermost position.
2. Check that the wheels are securely fitted and the tyres are in good condition.
3. Check the tyre pressures.
4. Attach the lighting and indicator systems and carry out a function check.
5. Remove the chocks and secure them in the transport securing device.



Replacement chocks can be purchased from KAESER representatives. A list is given at the end of this manual. The part number of the chock is 5.1325.0.

**Option sa, sd Ensure emergency braking in the case of breakaway from the towing vehicle:**

If the compressor breaks away from the towing vehicle, the cable tightens and pulls on the emergency brake (parking brake).

It is essential that the breakaway cable is threaded through its guides for correct emergency braking.






Fig. 90 Breakaway cable attachment

- ① Breakaway cable
- ② Breakaway cable guide (eye)
- ③ Connection (snap hook)



**CAUTION**

Unintentional brake application.

If the breakaway cable is too short it can apply the brakes when rounding a curve. This imposes high wear on the braking system.

- Make sure the breakaway cable is long enough.

1. Thread the breakaway cable through the guide welded on the side of the towbar.
2. Loop the end of the cable round the towing vehicle hitch and secure with the snap hook.

12.2.2 Parking the compressor



**CAUTION**

Injury can occur if the towbar is unsupported and allowed to fall.

A falling towbar can cause injury, especially by crushing the feet.

If the jockey wheel is wound up completely, the spindle can disengage and allow the towbar to fall to the ground.

- Do not wind the jockey wheel completely out when the machine is uncoupled from the towing vehicle.




Fig. 91 Injury can occur if the towbar is unsupported and allowed to fall.

**Option sa Height-adjustable chassis:**

When parking on a slope, securely chock the machine before uncoupling.




Fig. 92 Actuating the parking brake

- |   |  |   |   |
|---|--|---|---|
| Ⓐ | Parking brake with gas spring assistance | Ⓑ | Parking brake with ratchet and spring loading |
| ① | Parking brake lever                      | ④ | Ratchet                                       |
| ② | Gas spring                               | ⑤ | Spring loading device                         |
| ③ | Dead point zone                          |   |   |

1. Disconnect the lighting and signaling cable.
2. Pull on the parking brake past the dead point zone (see Fig.92/a).  
The gas spring holds the brake under tension.
3. Detach the breakaway cable.
4. Wind down the jockey wheel.
5. Place chocks under the wheels.
6. Uncouple the compressor from the towing vehicle:
  - Pull up the coupling release lever.
  - Lift the coupling off the towing hitch ball.



The gas spring automatically increases parking brake force if the machine rolls backwards or when parked on a slope.


**Option sd Fixed-height chassis (with parking brake):**

When parking on a slope, securely chock the machine before uncoupling.

1. Disconnect the lighting and signaling cable.
2. Pull on the parking brake to the last ratchet tooth (see Fig. 92/b).  
Hand brake lever is vertical: the brake is spring-loaded.  
Hand brake lever is not vertical: the machine is not secured against rolling.
3. Detach the breakaway cable.
4. Wind down the jockey wheel.
5. Place chocks under the wheels.
6. Uncouple the compressor from the towing vehicle:
  - Pull up the coupling release lever.
  - Lift the coupling off the towing hitch ball.

**Option sh Fixed-height chassis (without parking brake):**

When parking on a slope, securely chock the machine before uncoupling.



12-M0392

Fig. 93 Safety sign - secure the chocks

**WARNING**

Machine without parking brake.

Serious injury or death can result from an unsecured machine rolling away.

- Securely chock the machine before uncoupling.
- As a general rule, the machine should always be blocked with chocks when it is not being moved.
- The machine should not be manoeuvred by hand.

1. Wind down the jockey wheel.
2. Place chocks under the wheels.
3. Dismantle the lighting and signaling system.
4. Uncouple the compressor from the towing vehicle:
  - Withdraw the security pin from the ball coupling.
  - Pull up the coupling release lever.
  - Lift the coupling off the towing hitch ball.
  - Insert the security pin in the ball coupling fixing opening.

### 12.2.3 Transport with a crane

**Additional precautions for conditions of snow and ice**

Considerable snow or ice may build up on the machine under low temperature conditions.

This may adversely effect the machine's centre of gravity.

The permissible load on the crane or lifting eye may be exceeded.

- Additional measures should be taken under conditions of snow or ice.
  - Remove any snow and ice from the machine before lifting by a crane.
  - Make sure the lifting eye cover plate is freely accessible and can be opened.

**Carry out the following tasks before lifting the machine:**

A lifting eye is provided for transporting with a crane. The lifting eye is located beneath a lift-up cover in the centre of the canopy.

1. Unlock the cover from inside and lift up.
2. Position the crane hook vertically over the lifting eye.
3. Engage the hook in the eye.
4. Close and lock the access doors.
5. Lift the machine carefully.

#### Take care when setting down the machine



#### CAUTION

Incorrect setting down can damage the machine.

Machine components, particularly the chassis, can be damaged by incorrectly setting down.

- Set the machine down carefully.
- Do not set down unevenly.

- Set the machine down slowly and carefully.

#### 12.2.4 Option sc Transporting with a forklift truck

Precondition The machine is shut down.

All connecting lines and hoses disconnected and removed.



#### CAUTION

Damage to the machine by incorrect lifting with a fork truck.

The machine may fall or be damaged by the forks.

- Do not use a fork truck to lift towable machines.
- Only stationary machines with skids may be lifted with a fork truck.
- Pick up the machine only from the side with the forks through the lifting lugs.

Option sc




Fig. 94 Transporting using a forklift truck

- ① Skids
- ② Lifting lugs

1. Close and lock the access doors or canopy.
2. Position the fork truck to the side of the machine with the forks lined up with the lifting lugs.
3. Drive the forks fully through the lifting lugs as far as possible.  
The forks are fully under the machine.
4. Lift the machine carefully.

#### 12.2.5 Transporting as a load

The medium of transport determines the type of packing and securing.

Packing and securing methods must be such that, assuming proper handling, the load arrives in perfect condition at the destination.

Consult KAESER Service for advice concerning sea or air transport.

Material Chocks  
Restraints or timber bunks  
Straps

**Load securing devices**



National directives and regulations for securing loads should be followed. Load securing is taken to mean that by full braking or sudden turning the load will not slide, fall, roll or cause unnecessary noise. Accepted technical regulations should be observed (e.g. VDI directive 2700 ff in Germany). Responsibility for properly secured loads falls on the driver, the vehicle keeper and the carrier.

Use chocks, restrainers or timber bunks for securing the load.  
If necessary, use straps across the chassis and the towbar.




Fig. 95 Load secured by strapping



**CAUTION**

Braces can damage the bodywork.  
Movement during transportation can damage the bodywork.

- Do not use straps over the bodywork.
- Use straps only over the chassis.

1. Always observe valid accident and safety regulations when transporting.
2. The loads must be secured against rolling, tipping, slipping and falling.



Contact KAESER Service with any questions regarding transporting or load securing. KAESER accepts no liability for damages arising through incorrect transport methods or insufficient or wrong securing of loads. The transport restraints on rented, hired or exhibition machines should be re-used for the return journey.

**Before shipment as air freight**

The machine is designated as dangerous goods for air freight purposes; any disregard can result in a heavy fine.



**DANGER**

Danger of fire or explosion from operating fluids/materials.  
The machine incorporates an internal combustion engine.

- Any dangerous fluids/materials contained within the machine must be removed before transport.

- Remove all dangerous fluids/materials.

These include:

- Residues of fuel or fuel vapours
- Lubricating and cooling oils in the engine and compressor unit
- Battery electrolyte

## 12.3 Storage

Moisture can lead to corrosion, particularly in the engine, airend and oil separator tank.

Frozen moisture can damage components, valve diaphragms and gaskets.



Advice can be obtained from KAESER on storage and commissioning.



### CAUTION

Moisture and frost can damage the machine.

- Prevent ingress of moisture and formation of condensation.
- Maintain a storage temperature of  $>0$  °C.

- Store the machine in a dry place, free from frost if possible.

## 12.4 Disposal

When disposing of a machine, drain out all liquids and remove old filters.

Precondition The machine is decommissioned.

1. Completely drain the fuel from the machine.
2. Completely drain the cooling oil and engine oil from the machine.
3. Remove used filters and the oil separator cartridge.
4. Drain the coolant from water-cooled engines and systems.
5. Hand the machine over to an authorized disposal expert.



- Parts contaminated with cooling oil or engine oil must be disposed of in accordance with local environment protection regulations.

## 13 Annex

### 13.1 Marking





Fig. 96 Marking

- |   |  |
|---|--|
| ① Machine nameplate with serial number                          | ③ Combined label for coupling loading and built-in options                       |
| ② VIN *) (stamped in the bodywork)<br>* Vehicle identity number | ④ Engine nameplate with serial number (on the cylinder head cover or crankcase). |

### 13.2 Pipeline and instrument flow diagram (P+I diagram)




c	Datum	06.03.2009	Erstellt durch:		FFMM200ST-01015.01	Blatt 1
b	Bearb.	Plau	Ersatz für:			E
a	Ä-Nr.	22255	Ursprung:	FFMM200ST-01015.00		
Änderung	Datum	Name	Norm			
			P&I Diagram		Blatt 1	
			Mobilair		E	
			M 135/M 170/M 200			
			KOMPRESSOREN			
			FFMM200ST-01015.01			



1	2	3	4	5	6	7	8
1	Compressor – Air filter						
2	Filter maintenance indicator, Compressor –Air filter						
3	Inlet valve						
3.2	Pressure transducer – Control pressure						
4	Airend						
5	Oil separator tank						
5.2	Screw plug						
5.13	Pressure transducer – Internal pressure						
6	Oil reserve						
7	Oil separator cartridge						
11	Oil filler with screw plug						
12	Temperature gauge switch + Indication						
13	Pressure relief valve						
14	Pressure gauge Compressed air – Control panel						
15	Diesel engine						
16	Oil return line						
17	Dirt trap						
17.1	Nozzle						
19	Combination valve – Oil temperature controller						
20	Oil cooler						
20.1	Shut-off valve with hose coupling – Oil drain						
21	Oil filter						
23	Electric proportional controller						
24	Motor – Air filter						
25	Filter maintenance indicator, Motor – Air filter						
27	Venting valve						
28	Fan						
29	Exhaust silencer						
30	Coupling						
37	Minimum pressure check valve						
46	Nozzle (Secondary end Proportional controller)						
52	Control valve						
56	Water cooler						
56.1	Cooling water expansion tank						
56.4	Opto-electronic cooling water level sensor						
56.5	Cooling water sight glass (M 200)						
56.7	Shut-off valve with hose coupling – Water drain						
56.10	Water filling port with plug and pressure relief valve						
63	Control valve (Air circulation valve)						
83.1	Engine air intake shut-off valve (automatic and manual shutoff)						
84	Spark arrester						
	Option						
hc	Minimum pressure check valve (without combination filter)						
la	Spark arrester						
lb	Spark arrester + Engine air intake shut-off valve (automatic and manual shutoff)						

		P&I Diagram legend Mobilair M 135/M 170/M 200		Blatt 2 E
Ursprung: FFM200ST-01015.00		Ersatz für:		FFM200ST-01015.01
Datum: 06.03.2009	Bearb.: Piau	Ersatz durch:		
Gepr.: Grimm	Norm:	Name:		
Änderung:	Datum:	Name:		




Date: 06.10.2008		P&I Diagram	
Revised: Holtau	Mobilair M 135/M 170/M 200		
Drawn: Plau	Compressed air outlet-options		
Change	Name	Norm	FFMM200DL AO-01016.00
Revised by:	Revised by:	Revised by:	Blatt 1
Revised by:	Revised by:	Revised by:	E

1	2	3	4	5	6	7	8
	<p>10 Compressed air distributor</p> <p>32 Air cooler</p> <p>33 Centrifugal separator</p> <p>33.1 Dirt trap</p> <p>33.2 Nozzle</p> <p>34 Heat exchanger</p> <p>34.4 Screw plug – Oil drain</p> <p>35 Breathing air filter</p> <p>35.1 Hose coupling</p> <p>35.2 Nozzle</p> <p>36 Filter combination</p> <p>36.1 Shut-off valve for condensate drain</p>	<p>37 Minimum pressure check valve</p> <p>39 Check valve</p> <p>57 Shut-off valve - Venting line</p> <p>Option</p> <p>da Aftercooler + Centrifugal separator</p> <p>db Heat exchanger</p> <p>dc Breathing air filter</p> <p>dd Filter combination</p> <p>fa Direct air flow</p> <p>hd Minimum pressure check valve (with combination filter)</p>					
c	Datum: 06.10.2008			P&I Diagram legend			
b	Rearb. Plan			Mobilair M 135/M 170/M 200			
a	Gepr. Hellauer			Compressed air outlet-options			
Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	FFMM200DL AO-01016.00	
						Blatt 2 E	

**13.3 Dimensional drawings****13.3.1 Option sa****Dimensional drawing, chassis with height-adjustable tow bar**



\* towing eye allowance

DIN	0 mm
Nato	-43 mm
France	-57 mm
ULPIO	-29.5 mm
ball coupling	-40 mm



\*\* towing eye allowance

DIN	0 mm
Nato	-13 mm
France	-31 mm
ULPIO	-26 mm
ball coupling	-54 mm



**KAESER**  
KOMPRESSOREN  
T 11067 E  
1013751L-02

Portable compressor  
M 135 / M 170

2009	Top	Name	Gisela Fösel
2907	Rev.		
2907	Rev.		
120	auf A 2	Revised	


The drawing remains the property of KAESER. It is not to be used for other purposes without the written consent of KAESER. KAESER is not responsible for any damage or injury resulting from the use of the drawing. The drawing is not to be used for the design of other machines or components. The drawing is not to be used for the design of other machines or components. The drawing is not to be used for the design of other machines or components.

13.3.2 Option sd  
Dimensional drawing, chassis with fixed height tow bar

Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck amtrahnt und darf zu keinem anderen Zweck verwendet werden. Kopien oder sonstige Verwertungen einschließlich Speicherung, Verbreitung oder Verbreitung unter Verletzung der Vertriebsbedingungen sind ohne unsere schriftliche Genehmigung ausdrücklich untersagt. Änderungen vorbehalten. Zeichnung darf nur über CAD geändert werden.  
Entwicklungsbedingte Änderungen vorbehalten.  
Service Manual Screw Compressor

\* towing eye allowance


DIN	0 mm
Nato	-65 mm
France	-115 mm
ULP/O	-65 mm
ball coupling	-85 mm




\*\* towing eye allowance

DIN	0 mm
Nato	-65 mm
France	-90 mm
ULP/O	-60 mm
ball coupling	-92 mm

View X



Optional pedestrian protectors





2008	Top	Name	Portable compressor	Kaeser KOMPRESSOREN T 11140 E 10147783_01
Rev.	0312	Gisela Fösel	M 135/ M 170 with UK chassis	
Empf.	0312	Gisela Fösel	T 11140 E	
Beschreib.		120 auf A 2	Entwurf für T 11140 vom 14.11.2008	




**13.3.3 Option sh**  
**Dimensional drawing, chassis without parking brake**



\* towing eye allowance  
DIN 0 mm  
Nato -95 mm  
France -115 mm  
ULPIO -65 mm  
ball coupling -85 mm








\*\* towing eye allowance  
DIN 0 mm  
Nato -65 mm  
France -90 mm  
ULPIO -60 mm  
ball coupling -92 mm



2008	Top	Name	Portable compressor M 135/ M 170 with UK chassis
Rev.	04.12.	Gisela Fösel	M 135/ M 170 with UK chassis
Drawn	04.12.	Gisela Fösel	T 11141 E
Checked	120	aut. A 2	014697/5_01

Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck anvertraut und darf zu keinem anderen Zweck verwendet werden. Kopia oder sonstige Verwertungen einschließlich Speicherung, Verbreitung oder Verbreitung unter Verwendung elektronischer Systeme dürfen nur zu dem vereinbarten Zweck angeteilt werden. Weiter Original noch vervielfältigungen dürfen Dritten ausgedrückt oder in sonstiger Weise zugänglich gemacht werden. Entwiklungsbedingte Änderungen vorbehalten. Zeichnung darf nur über CAD geändert werden.

13.3.4 Option sc  
Dimensional drawings of stationary machine (skids)







Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck anvertraut und darf zu keinem anderen Zweck verwendet werden. Kopien oder sonstige Vervielfältigungen einschließlich Speicherung, Verbreitung oder Verbreitung unter Verwendung elektronischer Systeme dürfen nur zu dem vereinbarten Zweck angeteilt werden. Weder Original noch Vervielfältigungen dürfen Dritten ausgedrückt oder in sonstiger Weise zugänglich gemacht werden. Entwicklungsbedingte Änderungen vorbehalten. Zeichnung darf nur über CAD geändert werden.

2008	Top	Name	Gisela Fösel
Bez.	10.11.	Gepr.	18.11.
Mischstab 120 auf A2		Formst.	T 11143 E
		Arbeitsn.	1044678_00

Stationary compressor  
M 135 / M 170 on skids


**13.3.5 Option si**  
**Dimensional drawings of stationary machine (base frame)**




A Choice of rubber pads or machine mountings.  
Add 50mm if fitted with rubber pads.  
Anchor the machine only with machine mountings.

M 1:10

EINZELHEIT A



View X



Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck anvertraut und darf zu keinem anderen Zweck verwendet werden. Kopien oder sonstige Vervielfältigungen einschließlich Speicherung, Verbreitung oder Verbreitung unter Verwendung elektrischer Systeme dürfen nur zu dem vereinbarten Zweck angefertigt werden. Weder Original noch Vervielfältigungen dürfen Dritten ausleihend oder in sonstiger Weise zugänglich gemacht werden. Entwicklungsbedingte Änderungen vorbehalten. Zeichnung darf nur über CAD geändert werden.

2008		Name		Stationary compressor M 135 / M 170	Kaeser T11142 E 10446977_00
Rev.	2011	Gisela Fösel			
Ersp.	2011	Gisela Fösel			
ModStat	120 auf A2	Erstellt für			

13.4 Wiring diagrams

13.4.1 Electrical Diagram

1	2	3	4	5	6	7	8	
<div style="border: 1px solid black; padding: 20px; margin: 0 auto; width: 80%;"> <p>Electrical diagrams</p> <p>MOBILAIR M123/M135/M170</p> <p>DEUTZ TCD Motor with EMR III</p> <p>and SIGMA CONTROL MOBIL</p> </div> <p style="text-align: center; margin-top: 20px;"> <b>Manufacturer: Kaeser Kompressoren GmbH</b>                  Postfach 2143                  96410 Coburg             </p>								
<p>The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>								
c		Datum	07.01.2009	E	Cover page			=
b		Bearb.	Weid		MOBILAIR M123/M135/M170			+
a	Label GEN	27.02.09	Weid	Gepp.				
A	Änderung	Datum		Name	Norm	Ersatz durch:		DFA123.SCM-01230.02
								Blatt 1
								Bl.


Lfd. Nr. No.	Benennung Name	Zeichnungsnummer (Kunde) Drawing No. (customer)	Zeichnungsnummer (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DFA123.SCM-01230.02	1	
2	List of contents		ZFA123.SCM-01230.02	1	
3	Block diagram	general instructions	UFA123.SCM-01230.02	1	
4	Block diagram	cabling	UFA123.SCM-01230.02	2	
5	Circuit diagram	Diesel motor	SFA123.SCM-01230.02	1	
6	Circuit diagram	EMR3 Motor connection	SFA123.SCM-01230.02	2	
7	Circuit diagram	EMR3	SFA123.SCM-01230.02	3	
8	Circuit diagram	Control panel	SFA123.SCM-01230.02	4	
9	Circuit diagram	SCM Power supply unit	SFA123.SCM-01230.02	5	
10	Circuit diagram	SCM sensors	SFA123.SCM-01230.02	6	
11	Circuit diagram	SCM inputs	SFA123.SCM-01230.02	7	
12	Circuit diagram	SCM inputs	SFA123.SCM-01230.02	8	
13	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	9	
14	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	10	
15	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	11	
16	Circuit diagram	Volt-free contacts	SFA123.SCM-01230.02	12	
17	Electrical equipment identification		SFA123.SCM-01230.02	20	
18	Equipment parts list	control cabinet	GFA123.SCM-01230.02	1	
19	Terminal schedule	standard	KFA123.SCM-01230.02	1	
20	Terminal schedule	standard	KFA123.SCM-01230.02	2	
21	Terminal schedule	Automatic-start-stop	KFA123.SCM-01230.02	3	
22	Component layout	standard	AFA123.SCM-01230.02	1	
23	Component layout	Automatic-start-stop	AFA123.SCM-01230.02	2	


  

c	Datum	07.01.2009	List of contents		=
b	Bearb.	Weid	MOBILAIR SCM & EMR III		+
a	Gepr.	Weid	KOMPRESSOREN		
B	Änderung	Datum	List of contents		
			MOBILAIR SCM & EMR III		
			KOMPRESSOREN		
			Ursprung: afa0123_01		
			Ersatz für:		
			Ersatz durch:		
			ZFA123.SCM-01230.02		
			Blatt 1		
			Bl.		




1	2	3	4	5	6	7	8	
<p><b>general instructions</b></p> <p>Control voltage: 24VDC</p> <p>control cabinet wiring for non-designated conductors</p> <p>primary circuits:          Control voltage DC: black          1,5mm<sup>2</sup> H05V2-K/UL/CSA blue          external voltage: 1,5mm<sup>2</sup> H07V2-K/UL/CSA orange          measuring circuits: 1,0mm<sup>2</sup> H05V2-K/UL/CSA violet          earth conductor: green/yellow</p> <hr style="border-top: 1px dashed black;"/> <p>wiring colors:</p> <p>bl = blue          bn = brown          ge = yellow          gn = green          gnge = green-yellow          gr = grey          or = orange          rs = pink          rf = red          sw = black          vi = violet          ws = white</p>								
c	Datum	07.01.2009	Kaeser		Block diagram			=
b	Bearb.	Weid	KOMPRESSOREN		MOBILAIR SCM & EMRIII			+
a	Gepr.	Weid	Urprung:		general instructions			
c	Änderung	Datum	Ersatz für:		UFA123.SCM-01230.02			Blatt 1
		Ersatz durch:						Bl.








Service Manual Screw Compressor  
M170 SIGMA CONTROL MOBIL




Function: activation		Cable loom Motor	
Function: glow relay		Control electronics Diesel motor	
Group of functions:			
c	Datum	07.01.2009	=
b	Bearb.	Weid	+
a	Gepr.	Weid	
D	Änderung	Datum	Name
	Ersatz durch:	Ersatz durch:	Norm
			Ursprung: afa0123_01
			KAESER KOMPRESSOREN
			Circuit diagram
			MOBILAIR SCM & EMRIII
			EMR3 Motor connection
			SFA123.SCM-01230.02
			Blatt 2
			Bl.







Function: fusing Power supply unit		CAN interface		RS232 interface		option GSM Modem	
Function: Power supply unit - interface		Circuit diagram		MOBILAIR SCM & EMR III		SFA123.SCM-01230.02	
Group of functions: KAESER KOMPRESSOREN		Urprung: afa023_01		Ersatz für:		Blatt 5	
Date: 07.01.2009		Bearb. Weid		Gepr. Weid		Norm	
a) Datum		Name		Ersatz durch:		Bl.	




Function:  
Function:  
Group of functions:


analog signal  
fuel level


analog inputs - sensors		Circuit diagram		=	
KAESER KOMPRESSOREN		MOBILAIR SCM & EMRIII		+	
SCM sensors		SCM sensors		SFA123.SCM-01230.02	
Date: 07.01.2009		Ersatz durch:		Blatt 6	
Bearb.: Weid		Ersatz durch:		Bl.	
Gepr.: Weid		Ersatz durch:			
Datum		Ersatz durch:			
Name		Ersatz durch:			
Norm		Ersatz durch:			
Ursprung: afa0123_01		Ersatz durch:			







Service Manual Screw Compressor  
M170 SIGMA CONTROL MOBIL








Function: option: Relay switching on EMR		quick stop		Motor START outputs		option fuel pump	
Function: Valve defroster							
Group of functions:							
c	Datum	07.01.2009		Circuit diagram			
b	Bearb.	Weid		MOBILAIR SCM & EMRIII			
a	Gepr.	Weid		SCM outputs			
D	Änderung	Datum	Name	Ersatz durch:		SFA123.SCM-01230.02	
				Ersatz durch:		Blatt 10	
				Ersatz durch:		Bl.	





1	2	3	4	5	6	7	8
-A1	Control board SIGMA CONTROL MOBIL						
-A11	Operating unit SIGMA CONTROL MOBIL						
-A20	Control board EMR 3						
-B6	sensor airtend temperature						
-B8	sensor coolant level						
-B9	sensor fuel level						
-B10	Pressure transducer system pressure						
-B11	Pressure transducer package internal pressure						
-B78	Filter maintenance indication fuel						
-F3	Fuse preheat attachment						
-F5,-F6,-F7, -F10,-F11,-F12	Fuse						
-G2	Alternator						
-G10,-G11	Battery						
-K3	Relay Starter						
-K26	glow relay						
-K20,-K21	Relay						
-M2	Starter						
-P9	Display fuel level						
-R1.1,-R1.2,-R1.3, -R1.4,-R1.5,-R1.6	preheat attachment						
-R10,-R11	Resistor						
-S0	Battery isolating switch						
-S01	Control voltage ON/OFF switch						
-S41	quick stop pushbutton						
-V10	LOAD-DUMP-Modul 24 VDC						
-X1	Terminal strip						
-X17	Connector plug Motor						
-X18	Plug connection Starter Relay						
-X22	diagnostics plug						
-X23	Plug connection glow relay						
-X100,-X101	diagnosis-Plug PLC/HMI						
<b>components</b>							
<b>according to machine model / Type</b>							
-B50,-B51	Pressure switch filter clogging						
-K5,-K6,-K9, -K14,-K15,-K18	Relay Volt-free contacts						
-Y2	Valve Venting						
-Y3	Valve Full load operation						
-Y9	Control valve Inlet valve						
-Y10	Valve defroster						
-X2	Terminal strip Volt-free contacts						
-X4	Terminal strip Generator control box						
<b>Electrical equipment identification</b>							
<b>MOBILAIR SCM &amp; EMR11</b>							
<b>KAESER</b> KOMPRESSOREN				=			
Urprung:				+			
Ersatz durch:				SFA123.SCM-01230.02			
Ersatz für:				Blatt 20			
Datum				Bl.			
Bearb. Weid				Bl.			
Gepr. Weid				Bl.			
Name Norm				Bl.			
Datum				Bl.			

1	2	3	4	5	6	7	8
A Stückzahl Qty.	B Benennung und Verwendung Description and function	C Fabrikatsbezeichnung Typ: notwendige techn. Daten (z.B. Steuerspannung, Frequenz, Einstellbereich); Bestell-Nr.; Hersteller Identification data Type: basic technical data (e.g. control voltage, frequency, adjustable range); order No.; manufacturer	D Lfd. Nr. Item	E Betriebsmittel-Kennz. nach DIN 40719, Teil 2 Identifying symbol of device	F Stromlaufplan Planabschnitt Circuit diagram sheet No.; section No.	G Einbauort Location	Concerns only the manufacturer Wst.-Nr. H Schabl. Nr. I BZ-Pos. J VA Kz. *) K Eingangsvermerk
	control cabinet kpl.:						
1	Control cabinet	400x300x155 Rittal					
1	Control	CR0020 ifm		-A1			
1	LOAD-DUMP-Modul	EC2016 ifm		-V10			
3	Relay	24 VDC/1W Wehrle		-K3, -K20, -K21			
3	Relay socket	10 485 008 Wehrle		-K3, -K20, -K21			
22	Terminal	WK2.5D2/2/35 Wieland		-X1			
21	tiered terminals	WK1.5E/35 Wieland		-X1			
2	Terminal	WK4/35 Wieland		-X1			
6	Fuse terminal	ST4-FS/C Phönix		-X1			
2	Fuse UNIVAL	25 A 7.64.11.00070 L&K		-F4, -F5			
2	Fuse UNIVAL	15 A 7.64.11.00060 L&K		-F11, -F12			
2	Fuse UNIVAL	7.5 A 7.64.11.00100 L&K		-F6, -F7			
1	Fuse UNIVAL	1 A 7.64.11.00110 L&K		-F10			
2	Resistor	120 Ω 7.5392.00030 Bürklin		-R10, -R11			
<b>Control panel</b>							
1	Operating unit	CR9022 ifm		-A11			
1	Display fuel level	8.64.76.0 VDO		-P9			
1	switch Control voltage ON/OFF	26 00 00 24VDC / 7.5A 8.7045.0 Merit		-S01			
1	quick stop pushbutton	QRUV-MHT00 Schlegel		-S41			
<b>general components</b>							
1	Battery isolating switch	24 V/500 A 7.5788.00030 Hella Marine		-S0			
1	Control board EMR3	Equipment supplied by the user Motor DEUTZ		-A20			
1	glow relay	Equipment supplied by the user Motor DEUTZ		-K26			
<b>model-dependent components</b>							
6	Coupling relay	DC 24 V 1W 7.54.95.00010 OMRON		-K5, -K6, -K9, -K14, -K15, -K18			
6	tiered terminals	WK1.5E/35 Wieland		-X2			

\*) Versandanschrift - Kennzeichen

Bei Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten Spalten B und C angegebenen Daten anzugeben. Die Daten in den Spalten D bis G sind zusätzlich unter Nennung dieser Gerätestück-Nr. anzugeben, soweit sie die Beantwortung technischer Rückfragen erleichtern. Für Ersatzbestellung ist zusätzlich die Angabe der Seriennummer erforderlich, falls diese auf dem Typenschild des Erzeugnisses genannt ist.  
In Zweifelsfällen gilt die deutsche Fassung.  
When reordering the equipment, all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D to G should be given together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, also quote the serial No. of the product if stated on the rating plate.  
The German version applies in cases of doubt.







Cable identification		Terminal strip: -X1 total 80 terminals		Terminal schedule Terminal strip →X1 standard										Ersatz für: KFA123.SCM-01230.02		Blatt 2 Bl
-W4.4 FLY-B 55x1,0mm <sup>2</sup> -W4.3 Oelflex 110 7x1,0mm <sup>2</sup>				1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86												
Cable identification		Terminal strip: -X1 total 80 terminals		Terminal schedule Terminal strip →X1 standard										Ersatz für: KFA123.SCM-01230.02		Blatt 2 Bl
Destination	external	Destination	external													
Connection number		Connection number														
Component identification		Component identification														
Location		Location														
Wire link		Wire link														
Terminal legend		Terminal legend														
Link		Link														
Terminal number		Terminal number														
Motor connection 2,5/4 mm <sup>2</sup>		Motor connection 2,5/4 mm <sup>2</sup>														
-W3 Oelflex 110 2x1,5mm <sup>2</sup>		-W3 Oelflex 110 2x1,5mm <sup>2</sup>														
-W9 Oelflex 110 7x1,0mm <sup>2</sup>		-W9 Oelflex 110 7x1,0mm <sup>2</sup>														
-W11 PUR 5x0,34mm <sup>2</sup>		-W11 PUR 5x0,34mm <sup>2</sup>														
-W12 Oelflex 110 12x1,0mm <sup>2</sup>		-W12 Oelflex 110 12x1,0mm <sup>2</sup>														
-W18 Oelflex 110 4x0,75mm <sup>2</sup>		-W18 Oelflex 110 4x0,75mm <sup>2</sup>														
-W19 Oelflex 110 4x0,75mm <sup>2</sup>		-W19 Oelflex 110 4x0,75mm <sup>2</sup>														
-W31 Oelflex 110 3x0,75mm <sup>2</sup>		-W31 Oelflex 110 3x0,75mm <sup>2</sup>														
-W32 Oelflex 110 2x1,5mm <sup>2</sup>		-W32 Oelflex 110 2x1,5mm <sup>2</sup>														
-W33 Oelflex 110 3x0,75mm <sup>2</sup>		-W33 Oelflex 110 3x0,75mm <sup>2</sup>														
-W39 Oelflex 110 3x0,75mm <sup>2</sup>		-W39 Oelflex 110 3x0,75mm <sup>2</sup>														
-W4.2 cores 1,5/0,25mm <sup>2</sup>		-W4.2 cores 1,5/0,25mm <sup>2</sup>														
-W106 Oelflex 110 4x0,75mm <sup>2</sup>		-W106 Oelflex 110 4x0,75mm <sup>2</sup>														

1) model-dependent components

Cable identification			Terminal strip - X2				Cable identification			Terminal schedule								
Destination		Internal	Terminal strip		Terminal strip - X2		Destination		Terminal strip - X2		Automatic-start-stop							
external	Component identification	Connection number	Terminal number	Terminal legend	Wire link	Location	Component identification	Connection number	Component identification	Connection number	Terminal number	Component identification						
			1.1	a	•	/12.2	-K6	21			1.2							
			2.1	b		/12.2	-K6	22			2.2							
			3.1	a	•	/12.3	-K14	21			3.2							
			4.1	b		/12.3	-K14	22			4.2							
			5.1	a	•	/12.4	-K15	11			5.2							
			6.1	b		/12.4	-K15	12			6.2							
			7.1	a	•	/12.5	-K18	11			7.2							
			8.1	b		/12.5	-K18	12			8.2							
			9.1	a	•	/12.7	-K5	11			9.2							
			10.1	b		/12.7	-K5	12			10.2							
			11.1	a	•	/12.8	-K9	11			11.2							
			12.1	b		/12.8	-K9	14			12.2							
Total 24 Terminals																		
Destination		external	Component identification		Connection number		Terminal number		Terminal legend		Wire link		Location		Component identification		Connection number	




c	Datum	07.01.2009	Component layout		=	AFA123.SCM-01230.02	Blatt 1
b	Beerb.	Weid	Mounting plate		+		
a	Gepr.	Weid	standard				
	Änderung	Datum	Name	Norm	Ersatz durch:	Ursprung: afa0123_01	




13.4.2 Option tc  
Lighting and signalling system connection

1	2	3	4	5	6	7	8	
<div style="border: 1px solid black; padding: 20px; margin: 0 auto; width: 80%;"> <p>Electrical diagrams                  MOBILAIR                  Lighting equipment                  connection 12V / 13-pole</p> </div> <p style="text-align: center; margin-top: 20px;">                 Manufacturer: Kaeser Kompressoren GmbH                  Postfach 2143                  96410 Coburg             </p>								
<p>The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>								
c	Datum	17.10.2007	E	KAESER KOMPRESSOREN <small>Ursprung: AFA02002_00</small>				Cover page MOBILAIR Lighting equipment
b	Bearb.	Weid						=
a	Gepr.	Weid						+
D	Änderung	Datum	Name	Norm	Ersatz durch:		Ersatz für:	
							DFAEUR.BEL-02003.00	
								Blatt 1
								BL




Function:		Circuit diagram	
Group of functions:		Lighting equipment	
		Cable loom	
Kaeser logo		UFAEUR.BEL-02003.00	
KOMPRESSOREN		UFAEUR.BEL-02003.00	
Urprung: AFA0202_00		Blatt 1	
Ersatz durch:		Ersatz für:	
Datum: 17.10.2007		Bl.	
Bearb. Weid			
Gepr. Weid			
Name: Norm			
Datum			
Änderung			






Function:		Circuit diagram	
Group of functions:		MOBILAIR	
		Lighting equipment	
Kaeser logo		SFAEUR.BEL-02003.00	
KOMPRESSOREN		=	
Ursp.ung: AFA02002_00		+	
Ersatz durch:		Blatt 1	
Ersatz für:		BL	
Datum: 17.10.2007			
Bearb.: Weid			
Gepr.: Weid			
Name:			
Datum:			
Norm:			



Function:		Group of functions:		Circuit diagram		=		-		Blatt 2	
c		Datum	17.10.2007	KAESER KOMPRESSOREN		MOBILAIR		SFAEUR.BEL-02003.00		BL.	
b		Bearb.	Weid	KOMPRESSOREN		Lighting equipment					
a		Gepr.	Weid	Ursp.:		AFAD2002_00					
D	Aenderung	Datum	Name	Ersatz durch:		Ersatz für:					

**13.4.3 Option te  
Lighting and signalling system connection**

1	2	3	4	5	6	7	8
<div style="border: 1px solid black; padding: 10px; margin: 0 auto; width: 80%;"> <p style="font-size: 1.2em; margin: 0;">Electrical diagrams</p> <p style="font-size: 1.2em; margin: 0;">MOBILAIR</p> <p style="font-size: 1.2em; margin: 0;">DOT-Lighting equipment</p> </div> <p style="margin-top: 20px; text-align: center;"> <b>Manufacturer: Kaeser Kompressoren GmbH</b>                  Postfach 2143                  96410 Coburg             </p>							
<p style="font-size: 0.8em;">The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>							
c) Datum		10.08.1999		E			
b) Bearb.		Reup					
a) Gepr.		Schmidt					
D) Änderung		Datum		Name		Norm	
		Ersatz durch:		Ersatz für:		Ursprung:	
KAESER KOMPRESSOREN				Cover page MOBILAIR DOT-Lighting equipment			
				8.6514.0		DFAUSA.BEL-00909.00	
				=		+	
				Blatt 1		Bl.	



1 2 3 4 5 6 7 8

c	Datum	10.08.1999	Ersatz durch:	Ersatz für:	Urprung:	KAESER KOMPRESSOREN	Circuit diagram MOBILAIR DOT-Lighting equipment	8.6514.0	SFAUSA.BEL-00909.00	=	+	Blatt 1
	Bearb.	Reuß										
b	Gepr.	Schmidt										
a	Name											
D	Datum											

13.4.4 Option od  
Battery charger electrical diagrams

1	2	3	4	5	6	7	8	
<div style="border: 1px solid black; padding: 10px; margin: 10px auto; width: 80%;"> <p>Electrical diagrams</p> <p>Battery charger 12/24 VDC</p> <p>Power supply:</p> <p>400 V / 3~/N/PE/50 Hz</p> <p>230 V / 1~/N/PE/50 Hz</p> </div> <p style="text-align: center; margin-top: 20px;">                 Manufacturer: Kaeser Kompressoren GmbH                  Postfach 2143                  96410 Coburg             </p>								
<p>The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>								
c	Datum	18.05.2009	E	KAESER KOMPRESSOREN Ursprung: AFA0122_00				Cover page MOBILAIR Battery charger
b	Bearb.	Weid						=
a	Gepr.	Weid						+
A	Anderung	Datum	Name	Norm	Ersatz durch:		DFABLG-01225.00	Blatt 1
								Bl.

Lfd. Nr. No.	Benennung Name	Zeichnungsnummer (Kunde) Drawing No. (customer)	Zeichnungsnummer (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DFABLG-01225.00	1	
2	List of contents		ZFABLG-01225.00	1	
3	Block diagram		UFABLG-01225.00	1	
4	Block diagram		UFABLG-01225.00	2	
5	Circuit diagram		SFABLG-01225.00	1	
6	Circuit diagram		SFABLG-01225.00	2	
7	Terminal schedule		KFABLG-01225.00	1	
8	Component layout		AFABLG-01225.00	1	
9	Component layout		AFABLG-01225.00	2	


  

List of contents		MOBILAIR Battery charger	ZFABLG-01225.00	Blatt 1
KAESER KOMPRESSOREN	Ursp. Nr.: AFA0122_00			
18.05.2009	Ersatz durch:	Ersatz für:		
Beerb. Weid				
Gepp. Weid				
Name				
Datum				




1	2	3	4	5	6	7	8
<p><b>general instructions</b></p> <p>ATTENTION !!!</p> <p>Install supplies, grounding and shock protection to local safety regulations.</p> <p>Control circuits are single-end-earthed, if they are floating they may only be used together with insulation monitoring.</p> <p>Do not make or break live plug-in connectors.</p>							
<p>control cabinet wiring for non-designated conductors with multi-standard stranded conductors</p> <p>primary circuits: black</p> <p>Control voltage AC: red 1mm<sup>2</sup> H07V-K, 18AWG UL-Style 1015, CSA-TEW</p> <p>Control voltage DC: blue 1mm<sup>2</sup> H07V-K, 18AWG UL-Style 1015, CSA-TEW</p> <p>external voltage: orange 1,5mm<sup>2</sup> H07V-K, 16AWG UL-Style 1015, CSA-TEW</p> <p>measuring circuits: violet 1mm<sup>2</sup> H07V-K, 18AWG UL-Style 1015, CSA-TEW</p> <p>earth conductor: green/yellow</p>							
<p>Block diagram</p> <p>general instructions</p>							
<p><b>KAESER</b> KOMPRESSOREN</p> <p>Ursprung: AFA0122_00</p>							
<p>Ersatz durch: Ersatz für:</p>							
<p>Datum: 18.05.2009</p>							
<p>Bearb. Weid</p>							
<p>Gepr. Weid</p>							
<p>Name Norm</p>							
<p>Datum</p>							
<p>Ersatz durch: Ersatz für:</p>							
<p>=</p>							
<p>+</p>							
<p>UFABLG-01225.00</p>							
<p>Blatt 1</p>							
<p>Bl.</p>							

model		Equipment parts list Battery charger			
Power supply		230 V ±10 %, 50 Hz	400 V ±10 %, 50 Hz	230 V ±10 %, 50 Hz	400 V ±10 %, 50 Hz
Voltage Battery		12 VDC	12 VDC	24 VDC	24 VDC
<b>Control cabinet</b>					
Battery charger	-N2 Eltroma	7.9117.00010 BGL 1024 / 12V	7.9117.00010 BGL 1024 / 12V	7.9117.0 BGL 1024 / 24V	7.9117.0 BGL 1024 / 24V
Overload protection switch	-Q1 Siemens	7.6860.00170 3RV1011-1GA10 (4,5-6,3A) setting: 6A	7.6860.00170 3RV1011-1GA10 (4,5-6,3A) setting: 4,5A	7.6860.00170 3RV1011-1GA10 (4,5-6,3A) setting: 6A	7.6860.00170 3RV1011-1GA10 (4,5-6,3A) setting: 4,5A
Auxiliary switch	Siemens	7.3140.02210 3RV1901-1A	7.3140.02210 3RV1901-1A	7.3140.02210 3RV1901-1A	7.3140.02210 3RV1901-1A
Cut-out	-F12	7.3140.02750 5SY6106-7 C16 A 16 A	7.3140.02750 5SY6106-7 C16 A 16 A	7.3140.02750 5SY6106-7 C16 A 16 A	7.3140.02750 5SY6106-7 C16 A 16 A
voltmeter	-P11 VDO	7.9033.00010 332-030-001G 8-16 VDC	7.9033.00010 332-030-001G 8-16 VDC	7.9033.0 332-040-001G 16-32 VDC	7.9033.0 332-040-001G 16-32 VDC
Ammeter	-P12 VDO	7.9118.0 190-037-001G -30...0...+30 A	7.9118.0 190-037-001G -30...0...+30 A	7.9118.0 190-037-001G -30...0...+30 A	7.9118.0 190-037-001G -30...0...+30 A
front plate 6TE	Mennekes	7.5390.00020 40986	7.5390.00020 40986	7.5390.00020 40986	7.5390.00020 40986
Attachment piece 6TE	Mennekes	7.5395.00020 41431	7.5395.00020 41431	7.5395.00020 41431	7.5395.00020 41431
Terminal	-X10,-X12 Wieland	7.3149.01810 WKFN4/35 4mm <sup>2</sup>	7.3149.01810 WKFN4/35 4mm <sup>2</sup>	7.3149.01810 WKFN4/35 4mm <sup>2</sup>	7.3149.01810 WKFN4/35 4mm <sup>2</sup>
PE earth terminal	-X10 Wieland	7.3149.01830 WKFN4/SL/35 4mm <sup>2</sup>	7.3149.01830 WKFN4/SL/35 4mm <sup>2</sup>	7.3149.01830 WKFN4/SL/35 4mm <sup>2</sup>	7.3149.01830 WKFN4/SL/35 4mm <sup>2</sup>
Block diagram Battery charger Equipment parts list					
<b>KAESER</b> KOMPRESSOREN Ursprung: AFA0122_00					
Ersatz durch:					
Ersatz für:					
Datum: 18.05.2009					
Bearb. Weid					
Gepr. Weid					
Norm					
Name					
Datum					
Änderung					




**ATTENTION !!!**  
Mains voltage reconnected: connection variant Power supply 230V/1~/N/PE/50Hz  
All non-designated conductors 1,5mm² H07V-K black


Function: Power supply			Battery charger			Display instruments			MOBILAIR		
Group of functions:											
c	Datum	18.05.2009	Bearb.	Weid		Circuit diagram			=		
b	Datum		Bearb.	Weid		Battery charger			+		
a	Datum		Gepr.	Weid		Power supply 230V/1~/N/PE			SFABLG-01225.00		
D	Änderung	Datum	Name	Norm	Ersatz durch:	Urspung: AF40122_00			Blatt 1		
										BL	



Function:		Power supply		Battery charger		Display instruments		MOBILAIR M121	
Group of functions:									
c	Datum	18.05.2009	Bearb.	Weid					
b	Datum		Bearb.	Weid					
a	Datum		Gepr.	Weid					
D	Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:			
					Circuit diagram		=		
					Battery charger		+		
					Power supply 400V/3~/N/PE		SFABLG-01225.00		
							Blatt 2		
							Bl.		








## 13.5 Fuel circulation diagram





c	Datum	10.11.2008	Ersatz durch:		Ersatz für:	
b	Bearb.	Plan	Ersatz durch:		Ersatz für:	
a	Gepr.	Grimm	Ersatz durch:		Ersatz für:	
	Änderung	Name	Ersatz durch:		Ersatz für:	
			Kaeser KOMPRESSOREN			
			Ursprung: KFM125CR-00047.00			
			Fuel circulation diagram			
			6-Cylinder-diesel engine			
			Mobilair M 170 DEUTZ (Common Rail)			
			KFM170CR-00054.00		Blatt 1	
					E	

1	2	3	4	5	6	7	8	
		1 Fuel tank						
		2.1 Fuel prefilter with water separator and manual pump						
		3 Fuel feed pump						
		4 Injection pump						
		5 Injection pipe						
		6 Injection nozzle						
		7 Fuel filter						
		8 Fuel supply line						
		9 Fuel return line						
		14 Pressure regulating valve						
		15 Temperature sensor						
		16 Pressure sensor						
		17 Electronic control unit						
		18 Rail						
		19 Pressure limiting valve						
c	Datum	10.11.2008	Fuel circulation diagram					
b	Berech.	Plan	6-Cylinder-diesel engine					
a	Gepr.	Grünn	Mobilair M 170 DEUTZ (Common Rail)					Blatt 2
Änderung	Datum	Name	KFM170CR-00054.00					E
Ersatz durch:			KFM125CR-00047.00					Ursprung:
Ersatz für:								

## 13.6 SIGMA CONTROL MOBIL message codes

Further information See chapter 9.2 for measures to rectify the cause of message codes.

### Construction of message codes

The following is the key to 4-digit message codes.

- Position 1 - type of message:
  - 1 – Alarm
  - 2 – Maintenance
  - 3 – Warning
- Position 2 - location of the cause:
  - 1 – Engine
  - 2 - Compressor unit
  - 3 – Controller
  - 4 – General
- Positions 3 and 4 - numbers from 00 to 99

### Range 1100 - 1199: engine faults

Message code	Meaning
1100	Oil pressure fault.
1101	Oil pressure sensor defective.
1110	Coolant temperature high.
1111	Coolant level too low.
1112	Coolant temperature sensor defective.
1120	Turbo air pressure too high/low.
1121	Turbo air temperature too high.
1122	Turbo air temperature sensor defective.
1123	Turbo air temperature sensor defective.
1130	Fuel level low.
1131	Fuel temperature high.
1132	Fuel pressure low.
1133	Fuel temperature sensor defective.
1134	Fuel pressure sensor defective.
1135	Fuel pump fault..
1140	Defective alternator.
1141	Battery voltage too high/low.
1150	Engine electronics fault.
1151	Fault in the engine electronic communication - engine electronics side.
1152	Fault in the engine electronic communication - ECM side.
1160	Rail pressure sensor fault.
1161	Speed sensor fault.

Message code	Meaning
1170	Starting fault (after 3 failed attempts).

Tab. 91 Message code range 1100 – 1199: engine faults

**Range 1200 - 1299: compressor unit faults**

Message code	Meaning
1200	Compressor unit overheating.
1201	Compressor pressure too high.

Tab. 92 Message code range 1200 – 1299: compressor unit faults

**Range 1300 - 1399: controller faults**

Message code	Meaning
1300	Memory fault.
1301	Fault in bus communication with engine electronics.
1302	Fault in bus communication with display unit.
1303	Overheating.
1304	Power supply.

Tab. 93 Message code range 1300 – 1399: controller faults

**Message code range 1400 – 1499: general faults**

Message code	Meaning
1400	Quick stop
1410	Open circuit in the oil separator tank pressure sensor.
1411	Short circuit in the oil separator tank pressure sensor.
1412	Open circuit in the inlet valve pressure sensor.
1413	Short circuit in the inlet valve pressure sensor.
1414	Open circuit in the compressor unit temperature sensor.
1415	Short circuit in the compressor unit temperature sensor.
1416	Open circuit in fuel level sensor.
1417	Short circuit in fuel level sensor.
1420	Open circuit in the venting valve (p+e).
1421	Short circuit in the venting valve (p+e).
1422	Open circuit in the auxiliary venting valve (p)
1423	Short circuit in the auxiliary venting valve (p)
1424	Open circuit in the inlet valve control valve (e).
1425	Short circuit in the inlet valve control valve (e).
1426	Open circuit in the frost protector valve.
1427	Short circuit in the frost protector valve.
1430	Manual-stop automatic mode.

Message code	Meaning
1450	Controller block, GSM/GPS monitoring.
1470	Automatic start fault.

Tab. 94 Message code range 1400 – 1499: general faults

**Range 2100 - 2199: engine maintenance**

Message code	Meaning
2100	Change engine oil and filter (500h).
2101	Clean or change the engine air filter (500h).

Tab. 95 Message code range 2100 – 2199: engine maintenance

**Range 2200 - 2299: compressor unit maintenance**

Message code	Meaning
2200	Replace the compressor cooling oil and filter (1000h).
2201	Clean or change the compressor air filter (250h).

Tab. 96 Message code range 2200 – 2299: compressor unit maintenance

**Range 3100 - 3199: engine warnings**

Message code	Meaning
3100	Engine oil pressure too low.
3110	Coolant temperature high.
3121	Turbo air temperature high.
3130	Fuel level low.
3133	Fuel filter water level.

Tab. 97 Message code range 3100 – 3199: engine warnings

**Range 3200 - 3299: compressor unit warnings**

Message code	Meaning
3200	Compressor overheating.
3201	Compressor final pressure too high.

Tab. 98 Message code range 3200 – 3299: compressor unit warnings

**Message code range 3400 – 3499: general warnings**

Message code	Meaning
3400	Battery charging voltage.

Tab. 99 Message code range 3400 – 3499: general warnings

### 13.7 Option dd Operating instructions for compressed air filter (combination filter)


**Bedienungsanleitung  
Instruction Manual**

**Hochleistungs - Druckluftfilter**

**Compressed-air filters**

**Serie / Series**

**FA (D), FB (D&E), FC (D&E), FD (E), FE (D&E), FF (D&E), FG**



Kaeser Kompressoren GmbH  
Postfach 2143  
96410 Coburg  
Tel.: 09561/640-0  
Fax: 09561/640130  
<http://www.kaeser.com>

**KAESER**

gültig ab 01.04.2007

D

GB

A Kap. 9.2, 9.3 Wartungsintervalle	04.12.08	SK
Änd. Mittlg.	Datum	Bearb.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**

**Sign of material**

Filter: Standard		Filter: D-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FA-6	9.4600.0	FA-6 D	9.4600.00110	E-A-6	9.4800.0
FA-10	9.4601.0	FA-10 D	9.4601.00110	E-A-10	9.4801.0
FA-18	9.4602.0	FA-18 D	9.4602.00110	E-A-18	9.4802.0
FA-28	9.4603.0	FA-28 D	9.4603.00110	E-A-28	9.4803.0
FA-48	9.4604.0	FA-48 D	9.4604.00010	E-A-48	9.4804.0
FA-71	9.4605.0	FA-71 D	9.4605.00010	E-A-71	9.4805.0
FA-107	9.4606.0	FA-107 D	9.4606.00010	E-A-107	9.4806.0
FA-138	9.4607.0	FA-138 D	9.4607.00010	E-A-138	9.4807.0
FA-177	9.4608.0	FA-177 D	9.4608.00010	E-A-177	9.4808.0
FA-221	9.4609.0	FA-221 D	9.4609.00010	E-A-221	9.4809.0
FA-185	9.4610.0	FA-185 D	9.4610.00010	E-A-185	9.4810.0
FA-283	9.4611.0	FA-283 D	9.4611.00010	E-A-283	9.4811.0
FA-354	9.4612.0	FA-354 D	9.4612.00010	E-A-185	9.4810.0
FA-526	9.4613.0	FA-526 D	9.4613.00010	E-A-185	9.4810.0
FA-708	9.4614.0	FA-708 D	9.4614.00010	E-A-185	9.4810.0
FA-885	9.4615.0	FA-885 D	9.4615.00010	E-A-185	9.4810.0
FA-1420	9.4616.0	FA-1420 D	9.4616.00010	E-A-185	9.4810.0
FA-1950	9.4617.0	FA-1950 D	9.4617.00010	E-A-185	9.4810.0
FA-2480	9.4618.0	FA-2480 D	9.4618.00010	E-A-185	9.4810.0

D-Pack: Filter mit ECO-DRAIN /

D-Pack: Filter with ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Typ/Type	Nr./No.
FB-6	9.4620.0	FB-6 B	9.4620.00110	FB-6 D	9.4620.00120	FB-6 E	E-B-6	FB-6 E	9.4812.0
FB-10	9.4621.0	FB-10 B	9.4621.00110	FB-10 D	9.4621.00120	FB-10 E	E-B-10	FB-10 E	9.4813.0
FB-18	9.4622.0	FB-18 B	9.4622.00110	FB-18 D	9.4622.00120	FB-18 E	E-B-18	FB-18 E	9.4814.0
FB-28	9.4623.0	FB-28 B	9.4623.00110	FB-28 D	9.4623.00120	FB-28 E	E-B-28	FB-28 E	9.4815.0
FB-48	9.4624.0	FB-48 B	9.4624.00110	FB-48 D	9.4624.00120	FB-48 E	E-B-48	FB-48 E	9.4816.0
FB-71	9.4625.0	FB-71 B	9.4625.00110	FB-71 D	9.4625.00120	FB-71 E	E-B-71	FB-71 E	9.4817.0
FB-107	9.4626.0	FB-107 B	9.4626.00110	FB-107 D	9.4626.00120	FB-107 E	E-B-107	FB-107 E	9.4818.0
FB-138	9.4627.0	FB-138 B	9.4627.00110	FB-138 D	9.4627.00120	FB-138 E	E-B-138	FB-138 E	9.4819.0
FB-177	9.4628.0	FB-177 B	9.4628.00110	FB-177 D	9.4628.00120	FB-177 E	E-B-177	FB-177 E	9.4820.0
FB-221	9.4629.0	FB-221 B	9.4629.00110	FB-221 D	9.4629.00120	FB-221 E	E-B-221	FB-221 E	9.4821.0
FB-185	9.4630.0	-	-	FB-185 D	9.4630.00120	FB-185 E	E-B-185	FB-185 E	9.4822.0
FB-283	9.4631.0	-	-	FB-283 D	9.4631.00120	FB-283 E	E-B-283	FB-283 E	9.4823.0
FB-354	9.4632.0	-	-	FB-354 D	9.4632.00120	FB-354 E	E-B-185	FB-354 E	9.4822.0
FB-526	9.4633.0	-	-	FB-526 D	9.4633.00120	FB-526 E	E-B-185	FB-526 E	9.4822.0
FB-708	9.4634.0	-	-	FB-708 D	9.4634.00120	FB-708 E	E-B-185	FB-708 E	9.4822.0
FB-885	9.4635.0	-	-	FB-885 D	9.4635.00120	FB-885 E	E-B-185	FB-885 E	9.4822.0
FB-1420	9.4636.0	-	-	FB-1420 D	9.4636.00020	FB-1420 E	E-B-185	FB-1420 E	9.4822.0
FB-1950	9.4637.0	-	-	FB-1950 D	9.4637.00020	FB-1950 E	E-B-185	FB-1950 E	9.4822.0
FB-2480	9.4638.0	-	-	FB-2480 D	9.4638.00020	FB-2480 E	E-B-185	FB-2480 E	9.4822.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 2 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E



**Materialkennzeichnung**

**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Typ/Type	Nr./No.
FC-6	9.4640.0	FC-6 B	9.4640.00110	FC-6 D	9.4640.00120	FC-6 E	E-C-6		9.4824.0
FC-10	9.4641.0	FC-10 B	9.4641.00110	FC-10 D	9.4641.00120	FC-10 E	E-C-10		9.4825.0
FC-18	9.4642.0	FC-18 B	9.4642.00110	FC-18 D	9.4642.00120	FC-18 E	E-C-18		9.4826.0
FC-28	9.4643.0	FC-28 B	9.4643.00110	FC-28 D	9.4643.00120	FC-28 E	E-C-28		9.4827.0
FC-48	9.4644.0	FC-48 B	9.4644.00110	FC-48 D	9.4644.00120	FC-48 E	E-C-48		9.4828.0
FC-71	9.4645.0	FC-71 B	9.4645.00110	FC-71 D	9.4645.00120	FC-71 E	E-C-71		9.4829.0
FC-107	9.4646.0	FC-107 B	9.4646.00110	FC-107 D	9.4646.00120	FC-107 E	E-C-107		9.4830.0
FC-138	9.4647.0	FC-138 B	9.4647.00110	FC-138 D	9.4647.00120	FC-138 E	E-C-138		9.4831.0
FC-177	9.4648.0	FC-177 B	9.4648.00110	FC-177 D	9.4648.00120	FC-177 E	E-C-177		9.4832.0
FC-221	9.4649.0	FC-221 B	9.4649.00110	FC-221 D	9.4649.00120	FC-221 E	E-C-221		9.4833.0
FC-185	9.4650.0	-	-	FC-185 D	9.4650.00120	FC-185 E	E-C-185		9.4834.0
FC-283	9.4651.0	-	-	FC-283 D	9.4651.00120	FC-283 E	E-C-283		9.4835.0
FC-354	9.4652.0	-	-	FC-354 D	9.4652.00120	FC-354 E	E-C-185		9.4834.0
FC-526	9.4653.0	-	-	FC-526 D	9.4653.00120	FC-526 E	E-C-185		9.4834.0
FC-708	9.4654.0	-	-	FC-708 D	9.4654.00120	FC-708 E	E-C-185		9.4834.0
FC-885	9.4655.0	-	-	FC-885 D	9.4655.00120	FC-885 E	E-C-185		9.4834.0
FC-1420	9.4656.0	-	-	FC-1420 D	9.4656.00020	FC-1420 E	E-C-185		9.4834.0
FC-1950	9.4657.0	-	-	FC-1950 D	9.4657.00020	FC-1950 E	E-C-185		9.4834.0
FC-2480	9.4658.0	-	-	FC-2480 D	9.4658.00020	FC-2480 E	E-C-185		9.4834.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Typ/Type	Typ/Type	Nr./No.
FD-6	9.4660.0	FD-6 E		E-D-6	9.4836.0
FD-10	9.4661.0	FD-10 E		E-D-10	9.4837.0
FD-18	9.4662.0	FD-18 E		E-D-18	9.4838.0
FD-28	9.4663.0	FD-28 E		E-D-28	9.4839.0
FD-48	9.4664.0	FD-48 E		E-D-48	9.4840.0
FD-71	9.4665.0	FD-71 E		E-D-71	9.4841.0
FD-107	9.4666.0	FD-107 E		E-D-107	9.4842.0
FD-138	9.4667.0	FD-138 E		E-D-138	9.4843.0
FD-177	9.4668.0	FD-177 E		E-D-177	9.4844.0
FD-221	9.4669.0	FD-221 E		E-D-221	9.4845.0
FD-185	9.4670.0	FD-185 E		E-D-185	9.4846.0
FD-283	9.4671.0	FD-283 E		E-D-283	9.4847.0
FD-354	9.4672.0	FD-354 E		E-D-185	9.4846.0
FD-526	9.4673.0	FD-526 E		E-D-185	9.4846.0
FD-708	9.4674.0	FD-708 E		E-D-185	9.4846.0
FD-885	9.4675.0	FD-885 E		E-D-185	9.4846.0
FD-1420	9.4676.0	FD-1420 E		E-D-185	9.4846.0
FD-1950	9.4677.0	FD-1950 E		E-D-185	9.4846.0
FD-2480	9.4678.0	FD-2480 E		E-D-185	9.4846.0

E-Pack: Filter mit Filtermonitor

E-Pack: Filter with filtermonitor

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 3 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**

**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Nr./No.	Nr./No.
FE-6	9.4700.0	FE-6 B	9.4700.00110	FE-6 D	9.4700.00120	FE-6 E	E-E-6		9.4860.0
FE-10	9.4701.0	FE-10 B	9.4701.00110	FE-10 D	9.4701.00120	FE-10 E	E-E-10		9.4861.0
FE-18	9.4702.0	FE-18 B	9.4702.00110	FE-18 D	9.4702.00120	FE-18 E	E-E-18		9.4862.0
FE-28	9.4703.0	FE-28 B	9.4703.00110	FE-28 D	9.4703.00120	FE-28 E	E-E-28		9.4863.0
FE-48	9.4704.0	FE-48 B	9.4704.00110	FE-48 D	9.4704.00120	FE-48 E	E-E-48		9.4864.0
FE-71	9.4705.0	FE-71 B	9.4705.00110	FE-71 D	9.4705.00120	FE-71 E	E-E-71		9.4865.0
FE-107	9.4706.0	FE-107 B	9.4706.00110	FE-107 D	9.4706.00120	FE-107 E	E-E-107		9.4866.0
FE-138	9.4707.0	FE-138 B	9.4707.00110	FE-138 D	9.4707.00120	FE-138 E	E-E-138		9.4867.0
FE-177	9.4708.0	FE-177 B	9.4708.00110	FE-177 D	9.4708.00120	FE-177 E	E-E-177		9.4868.0
FE-221	9.4709.0	FE-221 B	9.4709.00110	FE-221 D	9.4709.00120	FE-221 E	E-E-221		9.4869.0
FE-185	9.4710.0	-	-	FE-185 D	9.4710.00120	FE-185 E	E-E-185		9.4870.0
FE-283	9.4711.0	-	-	FE-283 D	9.4711.00120	FE-283 E	E-E-283		9.4871.0
FE-354	9.4712.0	-	-	FE-354 D	9.4712.00120	FE-354 E	E-E-185		9.4870.0
FE-526	9.4713.0	-	-	FE-526 D	9.4713.00120	FE-526 E	E-E-185		9.4870.0
FE-708	9.4714.0	-	-	FE-708 D	9.4714.00120	FE-708 E	E-E-185		9.4870.0
FE-885	9.4715.0	-	-	FE-885 D	9.4715.00120	FE-885 E	E-E-185		9.4870.0
FE-1420	9.4716.0	-	-	FE-1420 D	9.4716.00020	FE-1420 E	E-E-185		9.4870.0
FE-1950	9.4717.0	-	-	FE-1950 D	9.4717.00020	FE-1950 E	E-E-185		9.4870.0
FE-2480	9.4718.0	-	-	FE-2480 D	9.4718.00020	FE-2480 E	E-E-185		9.4870.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Nr./No.	Nr./No.
FF-6	9.4720.0	FF-6 B	9.4720.00110	FF-6 D	9.4720.00120	FF-6 E	E-F-6		9.4872.0
FF-10	9.4721.0	FF-10 B	9.4721.00110	FF-10 D	9.4721.00120	FF-10 E	E-F-10		9.4873.0
FF-18	9.4722.0	FF-18 B	9.4722.00110	FF-18 D	9.4722.00120	FF-18 E	E-F-18		9.4874.0
FF-28	9.4723.0	FF-28 B	9.4723.00110	FF-28 D	9.4723.00120	FF-28 E	E-F-28		9.4875.0
FF-48	9.4724.0	FF-48 B	9.4724.00110	FF-48 D	9.4724.00120	FF-48 E	E-F-48		9.4876.0
FF-71	9.4725.0	FF-71 B	9.4725.00110	FF-71 D	9.4725.00120	FF-71 E	E-F-71		9.4877.0
FF-107	9.4726.0	FF-107 B	9.4726.00110	FF-107 D	9.4726.00120	FF-107 E	E-F-107		9.4878.0
FF-138	9.4727.0	FF-138 B	9.4727.00110	FF-138 D	9.4727.00120	FF-138 E	E-F-138		9.4879.0
FF-177	9.4728.0	FF-177 B	9.4728.00110	FF-177 D	9.4728.00120	FF-177 E	E-F-177		9.4880.0
FF-221	9.4729.0	FF-221 B	9.4729.00110	FF-221 D	9.4729.00120	FF-221 E	E-F-221		9.4881.0
FF-185	9.4730.0	-	-	FF-185 D	9.4730.00120	FF-185 E	E-F-185		9.4882.0
FF-283	9.4731.0	-	-	FF-283 D	9.4731.00120	FF-283 E	E-F-283		9.4883.0
FF-354	9.4732.0	-	-	FF-354 D	9.4732.00120	FF-354 E	E-F-185		9.4882.0
FF-526	9.4733.0	-	-	FF-526 D	9.4733.00120	FF-526 E	E-F-185		9.4882.0
FF-708	9.4734.0	-	-	FF-708 D	9.4734.00120	FF-708 E	E-F-185		9.4882.0
FF-885	9.4735.0	-	-	FF-885 D	9.4735.00120	FF-885 E	E-F-185		9.4882.0
FF-1420	9.4736.0	-	-	FF-1420 D	9.4736.00020	FF-1420 E	E-F-185		9.4882.0
FF-1950	9.4737.0	-	-	FF-1950 D	9.4737.00020	FF-1950 E	E-F-185		9.4882.0
FF-2480	9.4738.0	-	-	FF-2480 D	9.4738.00020	FF-2480 E	E-F-185		9.4882.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 4 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.
FG-6	9.4740.0	E-G-6	9.4884.0
FG-10	9.4741.0	E-G-10	9.4885.0
FG-18	9.4742.0	E-G-18	9.4886.0
FG-28	9.4743.0	E-G-28	9.4887.0
FG-48	9.4744.0	E-G-48	9.4888.0
FG-71	9.4745.0	E-G-71	9.4889.0
FG-107	9.4746.0	E-G-107	9.4890.0
FG-138	9.4747.0	E-G-138	9.4891.0
FG-177	9.4748.0	E-G-177	9.4892.0
FG-221	9.4749.0	E-G-221	9.4893.0
FG-185	9.4750.0	E-G-185	9.4894.0
FG-283	9.4751.0	E-G-283	9.4895.0
FG-354	9.4752.0	E-G-185	9.4894.0
FG-526	9.4753.0	E-G-185	9.4894.0
FG-708	9.4754.0	E-G-185	9.4894.0
FG-885	9.4755.0	E-G-185	9.4894.0
FG-1420	9.4756.0	E-G-185	9.4894.0
FG-1950	9.4757.0	E-G-185	9.4894.0
FG-2480	9.4758.0	E-G-185	9.4894.0

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type
FFG-6	9.4760.0	FFG-6 B	9.4760.00110	FFG-6 D	9.4760.00120	FFG-6 E
FFG-10	9.4761.0	FFG-10 B	9.4761.00110	FFG-10 D	9.4761.00120	FFG-10 E
FFG-18	9.4762.0	FFG-18 B	9.4762.00110	FFG-18 D	9.4762.00120	FFG-18 E
FFG-28	9.4763.0	FFG-28 B	9.4763.00110	FFG-28 D	9.4763.00120	FFG-28 E
FFG-48	9.4764.0	FFG-48 B	9.4764.00110	FFG-48 D	9.4764.00120	FFG-48 E
FFG-71	9.4765.0	FFG-71 B	9.4765.00110	FFG-71 D	9.4765.00120	FFG-71 E
FFG-107	9.4766.0	FFG-107 B	9.4766.00110	FFG-107 D	9.4766.00120	FFG-107 E
FFG-138	9.4767.0	FFG-138 B	9.4767.00110	FFG-138 D	9.4767.00120	FFG-138 E
FFG-177	9.4768.0	FFG-177 B	9.4768.00110	FFG-177 D	9.4768.00120	FFG-177 E
FFG-221	9.4769.0	FFG-221 B	9.4769.00110	FFG-221 D	9.4769.00120	FFG-221 E
FFG-185	9.4770.0	-	-	FFG-185 D	9.4770.00120	FFG-185 E
FFG-283	9.4771.0	-	-	FFG-283 D	9.4771.00120	FFG-283 E
FFG-354	9.4772.0	-	-	FFG-354 D	9.4772.00120	FFG-354 E
FFG-526	9.4773.0	-	-	FFG-526 D	9.4773.00120	FFG-526 E
FFG-708	9.4774.0	-	-	FFG-708 D	9.4774.00120	FFG-708 E
FFG-885	9.4775.0	-	-	FFG-885 D	9.4775.00120	FFG-885 E
FFG-1420	9.4776.0	-	-	FFG-1420 D	9.4776.00020	FFG-1420 E
FFG-1950	9.4777.0	-	-	FFG-1950 D	9.4777.00020	FFG-1950 E
FFG-2480	9.4778.0	-	-	FFG-2480 D	9.4778.00020	FFG-2480 E

Filterkombination bestehend aus Serie FF &amp; FG

Filter combination consist of series FF &amp; FG

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter Serie FF mit Filtermonitor und ECO-DRAIN

E-pack: Filter series FF with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 5 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Inhaltsverzeichnis**

**Contents**

<b>1. Einleitung</b>	<b>1. Introduction</b>
<b>2. Sicherheitsregeln, Warnhinweise</b>	<b>2. Safety rules, warnings</b>
<b>3. Technische Daten</b>	<b>3. Technical data</b>
<b>4. Funktionsbeschreibung</b>	<b>4. Description of functions</b>
<b>5. Kondensatableiter</b>	<b>5. Condensate discharger</b>
<b>6. Transport, Wareneingangskontrolle</b>	<b>6. Transportation, checking of goods received</b>
<b>7. Montage</b>	<b>7. Assembly</b>
<b>8. Inbetriebnahme, Betrieb</b>	<b>8. Start up, operation</b>
<b>9. Wartung, Austausch der Filterelemente</b>	<b>9. Servicing, filter cartridge replacement</b>
<b>10. Garantiebedingungen</b>	<b>10. Guarantee conditions</b>
<b>11. Maßzeichnung</b>	<b>11. Dimensional drawing</b>
<b>12. Anhang (ECO-DRAIN)</b>	<b>12. Annex (ECO-DRAIN)</b>
<b>13. Einteilung nach Druckgeräterichtlinie</b>	<b>13. Grading of filters according to pressure equipment directive (PED)</b>

Wir haben den Inhalt der Bedienungsanleitung auf Übereinstimmung mit dem beschriebenen Gerät geprüft. Dennoch können Abweichungen nicht ausgeschlossen werden, so daß wir für die vollständige Übereinstimmung keine Gewähr übernehmen.

We have examined the content of the operating instructions for conformity with the appliance described. Inconsistencies cannot be ruled out, however, with the result that we do not guarantee complete conformity

Technische Änderungen vorbehalten.

We reserve the right to alter the specifications without prior notice

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**1. Einleitung**

**1.1 Allgemeines**

Die in dieser Betriebsanleitung dokumentierten Druckluftfilter erfüllen alle Anforderungen, die an moderne Filtersysteme gestellt werden.


Um Sie optimal nutzen zu können, benötigt der Anwender ausführliche Informationen.

In der vorliegenden Betriebsanleitung haben wir diese Informationen möglichst vollständig und in entsprechende Kapitel gegliedert zusammengestellt.

Lesen und beachten Sie diese Informationen. Sie helfen Ihnen auch Unfälle zu vermeiden.


**1.2 Erklärung der Symbole in der Bedienungsanleitung**

- Aufzählungen werden mit diesem Punkt oder Sternchen \* gekennzeichnet.


 Mit diesem Symbol werden Textstellen gekennzeichnet, die unbedingt zu beachten sind.


- Wichtige Sicherheitshinweise
- Wichtige Bedienungs-/Wartungshinweise
- Warnung vor möglichen Fehlbedienungen
- Warnung vor Gefahren

 Elektrisches Gefahrensymbol

 Ausführende Tätigkeit.  
Vom Bediener auszuführende Bedienschritte.

**1.3 Erklärung der Symbole am Gerät**

 Automatischer Kondensatablaß / Automatic Condensate Drain

 Elektroanschluß / Electrical Supply

**1. Introduction**

**1.1 General remarks**

The compressed air filters documented in these instruction manual has all requirements that can be expected from a modern filter/ -system.

In order to obtain maximum benefit from using the filters/ -system the user should have sufficient information.

These instruction manual gave the user this information which has been divided into separate sections for easy reference.

Please read carefully before installing and operating the filter/ -system.


**1.2 Explanation to the symbols in the instruction manual**

- Technical data or instructions.  
\*


 Parts that require absolute attention


- Vital safety instructions
- Essential operation and maintenance instructions
- Warnings on handling or moving the dryer
- Danger areas

 Electrical danger symbol

 Changes sequence of operation

**1.3 Symbols used in the filter**

 Drucklufteintritt / Compressed Air Inlet

 Druckluftaustritt / Compressed Air Outlet


F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**2. Sicherheitsregeln,  
Warnhinweise**

**2. Safety rules,  
warnings**

**2.1 Bestimmungsgemäßer Gebrauch**

**2.1 Use of filter/ -system**

 **Achtung!**

 **Achtung!**

- Die Filter dürfen nur für die in dieser Bedienungsanleitung vorgesehenen Einsatzfälle zur Aufbereitung von Druckluft verwendet werden.
- Der einwandfreie und sichere Betrieb der Produkte erfordert sachgerechten Transport, Lagerung, Aufstellung und Montage, sowie sorgfältige Bedienung und Instandhaltung.

- The filter must only be used for the purpose as designated in the instruction manual to upgrading the compressed air.
- To obtain maximum efficiency and operation of the filter/ -system ensure all sections of the manual are read carefully.

**2.2 Sicherheitsregeln**

**2.2 Safety rules**

 **Warnung!**

 **Warning!**

- Die Filter dürfen nur von qualifiziertem Personal genutzt, bedient, gewartet oder instandgesetzt werden.
- Qualifiziertes Personal im Sinne der sicherheitsbezogenen Hinweise in dieser Dokumentation oder auf dem Produkt selbst, ist Personal das:
  - \* im Umgang mit Einrichtungen der Druckluft vertraut und unterwiesen sowie über die damit verbundenen Gefahren unterrichtet ist.
  - \* Den auf die Bedienung bezogenen Inhalt dieser Dokumentation kennt.
  - \* Es besitzt als solches eine zur Inbetriebnahme und Wartung derartiger Einrichtungen befähigende Ausbildung bzw. Berechtigung.

- The filter/ -system must only be used, operated, inspected and repaired by trained personnel.
- Trained personnel are defined as follows:
  - \* Operating staff who are skilled in the field of compressed air engineering and who are familiar with the filter/ -system and possible dangers in unauthorised operation or service.
  - \* Who can interpret and action the contents of this operation instruction manual.
  - \* Who have had the appropriate training and qualified as being competent in these fields.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**2. Sicherheitsregeln,  
Warnhinweise**

**2. Safety rules,  
warnings**

**2.3 Warnhinweise**

**2.3 Security-warnings**

 **Warnung!**

Das (die) Filter beinhalten unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

 **Warning!**

The filter/ -system contains components under high pressure.  
Before starting any service work turn off compressed air supply to the dryer and depressurise the system.

 **Warnung!**

Filtersysteme mit elektrisch gesteuerten Kondensatableitern enthalten unter elektrischer Spannung stehende Bauteile.  
Vor Servicearbeiten sind diese allpolig vom elektrischen Spannungsversorgungsnetz zu trennen.  
(Netzstecker ziehen, Hauptschalter ausschalten)

 **Warning!**

The filter/ -systems with electrical condensate discharger contains components that are electrically live and which can cause danger to life.  
Before starting any service work ensure all power is isolated from the filter/ -system, mains isolator to be off, mains plug if fitted to be removed.

**ACHTUNG!**  
Alle Arbeiten am elektrischen System dürfen nur von elektrotechnisch geschultem Fachpersonal, oder unter Aufsicht von diesem, durch Unterwiesene ausgeführt werden.

**ATTENTION!**  
Any electrical work on the dryer must only be carried out by skilled staff - qualified electricians, or persons under supervision of qualified staff.

 **Hinweis!**

Die Filter sind ausschließlich zur Aufbereitung von Druckluft einzusetzen.

 **Remark!**

Use filter for compressed air applications only.

**ACHTUNG!**  
Die Verwendung in Verbindung mit brennbaren Gasen ist verboten!

**Attention!**  
The use of combustible gases is prohibited.

 **ACHTUNG!**

Filter/ -systeme zur Aufbereitung von Atemluft dürfen nur nach Genehmigung des Herstellers der Filter/ -systeme eingesetzt und betrieben werden.

 **ATTENTION!**

Filter/ -systems for breathing air applications must be approved from manufacturer.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

3. Technische Daten

3. Technical data

MODELL BEZEICHNUNG / MODEL DESIGNATION		Volumenstrom Capacity [m³/min]	Anschluß Connection [ ]	Betriebsdruck Working Pressure [max]	Abmessungen Dimensions		Gewicht Weight [kg]	AUSTAUSCH-FILTERELEMENTE FILTER REPLACEMENT CARTRIDGE		
FILTER- GRAD / GRADE	FILTER- GEHÄUSE / HOUSING				Höhe / Height [mm]	Breite / Width [mm]		FILTER- GRAD / GRADE	FILTER- GEHÄUSE / HOUSING	Anzahl Quantity
<b>MODUL-BAUWEISE / MODULAR SYSTEM</b>										
	-6	0,58	3/8"	16	105				-6	1
	-10	1,00	1/2"	16	105	siehe Kapitel	siehe Kapitel		-10	1
FA	-18	1,75	1/2"	16	105	„Maßzeich- nung“	„Maßzeichnung“		-18	1
	-28	2,83	3/4"	16	133				-28	1
FB	-48	4,83	1"	16	133				-48	1
	-71	7,10	1-1/2"	16	164	see chapter „dimensional drawing“	see chapter „dimensional drawing“		-71	1
FC	-107	10,7	1-1/2"	16	164				-107	1
	-138	13,8	2	16	194				-138	1
FD	-177	17,7	2-1/2"	16	194				-177	1
	-221	22,1	2-1/2"	13	194				-221	1
<b>BEHÄLTER-BAUWEISE / PRESSURE VESSEL</b>										
FE	-185	18,5	DN80	16	1025		siehe Kapitel		-185	1
	-283	28,3	DN80	16	1045		„Maßzeichnung“		-283	2
FF	-354	35,4	DN80	16	1045				-354	2
	-526	52,6	DN100	16	1085				-526	3
FG	-708	70,8	DN100	16	1105		see chapter „dimensional drawing“		-708	4
	-885	88,5	DN100	16	1105				-885	5
	-1420	142	DN150	16	1215				-1420	8
	-1950	195	DN150	16	1245				-1950	11
	-2480	248	DN150	16	1245				-2480	14

- Volumenstrom m³/h bezogen auf +20°C und 1 bar absolut, bei Betriebsüberdruck 7 bar / Air flow m³/h based on +20°C and 1 bar absolute, at working pressure 7 bar
- Größere Betriebsdrücke auf Anfrage / Contact factory for dryers with a higher working pressure
- Filtergehäuse F-185 – F-2480: Konstruktion der Behälter entspricht der EG-Richtlinie 87/404/EEC für einfache Druckbehälter und ist mit CE-Zeichen versehen / Filter bowls F-185 – F-2480: Vessel construction complies with directive 87/404/EEC, simple pressure vessels, and is marked with the EC symbol

Volumenstrom - Korrekturtabelle / Sizing

Minimaler Betriebsdruck / Minimum working pressure bar															
Korrekturfaktor / Correction factor	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	0,38	0,52	0,63	0,75	0,88	1,00	1,13	1,26	1,38	1,52	1,65	1,76	1,87	2	2,14

Auslegung

Bei Drücken abweichend von 7 bar berechnet sich der max. Volumenstrom wie folgt:

den Korrekturfaktor des entsprechenden minimalen Betriebsdruckes mit dem gewählten Volumenstrom aus o.g. Tabelle multiplizieren.

Based on

To find the maximum flow at pressures other than 7 bar:

multiply the flow (from table above) by the correction factor corresponding to the minimum working pressure of the filter.

Betriebsbedingungen:

Min. Betriebstemperatur: +1°C

Max. Betriebstemperatur: 66°C.

Min. Betriebsdruck mit automatischem Kondensatableiter: 2,0 bar

Working conditions:

Min. Working temperature: +1°C

Max. Working temperature: 66°C

Min. working pressure with automatic condensate drain: 2.0 bar

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.



**4. Funktionsbeschreibung**

**4. Description of operation**

**4.3 Serie FC**

**4.3 Series FC**

**1-MIKRON-COALESCEING-FILTER**

**1-MICRON-COALESCEING-FILTER**

- Zweistufige Tiefenfiltration bewirkt hervorragende Leistung und höhere Standzeiten des Filterelementes
- Entfernt 100% des Kondensats
- Entfernt Feststoffpartikel bis herunter zu 1 Mikron
- Restölgehalt < 1 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbelastung: 2g/m<sup>3</sup>

- Two in-depth filter beds offer superior performance and extended cartridge life
- Removes 100% of liquid water
- Removes solid particles down to 1 micron
- Oil content < 1 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 2g/m<sup>3</sup>

**Anwendungen:**

**Application:**

- Allgemeine Filter für Werkstattluft
- Vorfilter für Hochleistungsfilter
- Nachfilter für Adsorptionstrockner
- Endstellenfiltration bei Einsatz von Nachkühlern oder Trocknern


- General filter for shop air
- Prefilter for high efficiency filters
- Afterfilter for pressure-swing desiccant dryers
- Point-of-use filter on systems utilising aftercoolers or dryers

**Funktion:**

**Operation:**

Die Luft tritt von oben in das Filterelement FC ein und strömt radial durch den perforierten inneren Stützmantel zur 1. Filtrationsstufe. Diese Stufe besteht aus mehreren Lagen Glasfaser und einer stützenden Glasfasermatte. Größere Feststoffteilchen werden hier zurückgehalten. Die Luft gelangt nun in die 2. Filtrationsstufe, bestehend aus einer mehrlagigen Mischung von imprägnierten Glasfasern und Mikrofibern. In beiden Stufen werden Feststoffpartikel und Flüssigkeiten nach dem Prinzip der Tiefenfiltration sowie des Coalescings ausgefiltert. Die Luft tritt durch den perforierten äußeren Stützmantel aus.

Air enters the inside of the cartridge FC and flows outwardly through two in-depth beds of glass fibres. Larger particles are collected in the first bed while all remaining particles one micron and larger are collected in the second bed. A combination of large void areas and stabilized media allows heavy particulate loading and low pressure drop resulting in a long service life for the cartridge. Throughout both stages, liquid aerosols are captured and coalesced. The coalesced liquids then drain to the bottom of the cartridge for removal.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**4. Funktionsbeschreibung**

**4. Description of operation**

**4.5 Serie FE**

**4.5 Series FE**

**0,01-MIKRON-COALESZING-FILTER**  
(bei 0,01 ppm w/w max. Ölgehalt)

**0,01-MICRON-COALESZING-FILTER**  
(at 0,01 ppm w/w max. oil content)

DUO-System Abscheidung

DUO-system separation

1. Stufe: flüssige Bestandteile
2. Stufe: Ölbestandteile

1. Stage: liquid particles
2. Stage: oil particles

- Entfernt mehr als 99,99% der Öl-Aerosole
- Entfernt Feststoffpartikel bis herunter zu 0,01 Mikron
- Restölgehalt < 0,01 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbelastung: 1g/m<sup>3</sup>

- Removes more than 99,99% of oil aerosols
- Removes solid particles down to 0,01 microns
- Oil content < 0,01 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 1g/m<sup>3</sup>

**Anwendungen:**

**Application:**

- Vorfilter für Membrantrockner
- Vorfilter für Adsorptionstrockner
- Endstellenfiltration (falls geringfügige Feuchtigkeit vorhanden ist)

- Prefilter for membrane dryers
- Prefilter for pressure-swing desiccant dryers
- Point-of-use filter (may be used if light liquid load is present)


**Funktion:**

**Operation:**

Die Luft tritt von oben in das Filterelement FE ein und strömt durch den inneren Stützmantel, radial durch verschiedenartige Lagen Fiberglas. Dann strömt die Luft durch ein weiteres Sieb. In dieser 1. Filtrationsstufe werden größere Partikel entfernt. In der zweiten Filtrationsstufe werden Aerosole und feste Bestandteile durch eine Mehrschicht-Membranwand aus epoxidharz verstärktem Fiberglas gefiltert, daß speziell für feinste Aerosole geeignet ist. Das Filtermedium ist ein Bett aus submikrofeinen Glasfasern und wirkt nach dem Prinzip des Coalescings sowie der Tiefenfiltration. Der innere Schaumstoffmantel gleicht Luftschwankungen und Aerosolkonzentrationen aus und gewährleistet eine gleichmäßige Verteilung. Im äußeren Schaumstoffmantel werden die Öltröpfchen gesammelt, fließen durch Schwerkraft in den unteren Teil des Filters und tropfen dann in den Filterbehälter ab.

Air enters the inside of the cartridge FE and flows through an inner foam sleeve, radially outward through various layers of glass fibers. Then the air flows through another screen. In the first stage filter section the larger solid particles are trapped. In the second stage filter section aerosols and solid particles are trapped using a multi-layered membrane wall made of epoxy resin-reinforced glass fibres which was especially designed for the finest aerosols.

The filter media is a bed of submicronic glass fibers and works to the principle of coalescing and in-depth filtration. The inner foam sleeve compensates air cycling and aerosol concentrations and maintains uniform distribution. The outer foam sleeve collects the coalesced oil droplets which then, due to gravity, travel downstream to the bottom of the sleeve and drain to the bottom of the filter bowl.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**7. Montage**

**7. Mounting**

**7.1 Montageort**

Das Filter/ -system sollte in einem trockenen, frostfreien Innenraum installiert werden.  
Zur Wartung ist genügend Freiraum vorzusehen.

**7.1 Location of mounting**

The filter/ -system should be installed in a dry and frost-proof room indoors.  
Ample free, space should be allowed for the maintenance.

**7.2 Montage**

Das Filter/ -system ist senkrecht so zu montieren, daß der Druckluft-ein- und austritt waagrecht erfolgt.

**7.2 Mounting**

Mount the filter/ -system so that inlet and outlet connections are horizontal (filter bowl vertical).

Im Filtergehäuse eingebaute Filterelemente können sich während des Transportes lösen.  
Prüfen Sie den richtigen Sitz der Filterelemente vor der Inbetriebnahme.

Cartridges installed in the filter housing may become dislodged during transport.  
Make sure that the cartridge is correctly installed before use.

**⚠ ACHTUNG!**  
Achten Sie bei der Montage darauf, daß keine Zug- und Druckkräfte auf die Geräteanschlüsse übertragen werden.

**⚠ ATTENTION!**  
When installing the filter/ -system ensure all connections are even and no pressure is placed on inlet and outlet connections.

**⚠ Hinweis!**  
Bei den Standard-Filtern FB, FC, FE und FF der Größe -185 & -283 ... -2480, den D-Pack-Basic-Filtern FB, FC, FE und FF, sowie den E-Pack-Filtern FA, FB, FC, FE und FF sind die Kondensatableiter beige packt und müssen wie in Kapitel 11. „Maßzeichnung“ angebaut werden.

**⚠ Remark!**  
By the standard-filter FB,FC,FE and FF with the size -185 & -283 ... -2480, by the D-pack-basic-filter FB, FC, FE, FF and by the E-pack-filter FA, FB, FC, FE and FF the condensate drains are attached and must mount as shown in chapter 11. „Dimensional drawing“.

**7.3 Anschluß an das Druckluftnetz**

Die Druckluftein- und -austrittsleitung sollte für Servicezwecke mit einem Bypass versehen werden.  
Die Dimensionierung des Anschlusses entnehmen Sie bitte dem Kapitel 3. „Technische Daten“.

**7.3 Connection to the compressed air system**

The compressed air inlet and outlet line should be equipped with a by-pass system for the maintenance.  
For the sizing of the connections please see chapter 3. „Technical data“.

**⚠ ACHTUNG!**  
Durchflußrichtung beachten.  
Druckluftein- und austritt dürfen nicht vertauscht werden.

**⚠ ATTENTION!**  
Pay attention to the flow direction.  
Do not exchange the compressed air inlet and outlet.

**7.4 Kondensatableitung**

Für die automatische Kondensatableitung ist bei den Filtern (FA, FB, FC, FE, FF) ein Anschluß vorhanden.  
Die Dimensionierung des Anschlusses entnehmen Sie bitte Kapitel 5. „Kondensatableiter“.

**7.4 Condensate drain**

The filters (FA, FB, FC, FE, FF) are equipped with one connection for the automatically condensate drain.  
For the sizing of the connection please see chapter 5. „Condensate discharger“.

**⚠ Achten Sie bei der Montage der Kondensatableitung darauf, daß das abgeschiedene Kondensat ungehindert abfließen kann.**

**⚠ When fitting the drains please see to it, that the condensate separated is drained off into a system that does not create a back pressure.**

**⚠ HINWEIS!**  
Bei der Entsorgung des Kondensats ist der Schmutzanteil zu berücksichtigen.  
Beachten Sie die jeweils geltenden gesetzlichen Vorschriften.

**⚠ Instruction!**  
When disposing of the condensate the amount of pollution has to be taken into consideration. Please act according to the prevailing regulations of law.

Bei den Filtern FD, FG entfällt der Kondensatableitungsanschluß.

Condensate drain does not exist in filters FD, FG.


F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.


**8. Inbetriebnahme, Betrieb**

**8. Start-up, operation**

**8.1 Bereitschaft zur Inbetriebnahme**





**8.1 Preconditions for starting the dryer**





-  **Druckluftfilter/ -systeme sind bereit zur Inbetriebnahme, wenn:**
- Der auf dem Typenschild angegebene Druck dem maximalen Betriebsdruck entspricht.
  - Sie entsprechend Kapitel 7. „Montage“ installiert wurden.
  - Alle Zu- und Ableitungen sachgerecht angeschlossen sind.
  - Die erforderlichen Energien (Druckluft) verfügbar sind.
  - Absperrorgane (z.B. Ventil, Kugelhahn) in der Druckluftein- und austrittsleitung geschlossen sind.
  - Kondensat durch die Kondensatableitung ungehindert abfließen kann.
  - Der elektrisch gesteuerte Kondensatableiter an das elektrische Spannungsversorgungsnetz mit der richtigen Betriebsspannung angeschlossen ist. (Nur bei elektrisch gesteuerten Kondensatableitern)
  - Das Filter/ -system mit den richtigen Filterelementen ausgerüstet ist.

-  **The filter/ -system is ready for starting when:**
- Check unit serial number tag to verify working pressure.
  - They has been installed in accordance with section 7. „Mounting“.
  - All inlet and outlet lines have been correctly connected.
  - The required forms of energy (compressed-air) are available.
  - The shut-off devices (e.g. ball valve) in the compressed-air inlet and outlet lines are closed.
  - The condensate is able to flow through the condensate discharger without obstruction.
  - The electrical condensate drain has been connected to the electric power supply system with the correct operating voltage (only electrical condensate drains).
  - The filter/ -system is equipped with the right cartridges.

**8.2 Inbetriebnahme, Betrieb**

**8.2 Start up, operation**

-  **Vor der Inbetriebnahme ist sicherzustellen, daß alle Bedingungen des Abschnittes 8.1 „Bereitschaft zur Inbetriebnahme“ erfüllt sind.**
-  Setzen Sie das Filter/ -system durch langsames Öffnen der Drucklufteintritts- und austrittsleitung unter Druck.
-  Schließen Sie das Absperrorgan im Bypass (falls vorhanden).
-  **Das Filter/ -system ist nun in BETRIEB.**

-  **Before starting the dryer, ensure that all the requirements specified in section 8.1 „Preconditions for starting the dryer“ have been fulfilled.**
-  Place filter/ -system under pressure gradually by slowly opening the compressed air inlet/outlet.
-  Close the shut-off device in the bypass (if installed).
-  **The filter/ -system is now OPERATIVE.**


F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**8. Inbetriebnahme, Betrieb**

**8. Start-up, operation**

**8.3 Differenzdruckanzeige-Standard und D-Pack (OPTION)**

**8.3 Differential pressure indicator-standard and D-Pack (OPTION)**



Die Differenzdruckanzeige informiert als Störanzeige über eine atypische Verschmutzung.

The differential pressure indicator indicates atypical contamination.

⚠ **Unabhängig von der Differenzdruckanzeige müssen die Filterelemente gemäß der Wartungsintervalle gewechselt werden. (Siehe Kapitel 9)**

⚠ **We recommend installing a new filter cartridge according to the maintenance periods. (See chapter 9)**

⚠ **Das Filter FG benötigt keine Differenzdruckanzeige.**

⚠ **The FG filter does not require a differential pressure gauge.**

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

**9. Servicing, filter cartridge replacement**

**9.1 Standzeit der Filterelemente**

**9.1 Serviceable life of cartridge**

Die Standzeit der Filterelemente ist abhängig von der Beladung. Mit steigender Beladung der Elemente erhöht sich der Differenzdruck über den Filter.  
Die Filterelemente müssen gemäß unten stehender Tabelle gewechselt werden.

The cartridge's serviceable life depends upon the degree of contamination. As the cartridge becomes more contaminated, the differential pressure above the filter increases.  
The filterelements must be changed according to the table below.

**9.2 Austausch der Filterelemente**

**9.2 Replacing the cartridge**

**Filtergehäuse -6 bis -221**

**Filter housing -6 to -221**

Anzahl der Filterelemente siehe Kapitel 4. „Technische Daten“.


Number of cartridges see chapter 4. „Technical data“.


**⚠️ WARNUNG!**

**⚠️ CAUTION!**


- Verwenden Sie keine Werkzeuge! (Filtergehäuse -6 bis -48)
- Öffnen und Schließen Sie das Filter nicht mit Gewalt.
- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.


- Do not use any tools (filter housings -6 to -48)
- Do not force the filter open or closed.
- The filter(s) contain(s) systems under high pressure.  
All pressure must be let off before servicing.


 Absperrvorrichtung im Druckluftein- und -austritt schließen.

 Close the shut-off device in the compressed air inlet/outlet.

 Kondensatableitungsschlauch an (1) lösen.  
(Nur bei FB, FC, FE, FF).

 Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).

 Rändelschraube (1) langsam im Uhrzeigersinn lösen.  
Das Filtergehäuse wird entlüftet.

 Slowly turn the knurled screw (1) clockwise. This will release the air from the housing.

**Wartungsintervalle / Maintenance-intervals**


Wartungsteil Part of maintenance	Type	Anwendung Application	Wartungs-Intervall Maintenance-interval
Filter-Elemente / filter cartridges	FB, FC	Vorfilter Pre-filter	6.000 Bh, max. 1 Jahr / 6.000 Bh, max. 1 year
	FE, FF	Microfilter	3.000 Bh, max. 1 Jahr/ 3.000 Bh, max. 1 year
	FEG	Filterkombination Filter combination	3.000 Bh, max. 1 Jahr (Type FE) 3.000 Bh, max. 1 year (Type FE)
	FFG		1.000 Bh, max. 1 Jahr (Type FG) 1.000 Bh, max. 1 year (Type FG)
	FD	Nachfilter After-filter	6.000 Bh, max. 1 Jahr/ 6.000 Bh, max. 1 year
	FG	Aktivkohlefilter Act. carbon filter	1.000 Bh
Kondensatableiter / condensate drain	Service-unit	Vorfilter Pre-filter	6.000 Bh
	Service-unit	Microfilter	6.000 Bh
	Service-unit	Filterkombination Filter combination	6.000 Bh

Bh = Kompressor-Betriebsstunden / Working hours




F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.


**9. Wartung  
Austausch der Filterelemente**

 Filtergehäuse entfernen.

- **Filtergehäuse -6 bis -48 (Bajonett-Verschluss)**
  - \* Das Filtergehäuse nach oben, gegen den Filterkopf drücken.
  - \* Dann das Filtergehäuse im Uhrzeigersinn langsam gegen den Anschlag drehen (etwa 1/8 Drehung) und nach unten abziehen.
- **Filtergehäuse -71 bis -221 (Gewinde-Verschluss)**
  - \* Schrauben Sie das Filtergehäuse gegen den Uhrzeigersinn (per Hand oder mit Hilfe eines Filterschlüssels) auf.

 Filterelement gemäß unten stehender Skizze abziehen, bzw. wechseln.


**Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF und FG dürfen nicht mit den Fingern angefaßt werden.

 Filtergehäuse in umgekehrter Reihenfolge zusammenbauen.


 Filter durch langsames Öffnen der Absperrvorrichtung wieder mit Druck beaufschlagen.




**9. Servicing, filter cartridge replacement**


 Remove housing.


- **Housing -6 to -48 (bayonet-style head)**
  - \* Push housing upwards against the filter head.
  - \* Then slowly turn the housing clockwise to the stop (about 1/8 of a turn) and remove by pulling downwards.
- **Housing -71 to -221 (threaded head)**
  - \* Screw off the housing counter-clockwise (by hand or using a filter wrench).

 Remove and replace cartridge as shown below.

**Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF and FG series with your fingers.

 Re-assemble the housing in the reverse order.

 Place filter under pressure again by slowly opening the shut-off device.



**Filtergehäuse -185 bis -2480**


Anzahl der Filterelemente siehe Kapitel 3. „Technische Daten“.

 **WARNUNG!**

- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

**Housing -185 to -2480**










Number of cartridges see chapter 3. „Technical data“.

 **CAUTION!**










- The filter(s) contain(s) systems under high pressure.  
Alle pressure must be let off before servicing

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

-  Absperrvorrichtung im Druckluftein- und -austritt schließen.
  -  Kondensatableitungsschlauch an (1) lösen. (Nur bei FB, FC, FE, FF).
  -  Um das Filtergehäuse zu entlüften müssen Sie beim:  
- Kondensatableiter Nr. 30505 und Nr. 30506 die Entlüftungsschraube (3) entgegen dem Uhrzeigersinn lösen.  
- FG den Kugelhahn (5) öffnen.
  -  Schrauben der Flanschverbindung am Boden des Filtergehäuses vorsichtig lösen, da evtl. noch ein geringer Restdruck im System vorhanden ist.
  -  Schrauben bis auf eine entfernen und Flansch zur Seite schwenken.
  -  Filterelemente entgegen dem Uhrzeigersinn heraus-schrauben.
  -  Neue Filterelemente ohne Werkzeug „fingerfest“ einschrauben.
- Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF, FG dürfen nicht mit den Fingern angefaßt werden.
-  Filtergehäuse in umgekehrter Reihenfolge schließen.
  -  Filter durch langsames Öffnen der Absperrvorrichtungen wieder mit Druck beaufschlagen.

**9. Servicing, filter cartridge replacement**

-  Close shut-off device in compressed air inlet/outlet.
  -  Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).
  -  Follow these steps to release the air from the housing:  
- for condensate drain no. 30505 and no. 30506, loosen the bleed screw (3) in counter-clockwise direction.  
- on FG models, open the ball valve (5).
  -  Gently loosen the screws at the bottom flange of the housing. Caution is necessary as the system may still be under slight residual pressure.
  -  Remove all screws except one and swing flange to the side.
  -  Screw out cartridge counter-clockwise.
  -  Screw in new cartridge by hand until „handtight“. Do not use a wrench.
- Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF, FG series with your fingers.
-  Close housing in reverse order.
  -  Place filter under pressure again by slowly opening the shut-off device.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.



**9. Wartung  
Austausch der Filterelemente**

**9. Servicing, filter cartridge  
replacement**

**9.3 Austausch der**

**Schwimmerableiter /  
ECO-DRAIN Service-unit /  
ECO-DRAIN Membransätze**

**9.3 Changing of**

**Float drain /  
ECO-DRAIN Service-unit /  
ECO-DRAIN membrane set**

Die Kondensatableiter / Wartungspakete sind gemäß unten aufgeführter Tabelle regelmäßig zu wechseln.

The condensate drains / service packages must be changed according to the table below.

Wartungsteil Part of maintenance	Wartungs-Intervall Maintenance-interval
Schwimmer-Kondensatableiter/ Float drain	3.000 Bh
Service-Unit (ECO DRAIN 30/31)	6.000 Bh
ECO DRAIN Verschleißteilsatz (ECO DRAIN 13/14) ECO DRAIN wearing part set (ECO DRAIN 13/14)	6.000 Bh

Nähere Informationen finden Sie auch im Anhang ECO DRAIN.

For more details please see annexe ECO DRAIN.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**10. Garantiebedingungen**

**10. Garantie conditions**

**10.1 Allgemeines**

Die Garantie erstreckt sich, im Rahmen unserer allgemeinen Lieferbedingungen, auf das gelieferte Filter/-system.

**10.1 General**

The guarantee covers the delivered device with regard to our general terms of delivery.

**10.2 Garantieausschluß**

Garantieansprüche bestehen nicht,

- wenn das Filter/ -system durch Einfluß höherer Gewalt oder durch Umwelteinflüsse beschädigt oder zerstört wird.
- bei Schäden, die durch unsachgemäße Behandlung, insbesondere Nichtbeachtung der Betriebs- und Wartungsanleitung aufgetreten sind (regelmäßige Kontrolle des Kondensatableiters / regelmäßiger Wechsel der Filterelemente).
- falls das Filter/ -system nicht seinen Bestimmungen entsprechend eingesetzt war (siehe Kapitel 3. „Technische Daten“).
- falls das Filter/ -system durch nicht hierfür autorisierte Werkstätten oder andere Personen unsachgemäß geöffnet oder repariert wurde und/oder mechanische Beschädigungen irgendwelcher Art aufweist.


**10.2 Exclusion from guarantee coverage**

No guarantee claims shall be assertible,

- if the filter/ -system is damaged or destroyed due to force majeure or environmental effects.
- for damage resulting from incorrect handling, in particular failure to comply with the operating and maintenance instructions (regular inspection of the condensate discharger, regular change of the filter cartridges).
- if the filter/ -system has not been used in accordance with its specifications (see section 3. „Technical data“).
- if the filter/ -system has been opened or repaired by workshops or other persons unauthorised for this purpose and/or reveals any type of mechanical damage.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**13.8 Option dc**  
**Operating instructions for compressed air filter (fresh air filter)**

**domnick hunter**

AC010 - AC030

**OIL-X**  
EVOLUTIONOriginal Language **EN** **OIL VAPOUR & ODOUR REMOVAL FILTERS**

<b>NL</b> OLIEDAMP & GEUR VERWIJDERINGSFILTERS	<b>DE</b> FILTER ZUM ENTFERNEN VON ÖLNEBEL UND GERÜCHEN
<b>FR</b> FILTRES D'ÉLIMINATION DES ODEURS ET DES VAPEURS D'HUILE	<b>FI</b> ÖLJYHÖYRYN JA HAJUN POISTOSUODATTIMET
<b>SV</b> FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	<b>NO</b> OLJEDAMP- OG OLJELUKTFJERNINGSFILTRE
<b>DA</b> FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	<b>EL</b> ΦΙΛΤΡΑ ΑΦΑΙΡΕΣΗΣ ΑΤΜΩΝ & ΟΣΜΩΝ ΛΑΔΙΟΥ
<b>ES</b> FILTROS DE ELIMINACIÓN DE OLORES Y VAPORES DE ACEITE	<b>PT</b> VAPOR DO ÓLEO E FILTROS DE REMOÇÃO DOS CHEIROS
<b>IT</b> FILTRI PER L'ELIMINAZIONE DEGLI ODORI E DEI VAPORI D'OLIO	<b>PL</b> FILTRY DO USUWANIA OPARÓW I ZAPACHU OLEJU
<b>SK</b> FILTRE NA ODSTRAŇOVANIE OLEJOVÝCH VÝPAROV A ZÁPACHU	<b>CS</b> OLEJOVÉ A PROTIPACHOVÉ FILTRY
<b>ET</b> ÕLISUDU JA -HAISU EEMALDUSFILTRID	<b>HU</b> OLAJGŐZ- ÉS SZAGELTÁVOLÍTÓ SZŰRŐK
<b>LV</b> EĻĻAS TVAIKU UN AROMĀTA NOVĒRŠANAS FILTRI	<b>LT</b> ALYVOS GARŲ IR KVAPO ŠALINIMO FILTRAI
<b>RU</b> ФИЛЬТРЫ ДЛЯ УСТРАНЕНИЯ ЗАПАХА И ПАРОВ МАСЛА	<b>SL</b> FILTRI ZA ODSTRANJEVANJE OLJNIH HLAPOV IN VONJAV
<b>TR</b> YAĞ BUHARI VE KOKUSU GİDERİCİ FİLTRELER	<b>MT</b> FILTRI LI JNEHHU L-FWAR TAŻ-ŻJUT U L-IRWEJJAĦ



AC010 - AC030



Warning

- Highlights actions or procedures, which if not performed correctly, may lead to personal injury or death.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, lichamelijk letsel of de dood kunnen veroorzaken.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Verletzungen und tödlichen Unfällen führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent entraîner des dommages corporels ou la mort.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuina saattavat aiheuttaa henkilövahingon tai kuoleman.
- Anger åtgärder och metoder som kan orsaka personskador eller dödsfall om de inte utförs korrekt.
- Fremhæver handlinger eller prosedyrer som kan føre til personskade eller dødsfall hvis de ikke utføres på korrekt måte.
- Fremhæver handlinger eller fremgangsmåder, som kan medføre personskade eller dødsfald, hvis de ikke udføres korrekt.
- Επισημαίνει τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να οδηγήσουν σε τραυματισμό προσωπικού ή σε θάνατο
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar daños personales o la muerte.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão provocar danos pessoais ou morte.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di infortuni o morte.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą prowadzić do obrażeń ciała lub śmierci.
- Zvýrazňuje činnosti alebo postupy, ktoré môžu v prípade nesprávneho vykonania viesť zraneniu alebo usmrteniu.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést ke zranění nebo usmrcení osob.
- Tóstab esile toimingud või protseduurid, mis väärteostamisel korral võivad põhjustada kehavigastusi või surma.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása súlyos vagy végzetes személyi sérülést okozhat.
- Uzsvēr darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var izraisīt ievainojumus vai nāvi.
- Żymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima susižeisti ar mirtį.
- Указывает на действия, ненадлежащее выполнение которых может привести к нанесению вреда здоровью или смерти
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajanju poškodujejo človeka ali povzročijo smrt.
- Doğru bir şekilde yerine getirilmediği takdirde bu ürüne hasar verebilecek işlem ve süreçleri vurgular.
- Tissottolinea l-azzjonijiet jew il-proċeduri, li jekk ma jsirux kif suppost, jista' jkun hemm korrimnt jew mewt



Caution

- Highlights actions or procedures, which if not performed correctly, may lead to damage to this product.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, schade kunnen berokkenen aan dit product.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Schäden am Gerät führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent endommager ce produit.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuina saattavat vaurioittaa tätä laitetta.
- Anger åtgärder och metoder som kan orsaka skador på den här produkten om de inte utförs korrekt.
- Fremhæver handlinger eller prosedyrer som kan føre til skade på produktet hvis de ikke utføres på korrekt måte.
- Fremhæver handlinger eller fremgangsmåder, som kan medføre beskadigelse af dette produkt, hvis de ikke udføres korrekt.
- Επισημαίνει τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να προκαλέσουν ζημιά στο προϊόν αυτό
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar el deterioro del producto.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão danificar este produto.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di danneggiare il prodotto.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą powodować uszkodzenie produktu.
- Zvýrazňuje činnosti alebo postupy, ktoré v prípade nesprávneho vykonania môžu viesť k poškodeniu tohto výrobku.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést k poškození tohoto výrobku.
- Tóstab esile toimingud või protseduurid, mis väärteostamisel korral võivad kaesolevat toodet kahjustada.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása a termék károsodásához vezethet.
- Uzsvēr darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var sabojāt šo izstrādājumu.
- Żymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima sugadinti šį gaminį.
- Указывает на действия, ненадлежащее выполнение которых может привести к повреждениям данного изделия
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajanju poškodujejo izdelek.
- Doğru bir şekilde yerine getirilmediği takdirde yaralanma ya da ölüme yol açabilecek işlem ve süreçleri vurgular
- Tissottolinea l-azzjonijiet jew il-proċeduri, li jekk ma jsirux kif suppost, tista' ssir hsara lil dan il prodott












- Suitable gloves must be worn.
- Geeignete Schutzhandschuhe tragen.
- Käytettävä asianmukaisia käsineitä.
- Bruk egnete hansker.
- Απαιτείται να φοράτε κατάλληλα γάντια
- Devem ser utilizadas luvas adequadas.
- Należy zakładać odpowiednie rękawice
- Kohustuslik kanda sobivaid kaitsekindaid
- Jävalkä piemēroti cimdi.
- Работы должны проводиться в соответствующих перчатках
- Uyğun eldiven giyimelidir

- Altijd geschikte handschoenen dragen.
- Le port de gants adaptés est obligatoire.
- Använd lämpliga handskar.
- Der skal anvendes egnete handsker.
- Se deben llevar puestos guantes apropiados.
- Indossare guanti di protezione.
- Je nutné použít vhodné rukavice.
- Viseljen megfelelő védőkesztyűt.
- Reikia mūvēti tinkamas pirštines.
- Uporabiti je treba ustrezne rokavice.
- Ghandhom jintlibsu ingwanti adatti



- Highlights the requirements for disposing of used parts and waste.
- Benadrukt de vereisten voor het weggoeien van gebruikte onderdelen en afval.
- Weist auf die Anforderungen zur Entsorgung gebrauchter Teile und Abfall hin.
- Met en relief les consignes de mise au rebut des pièces usagées et des déchets.
- Osoittaa käytettyjen osien ja jätteen hävittämistä koskevia vaatimuksia.
- Anger de krav som ställs på bortskaffande av gamla delar och avfall.
- Fremhæver kravene for avhending av brukte deler og avfall.
- Fremhæver kravene til bortskaffelse af udtjente dele og affald.
- Επισημαίνει τις απαιτήσεις απόρριψης των χρησιμοποιημένων εξαρτημάτων και των απορριμμάτων
- Destaca los requisitos para desechar las piezas usadas y los residuos.
- Realça os requisitos para eliminar as peças utilizadas e os desperdícios.
- Segnala i criteri per lo smaltimento di componenti usati e rifiuti.
- Wskazuje wymagania dotyczące usuwania zużytych części i odpadów.
- Zvýrazňuje požiadavky pre zneškodňovanie použitých dielov a odpadu.
- Upozornění na požadavky týkající se likvidace použitých dílů a odpadu.
- Tóstab esile kasutatud osade ja jääkide utiliseerimisele esitatavad nõuded
- A használt alkatrészek és a hulladék megfelelő módon történő elhelyezésére hívja fel a figyelmet.
- Uzsvēr prasības tam, kā atbrīvoties no lietotajām detaļām un atkritumiem.
- Żymi panaudotą dalių ir atliekų išmetimo reikalavimus.
- Указывает на требования по уничтожению использованных деталей и отходов
- Označuje zahteve za odlaganje rabljenih delov in odpadkov.
- Kullaniilmiş parçaların ve atıkların atılmasına ilişkin gereklilikleri vurgular
- Tissottolinea l-kundizzjonijiet biex wiehed jarmi l-partijiet uzati u l-iskart

#### AC010 - AC030

	<ul style="list-style-type: none"> <li>• Pressure.</li> <li>• Paine.</li> <li>• Πίεση</li> <li>• Ciśnienie</li> <li>• Nyomás alatt.</li> <li>• Tlak</li> </ul>	<ul style="list-style-type: none"> <li>• Druk</li> <li>• Trykk</li> <li>• Presión.</li> <li>• Tlak.</li> <li>• Spiediensi.</li> <li>• Basınc</li> </ul>	<ul style="list-style-type: none"> <li>• Druck.</li> <li>• Trykk</li> <li>• Pressão.</li> <li>• Tlak.</li> <li>• Sléigis.</li> <li>• Pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>• Pression.</li> <li>• Tryk</li> <li>• Pressione.</li> <li>• Surve.</li> <li>• Давление</li> </ul>
	<ul style="list-style-type: none"> <li>• Release Pressure.</li> <li>• Evacuation de pression.</li> <li>• Avlast trykk</li> <li>• Despresurizar.</li> <li>• Ciśnienie spustowe</li> <li>• Surve väljalase</li> <li>• Ísleiskite sléigj.</li> <li>• Basıncı Kaldırın</li> </ul>	<ul style="list-style-type: none"> <li>• Druk aflaten.</li> <li>• Vapauta paine.</li> <li>• Aflast tryk</li> <li>• Liberta Pressão.</li> <li>• Uvolnitte tlak.</li> <li>• Engedje ki a nyomást.</li> <li>• Стравить давление</li> <li>• Nehhi l-pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>• Druck ablassen.</li> <li>• Tryckutsläpp.</li> <li>• Εκτόνωση πίεσης</li> <li>• Scaricare la pressione.</li> <li>• Uvolnění tlaku.</li> <li>• Pazeminiet spiedienu.</li> <li>• Sprostitev tlaka.</li> </ul>	
	<ul style="list-style-type: none"> <li>• Replace every year</li> <li>• Remplacer tous les ans.</li> <li>• Skift ut hvert år</li> <li>• Sustituir anualmente</li> <li>• Należy wymieniać raz w roku</li> <li>• Asendage igal aastal</li> <li>• Keiskite kartā per metus</li> <li>• Her yıl değiştirin</li> </ul>	<ul style="list-style-type: none"> <li>• Elk jaar vervangen</li> <li>• Vaihda vuosittain.</li> <li>• Udskift en gang om året</li> <li>• Substituir todos os anos</li> <li>• Každý rok vymieňajte</li> <li>• Evente cserélje</li> <li>• Заменять каждый год.</li> <li>• İbde l kull sena</li> </ul>	<ul style="list-style-type: none"> <li>• Jährlich austauschen</li> <li>• Byt varje år</li> <li>• Αντικατάσταση κάθε χρόνο</li> <li>• Sostituire ogni anno</li> <li>• Nutná výměna každý rok.</li> <li>• Nomainiet reizi gadā</li> <li>• Zamenjajte vsako leto.</li> </ul>	
	<ul style="list-style-type: none"> <li>• Filter housing / Model</li> <li>• Logement du filtre/modèle.</li> <li>• Filterhus/-modell</li> <li>• Caja de filtro/modelo.</li> <li>• Obudowa filtra / model.</li> <li>• Filtri korpus/mudel</li> <li>• Filtr korpusas / modelis</li> <li>• Filtre muhafazası / Model</li> </ul>	<ul style="list-style-type: none"> <li>• Filterhuis / Model</li> <li>• Suodatinkotelo/-malli</li> <li>• Filterhus/modell</li> <li>• Caixa / Modelo do filtro</li> <li>• Kryt filtra / Model</li> <li>• Szűrőház / típus</li> <li>• Корпус фильтра / модель</li> <li>• Kontenitur tal-filtru - Mudell</li> </ul>	<ul style="list-style-type: none"> <li>• Filtergehäuse / Modell</li> <li>• Filterhus/modell</li> <li>• Υπόδοχη/μοντέλο φίλτρου</li> <li>• Corpo del filtro / Modello</li> <li>• Kryt filtru / Model</li> <li>• Filtra korpus / modelis</li> <li>• Ohišje filtra / Model</li> </ul>	
	<ul style="list-style-type: none"> <li>• High efficiency filter element</li> <li>• Hochleistungsfilterelement</li> <li>• Tehokas suodatinelementti</li> <li>• Høyeffektivt filterelement</li> <li>• Φίλτρο υψηλής απόδοσης</li> <li>• Elemento do filtro de elevado rendimento</li> <li>• Wysokowydajny wkład filtra</li> <li>• Vysoce účinný filtrační prvek</li> <li>• Nagy hatékonyságú szűrőelem</li> <li>• Labai efektyvus filtravimo elementas</li> <li>• Visoko učinkovit filtrirni element</li> <li>• Element tal-filtru b'effiċjenza kbira</li> </ul>	<ul style="list-style-type: none"> <li>• Zeer efficiënt filterelement</li> <li>• Cartouche filtrante haute efficacité.</li> <li>• Høgeffektivt filterelement</li> <li>• Høgeffektivt filterelement</li> <li>• Elemento filtrante de gran eficiencia.</li> <li>• Elemento filtrante ad alta efficienza</li> <li>• Vysoko účinný filtračný článok</li> <li>• Kőrgtőotlik filterelement</li> <li>• Augstas produktivitātes filtra elements</li> <li>• Высокоэффективный фильтрующий элемент</li> <li>• Yüksek etkinlikli filtre öğesi</li> </ul>		
	<ul style="list-style-type: none"> <li>• Adsorption filter cartridge - Granular carbon</li> <li>• Adsorptionsfiltereinsatz - Granulatkohle</li> <li>• Adsorptiosuodatinelementti - rakeinen hiili</li> <li>• Adsorpsjonsfilterpatron - Karbon i kornform</li> <li>• Φασιγγίο φίλτρου προσρόφησης - Κοκκώδης άνθρακας</li> <li>• Cartucho do filtro de absorção - Carvão granular</li> <li>• Adsorpcyjny wkład filtrujący z węgla ziamistego</li> <li>• Adsorpcni filtračni prvek - granulovaný uhlík</li> <li>• Adsorpciószűrőbetét - granulált szén</li> <li>• Adsorbicinio filtro kasetē - anglies granulēs</li> </ul>	<ul style="list-style-type: none"> <li>• Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>• Cartouche filtrante d'adsorption - Charbon en granulé.</li> <li>• Adsorptionsfilterkassett - Kornigt kol</li> <li>• Adsorptionsfilterkassett - Kornigt kol</li> <li>• Cartucho filtrante de adsorción, granulos de carbón.</li> <li>• Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>• Adsorpcná filtračná kazeta - Granulovaný uhlík</li> <li>• Adsorpciofiltri kassett - teraline süsi</li> <li>• Absorbējoša filtra kasetne - graudains ogleklis</li> <li>• Адсорбционный фильтрующий элемент - гранулированный уголь</li> <li>• Adsorpsiyon filtresi kartuşu - Taneli karbon</li> </ul>		
	<ul style="list-style-type: none"> <li>• Kaseta adsorbiciniskega filtra - zrnasti ogljik</li> <li>• Kaxxa assorbenti tal-filtru - Karbonju mrammel</li> </ul>			
	<ul style="list-style-type: none"> <li>• Adsorption filter element - Wrapped carbon cloth</li> <li>• Adsorptie filterelement - gewikkelde koolstofdoek</li> <li>• Adsorptionsfilterelement - eingewickeltes Filtertuch aus Kohlenstoff</li> <li>• Cartouche filtrante d'adsorption - Charbon entouré de tissu.</li> <li>• Adsorptiosuodatinelementti - käärittö hiilikangas</li> <li>• Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>• Adsorpsjonsfilterelement - Innpakket karbonstoff</li> <li>• Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>• Φίλτρο προσρόφησης - Τυλιγμένο ύφασμα άνθρακα</li> <li>• Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>• Elemento do filtro de absorção - Pano revestido de carvão</li> <li>• Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>• Wkład adsorpcyjny filtra ze zwijanej tkaniny z włókna węglowego</li> <li>• Adsorpcni filtrační článok - Zabalená uhlíková tkanina</li> <li>• Adsorpcni filtračni prvek - zabalená uhlíková tkanina</li> <li>• Adsorpciofiltri element - isoleeritud süsinikriie</li> <li>• Adsorpciószűrőelem - göngyölt szénszövet</li> <li>• Absorbējošs filtra elements - saīta oglekļa drāniņa</li> <li>• Adsorbicinis filtravimo elementas - susuktas anglies audinys</li> <li>• Адсорбционный фильтрующий элемент - ткань из углеродистого волокна</li> <li>• Adsorpcijski filtrirni element - navita ogljikova krpa</li> <li>• Adsorpsiyon filtresi öğesi - Sarılı karbon kumaş</li> <li>• Element tal-filtru li jassorbixxi - Xoqqa tal-karbonju mgezwra</li> </ul>			
	<ul style="list-style-type: none"> <li>• Ensure correct tool is used</li> <li>• Zorg dat het juiste gereedschap wordt gebruik</li> <li>• Vérifier que les outils adéquats sont utilisés.</li> <li>• Se till att rätt verktyg används.</li> <li>• Sørg for at benytte korrekt værktøj</li> <li>• Asegúrese de que se utiliza la herramienta adecuada</li> <li>• Assicurarsi di utilizzare l'utensile corretto</li> <li>• Uistite sa, že používate správny nástroj</li> <li>• Tagage őige tőőriista kasutamine</li> <li>• Izmantojiet tikai atbilstošus darbarīkus</li> <li>• Убедитесь, что используется правильный инструмент</li> <li>• Doğru alet kullanilmasini sağlayın</li> </ul>	<ul style="list-style-type: none"> <li>• Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>• Käyttävä oikeaa työkalua</li> <li>• Pass på at korrekt værktøj bruges</li> <li>• Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>• Certifique-se de que é utilizada a ferramenta correcta</li> <li>• Należy używać odpowiedniego narzędzia.</li> <li>• Zkontrolujte použití správného nástroje</li> <li>• Mindig a célnak megfelelő szerszámot használja</li> <li>• Isitinkite, kad naudojamas reikiamas įrankis</li> <li>• Poskrbite, da boste uporabili ustrezno orodje</li> <li>• Kun žgur li tintuza l-ghodda t-tajba</li> </ul>		

AC010 - AC030

---

**Warning!**

This product must be installed and maintained by competent and authorised personnel only, under strict observance of these operating instructions, any relevant standards and legal requirements where appropriate.

**Retain this user guide for future reference**

**Waarschuwing!**

Dit product mag alleen geïnstalleerd en onderhouden worden door deskundig en bevoegd personeel met strikte inachtneming van deze bedieningsinstructies en de betreffende normen en wettelijke vereisten indien van toepassing.

**Bewaar deze handleiding als naslag.**

**Warnung!**

Das Produkt darf ausschließlich von autorisiertem Fachpersonal unter strikter Befolgung dieser Betriebsanleitung, ggf. relevanter Normen sowie gesetzlicher Vorschriften installiert und gewartet werden.

**Bewahren Sie die Bedienungsanleitung zu Referenzzwecken auf.**

**Attention !**

Ce produit doit être installé et entretenu exclusivement par un personnel compétent et autorisé, dans le respect le plus strict de ce mode d'emploi et des normes applicables et exigences légales éventuelles.

**Conserver ce guide de l'utilisateur à titre de référence future**

**Varoitus!**

Tämän tuotteen saa asentaa ja huoltaa vain pätevä ja valtuutettu henkilöstö, noudattaen tarkasti näitä käyttöohjeita, kaikkia asiaankuuluvia normeja ja tarpeen vaatiessa lain asettamia vaatimuksia.

**Säilytä tämä käyttöohje tulevaa tarvetta varten.**

**Varning!**

Produkten får endast installeras och underhållas av utbildad och behörig personal, som följer denna bruksanvisning och eventuella tillämpliga normer och lagföreskrifter noga i förekommande fall.

**Behåll denna användarhandbok som referens**

**Advarsel!**

Dette produktet må bare installeres og vedlikeholdes av kompetent og autorisert personale, i streng overholdelse av disse betjeningsanvisningene, alle relevante standarder og rettslige krav der det passer.

**Ta vare på denne brukerveiledningen for senere bruk**

**Advarsel!**

Dette produkt må kun installeres og vedligeholdes af autoriseret personale, under nøje overholdelse af disse driftsinstruktioner, relevante standarder og lovgivningsmæssige krav, hvor dette er aktuelt.

**Gem denne vejledning til senere reference.**

**Προειδοποίηση!**

Η εγκατάσταση και συντήρηση αυτού του προϊόντος πρέπει να γίνεται μόνο από κατάλληλα εκπαιδευμένο και εξουσιοδοτημένο προσωπικό, με αυστηρή τήρηση των οδηγιών χειρισμού, των εφαρμοζόμενων προτύπων και των νομικών απαιτήσεων όπου απαιτείται.

**Φυλάξτε αυτό το εγχειρίδιο χρήσης για μελλοντική αναφορά**

**Advertencia**

La instalación y mantenimiento de este producto debe ser efectuada únicamente por personal competente y autorizado, respetándose de forma estricta estas instrucciones de funcionamiento, así como cualquier norma y requerimiento legal que sean aplicables.

**Conserve esta guía del usuario para poder consultarla en el futuro.**

**Advertência!**

A instalação e a manutenção deste produto só deve ser realizada por pessoal autorizado e competente, sob estrita observância destas instruções de utilização e de quaisquer normas e requisitos legais relevantes, quando adequado.

**Conserve este guia do utilizador para referência futura**



AC010 - AC030

MT

**Rakkomandazzjonijiet għall-Installazzjoni**

Nirakkomandaw li l-arja kumpressata tiġi trattata qabel ma tidhol fis-sistema ta' distribuzzjoni kif ukoll fil-punti ċ l-applikazzjonijiet kritiċi ta' l-użu.

L-installazzjoni ta' taghmir li jnixxef l-arja kumpressata fuq sistema li kienet imxarbra jista' jirriżulta f'aktar taghbija ta' hmieg għall-filtri li jintużaw f'punt wiehed, għall-perjodu sakemm is-sistema ta' distribuzzjoni tinxef. L-elementi tal-filtri jista' jkollhom bżonn li jinbidlu aktar spiss matul dan il-perjodu.

Għal installazzjonijiet fejn jintużaw kumpressuri minghajr żejt, xorta jkun hemm prezenti ajrusols u partijiet ta' l-ilma, għalhekk xorta għandhom jintużaw gradi bi skop ġenerali u b'effiċjenza kbira.

Filtru għal skopijiet ġenerali għandu dejjem jiġi installat biex jiproteġi l-filtru ta' effiċjenza kbira mill-volum kbir ta' ajrusols likwidi u partijiet solidi.

Installa taghmir ta' purifikazzjoni fl-aktar temperatura baxxa possibbli imma b'mod li ma jkunx hemm iffrizar, preferibbilment aktar 'l isfel mill-aftercoolers u mir-riċevituri ta' l-arja.

Taghmir tal-purifikazzjoni fil-punt ta' l-użu għandu jiġi installat kemm jista' jkun qrib tal-post fejn għandu japplika.

It-taghmir ta' purifikazzjoni m'għandux jiġi installat aktar 'l isfel mill-valvs li jifthu malajr u għandu jkun protett minn possibiltà ta' fluss b'lura jew kundizzjonijiet oħra stressanti.

Naddaf il-pajps kollha li jwasslu għat-taghmir ta' purifikazzjoni qabel tinstalla u l-pajps kollha wara li tinstalla t-taghmir ta' purifikazzjoni u qabel ma tqabbad ma' l-applikazzjoni finali.



Jekk tiffittja linji ta' by-pass madwar it-taghmir ta' purifikazzjoni, kun żgur li hemm biżżejjed filtrazzjoni ffitjtata mal-linja tal-by-pass biex ma thallix li jkun hemm kontaminazzjoni tas-sistema aktar 'l isfel.

Ipprovdif facilità biex tiddrejnja l-likwidi li jingabru mit-taghmir tal-purifikazzjoni. Il-likwidi li jingabru għandhom jiġu trattati u mormija b'mod responsabbli.



Iż-żmien kemm idumu jersvu l-elementi tal-filtru li jneħhi l-fwar taż-żjut huwa affettwat mill-koncentrazzjoni taż-żejt tad-dhul, l-umdità relattiva u t-temperatura tas-sistema ta' l-arja kumpressata. L-elementi li jneħhu l-fwar taż-żjut ikollhom bżonn jinbidlu aktar ta' sikwit mill-element shih ekwivalenti.

Mudelli AC010□□□□ - AC030□□□□ huma ffitjtati b'indikatur tal-volum taż-żejt. Kemm l-elementi tal-filtru kif ukoll l-indikatur għandhom jinbidlu jekk l-indikatur isir ta' kulur blu.

**Jekk Joghġbok Innota - Dan hu indikatur tal-volum taż-żejt u ma jindikax iż-żmien li jdum iservi l-element tal-filtru.**



AC010 - AC030



6



FILTER-DH-OIL-XEVOLUTION 01











21


AC010 - AC030

5. Spare Parts (Service Kits)

- Reserve-onderdelen (servicekits) • Ersatzteile (Service-Kits) • Pièces de rechange (nécessaires d'entretien) • Varaosat (Huoltopakkaukset) • Reservdelar (servicesatser) • Reservedeler (service-sett) • Reservedele (Servicekit) • Ανταλλακτικά (Πακέτα τεχνικής υποστήριξης) • Piezas de repuesto (kits de mantenimiento) • Peças Sobressalentes (Kit de Reparação) • Ricambi (kit per l'assistenza) • Części zamienne (zestawy serwisowe) • Náhradné diely (Servisná súprava) • Náhradní díly (Sady pro údržbu) • Varuosad (hooldekomplektid) • Pótkatrészek (szervizkészletek) • Rezerwes części (apkopes komplekti) • Atsarginės dalys (priežiros detalių komplektai) • Запасные части (ЗИП) • Nadomestni deli (servisni kompleti) • Yedek parça (Servis kiti) • Partijiet Ghat-Tibdil (Kitts tas-Servizz)

 EF1	<ul style="list-style-type: none"> <li>• AUTOMATIC DRAIN</li> <li>• AUTOMATISCHER ABLAUF</li> <li>• VIDANGE AUTOMATIQUE</li> <li>• AUTOMISCHAFTAPPEN</li> <li>• DRENAJE AUTOMATICO</li> <li>• SCARIO AUTOMATICO</li> <li>• AUTOMATISK AFLØB</li> <li>• DRENO AUTOMÁTICO</li> <li>• ΑΥΤΟΜΑΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• AUTOMATDRÄNERING</li> <li>• AUTOMAATTINEN</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN AUTOMATYCZNY</li> <li>• AUTOMATICKÉ VYSUŠENIE</li> <li>• AUTOMATICKÉ VYPOUŠTĚNÍ</li> <li>• AUTOMAATNE VÄLJALASE</li> <li>• AUTOMATIKUS LEERESZTÉS</li> <li>• AUTOMÁTISKA IZTECINĀŠANA</li> <li>• AUTOMATINIS IŠLEIDIMAS</li> <li>• АВТОМАТИЧЕСКИЙ ДРЕНАЖ</li> <li>• SAMODEJNI ODTOK</li> <li>• OTOMATİK SÜZDÜRÜCÜ</li> <li>• DREJN AWTOMATIKU</li> </ul>	 EM1	<ul style="list-style-type: none"> <li>• MANUAL DRAIN</li> <li>• MANUELLER ABLAUF</li> <li>• VIDANGE MANUELLE</li> <li>• MANUEEL AFTAPPEN</li> <li>• DRENAJE MANUAL</li> <li>• SCARIO MANUALE</li> <li>• MANUELT AFLØB</li> <li>• DRENO MANUAL</li> <li>• ΧΕΙΡΟΚΙΝΗΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• MANUELL DRÄNERING</li> <li>• ΚΑΣΙΚΑΥΤΤΟΙΝΕΝ</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN RECZNY</li> <li>• RUČNÉ VYSUŠENIE</li> <li>• RUČNÍ VYPOUŠTĚNÍ</li> <li>• KÄSITSI VÄLJALASE</li> <li>• KÉZI LEERESZTÉS</li> <li>• MANUĀLA IZTECINĀŠANA</li> <li>• RANKINIS IŠLEIDIMAS</li> <li>• ДРЕНАЖ ВРУЧНЮЮ</li> <li>• ROČNI ODTOK</li> <li>• ELLE KULLANILACAK SÜZDÜRÜCÜ</li> <li>• DREJN MANWALI</li> </ul>
--	--	--	--



 010 A	 AA	 AC	 AC
010 B	010AA	010AC	
010 C	015AA	015AC	
015 B	020AA	020AC	
015 C	025AA	025DAC	
020 C	025AA	025EAC	
020 D	030AA	030AC	
020 E			
025 D			
025 E			
030 E			
030 F			
030 G			



BOIE1  
AC010 □□□ I - AC030 □□□ I

**AC010 - AC030**
**6. Maintenance**

Onderhoud • Wartung • Entretien • Kunnossapito • Underhåll • Vedlikehold • Vedligeholdelse • Συντήρηση • Mantenimiento • Manutenção • Manutenzione • Konserwacja • Údržba • Údržba • Hooldus • Karbantartás • Tehniskā apkope • Techninė priežiūra • Обслуживание • Vzdrževanja • Bakım • **Manutenzjoni**



Models AC010□□□□ - AC030□□□□ are fitted with a bulk oil indicator. Both filter elements and indicator should be changed if indicator is blue in colour.

**Please Note - This is a bulk oil indicator, it does not indicate filter element life.**

Modellen AC010□□□□ - AC030□□□□ zijn uitgerust met een bulk olie indicator. Zowel de filterelementen als de indicator moeten vervangen worden als de indicator blauw van kleur is.

**N.B. - Dit is een bulk olie indicator, het is geen indicator voor de levensduur van het filterelement.**

Die Modelle AC010□□□□ - AC030□□□□ sind mit einer Ölanzeige ausgestattet. Sowohl die Filterelemente also auch die Anzeige sollte ausgetauscht werden, wenn sich die Anzeige blau färbt.

**Bitte beachten - Es handelt sich hier um eine Ölanzeige. Diese gibt keinen Hinweis auf die Lebensdauer des Filterelements.**

Les modèles AC010□□□□ - AC030□□□□ sont fournis avec un indicateur de présence massive d'huile. Lorsque l'indicateur est bleu, il est nécessaire de remplacer les cartouches et l'indicateur.

**Remarque : Il s'agit d'un indicateur de présence massive d'huile, et non pas de la durée de vie des cartouches.**

Malleissa AC010□□□□ - AC030□□□□ on öljynilmais. Sekä suodatinelementit että ilmaisin on vaihdettava, jos ilmaisin on sininen.

**Huomautus - Tämä on öljynilmais. Se ei ilmaise suodatinelementin ikää.**

Modell AC010□□□□ - AC030□□□□ har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Modell AC010□□□□ - AC030□□□□ er monteret med bulkvolum oljeindikator. Både filterelementer og indikator skal skiftes når indikatoren er blå.

**Merk - Dette er en bulkvolum oljeindikator, den indikerer ikke filterelementets levetid.**

Modell AC010□□□□ - AC030□□□□ har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Τα μοντέλα AC010□□□□ - AC030□□□□ διαθέτουν ένα δείκτη παρουσίας λαδιού. Όταν ο δείκτης είναι μπλε πρέπει να αλλάζονται τόσο τα φίλτρα όσο και οι δείκτες.

**Παρακαλούμε σημειώστε ότι - Αυτός είναι ένας δείκτης παρουσίας λαδιού, δεν υποδεικνύει τη διάρκεια ζωής του φίλτρου.**

Los modelos AC010□□□□ - AC030□□□□ disponen de un indicador de presencia de aceite. Si el indicador se vuelve azul deben cambiarse tanto los elementos filtrantes como el indicador.

**Nota importante: se trata de un indicador de presencia de aceite. No indica la vida del elemento filtrante.**


Modelos AC010□□□□ - AC030□□□□ são instalados com um indicador do óleo em bruto. Ambos os elementos do filtro e o indicador deverão ser mudados se o indicador estiver azul.

**Nota - Este é um indicador do óleo em bruto, não indica a vida útil do elemento do filtro.**

I modelli AC010□□□□ - AC030□□□□ sono provvisti di un indicatore degli oli misti. Sostituire gli elementi filtranti e l'indicatore quando il secondo assume una colorazione blu.

**Nota - L'indicatore segnala la presenza di oli misti, ma non la durata dell'elemento filtrante.**







AC010 - AC030



9

FILTER-DH-OIL-XEVOLUTION 01




AC010 - AC030




10


FILTER-DH-OIL-XEVOLUTION 01


AC010 - AC030





#### AC010 - AC030


Konformitätserklärung		DE
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, UK AC010, 015, 020 025, 030 97/23/EC.		
Richtlinien	Allgemein in Übereinstimmung mit ASMEVIII Div 1 : 2004.	
Angewandte Normen	Artikel 3.3 (AC 010, 015, 020, 025) Modul A (AC030)	
Beurteilungsrouten der Druckgeräterichtlinie:	N/A	
Benannte Stelle für die Druckgeräterichtlinie:	N/A	
EG-Baumusterprüfbescheinigung:	Barry Wade Business Systems Improvement Manager domnick hunter ltd	
Bevollmächtigter Vertreter	Erklärung Hiermit erkläre ich als bevollmächtigter Vertreter die Konformität der oben aufgeführten Informationen in Bezug auf die Lieferung/Herstellung dieses Produkts mit den Normen und anderen zugehörigen Dokumenten gemäß den Bestimmungen der oben genannten Richtlinien.	
Unterschrift:		Datum: 28 / 09 / 05
Nummer der Erklärung: 0001/280905		

Försäkran om överensstämmelse		SV
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, Storbritannien AC010, 015, 020 025, 030 97/23/EC.		
Direktiv	Generellt i enlighet med ASMEVIII Div 1: 2004.	
Använda standarder	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)	
Fastställningsväg för PED:	N/A	
Anmält organ för PED:	N/A	
EG-intyg om typprovning:	N/A	
Auktoriserad representant	Barry Wade Business Systems Improvement Manager domnick hunter ltd	
Försäkran Jag försäkrar, i egenskap av auktoriserad representant, att ovan nämnda information avseende överensstämmelse med denna produkt överensstämmer med standarder och övriga relevanta dokument enligt Villkoren i ovanstående direktiv.		
Underskrift:		Datum: 28 / 09 / 05
Försäkran nummer: 0001/280905		

Verklaring van Conformiteit		NL
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, GB AC010, 015, 020 025, 030 97/23/EC.		
Richtlijnen	Gewoonlijk volgens ASMEVIII Div 1: 2004.	
Gehanteerde normen	Artikel 3.3 (AC 010, 015, 020, 025) Module A (AC 030)	
PED-beoordelingsstraject:	N/A	
Aangemelde instantie voor PED:	N/A	
EC Type onderzoekscertificaat:	N/A	
Bevoegde vertegenwoordiger	Barry Wade Manager Bedrijfsysteemverbetering domnick hunter ltd	
Verklaring Als bevoegde vertegenwoordiger verklaar ik dat bovenstaande informatie met betrekking tot de levering / vervaardiging van dit product overeenstemt met de normen en andere bijbehorende documentatie volgens de bepalingen van bovengenoemde richtlijnen.		
Handtekening:		Datum: 28 / 09 / 05
Verklaringnummer: 0001/280905		

Vaatim�nnetmukausuvakuutus		FI
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, ISO-BRITANNIA AC010, 015, 020 025, 030 97/23/EC.		
Direktiivit	Yleensä seuraavaan standardin mukaisesti: ASMEVIII Div 1: 2004.	
Käytetyt standardit	Artikkla 3.3 (AC010, 015, 020, 025, 030) Moduulil A (AC030)	
PED-arvioitimenetely:	N/A	
PED-säännösten ilmoitettu laitos:	N/A	
EY-tyyppihyväksynnän sertifikaatti:	N/A	
Valtuutettu edustaja	Barry Wade Yhtisjärjestelmien kehityspäällikkö domnick hunter ltd	
Vakuutus Valtuutettuna edustajana vakuutan, että yllä olevat tiedot, jotka liittyvät tämän tuotteen toimittamiseen tai valmistamiseen, ovat standardien ja muiden asiaan liittyvien asiakirjojen mukaisia ja noudattavat yllä mainittuja direktiivejä.		
Allekirjoitus:		Päiväys: 28 / 09 / 05
Vakuutuksen numero: 0001/280905		

Declaration of Conformity		EN
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, UK AC010, 015, 020 025, 030 97/23/EC.		
Directives	Generally in accordance with ASMEVII Div 1: 2004.	
Standards used	Article 3.3 (AC 010, 015, 020, 025) Module A (AC 030)	
PED Assessment Route :	N/A	
Notified body for PED:	N/A	
EC Type-examination Certificate:	N/A	
Authorised Representative	Barry Wade Business Systems Improvement Manager domnick hunter ltd	
Declaration I declare that as the authorised representative, the above information in relation to the supply / manufacture of this product, is in conformity with the standards and other related documents following the provisions of the above Directives.		
Signature:		Date: 28 / 09 / 05
Declaration Number: 0001/280905		

Déclaration de conformité		FR
domnick hunter Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ, GB AC010, 015, 020 025, 030 97/23/EC.		
Directives	Généralement conforme à ASMEVII div. 1 : 2004.	
Normes utilisées	Article 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	
Méthode d'évaluation de la directive d'équipements de pression :	N/A	
Organisme de notification pour la directive d'équipement sous pression :	N/A	
Certificat d'examen de type CE :	N/A	
Représentant agréé	Barry Wade Business Systems Improvement Manager domnick hunter ltd	
Déclaration Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents liés déclarés selon les dispositions des directives susmentionnées.		
Signature :		Date : 28 / 09 / 05
N° de déclaration : 0001/280905		